



875-0439-10

Operator Guide

Revision: **A2**

April 7, 2021

GradeMetrix™

**Machine Control &
Guidance Software for
Excavators for v1.4.152**

Table of Contents

Device Compliance, License and Patents	4
Terms and Definitions.....	6
Chapter 1: Introduction	8
Overview	8
Product Overview	9
Key Features.....	10
Chapter 2: Getting Started with GradeMetrix.....	11
Overview	11
Software Installation.....	12
Operator Interface	15
GradeMetrix Main Menu	45
Chapter 3: Working with GradeMetrix Jobs	62
Overview	62
Menu Icons.....	63
Create a Job.....	64
Open a Job	77
Modify a Job.....	78
Delete a Job.....	80
Job Tools	81
File Tools	83
Chapter 4: Machine Configuration	84
Overview	84
Menu Icons.....	85
Equipment Setup	87
Calibrate Sensors	93
Quick Calibrate.....	94
3D Calibration	95
Radio Settings	96
NTRIP Configuration.....	101
Chapter 5: Navigation and Field Design.....	103

Overview	103
Menu Icons.....	104
Control	105
Navigation	108
Field Design.....	112
Grade 2D	121
Topo	138
Appendix A: Troubleshooting	145
Overview	145
GradeMetrix Troubleshooting	146
Appendix B: Supported Hardware	150
Overview	150
VR500 Vector™ Smart Antenna	151
VR1000 GNSS Receiver	157
IronOne Hardware	164
End User License Agreement	169
Warranty Notice	173

Device Compliance, License and Patents

Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 This device may not cause harmful interference, and
 this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

E-Mark Statement: This product is not to be used for driverless/autonomous driving.

Copyright Notice

Copyright Hemisphere GNSS, Inc. (2021). All rights reserved.
 No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™, Cygnus™, Atlas™, aRTK, SureFix™, and Athena™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

Continued on next page

Device Compliance, License and Patents, Continued

Notice to Customers Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc
8515 East Anderson Drive
Scottsdale, AZ 85255 USA
Phone: (480) 348-6380
Fax: (480) 270-5070
PRECISION@HGNS.COM
[HTTPS://WWW.HEMISPHEREGNSS.COM/](https://www.hemispheregnss.com/)

Technical Support If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.
8515 East Anderson Drive
Scottsdale, AZ 85255 USA
Phone: (480) 348-6380
Fax: (480) 270-5070
SUPPORT.HGNS.COM

**Documentation
Feedback**

Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website:

[HTTPS://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2](https://hemisphere.atlassian.net/servicedesk/customer/portal/2/user/login?destination=portal%2F2)

Terms and Definitions

Introduction

The following table lists the terms and definitions used in this document.

GradeMetrix terms & definitions

Term	Definition
Activation	Activation refers to a feature added through a one-time purchase. For features that require recurring fees, see Subscription.
BeiDou	BeiDou is a global navigation satellite system deployed and maintained by China.
DTM	Digital Terrain Model – the 3D grading of a job.
Ellipsoid	Ellipsoidal elevation refers to your height above the WGS84 ellipsoid.
Flat Pad	A set elevation that you grade to over the entire job site, regardless of design elevation.
Galileo	Galileo is a global navigation satellite system implemented by the European Union and European Space Agency.
Geoid	A model representing the shape of the earth, represented by mean sea level.
GLONASS	Global Orbiting Navigation Satellite System (GLONASS) is a Global Navigation Satellite System deployed and maintained by Russia.
GNSS	Global Navigation Satellite System (GNSS) is a system that provides autonomous 3D position (latitude, longitude, and altitude) and accurate timing globally by using satellites.
GPS	Global Positioning System (GPS) is a global navigation satellite system deployed and maintained by the United States.
Heading	The vector created from the primary to secondary antenna. It points to the direction that the receiver is facing.
Latitude	A measure of how far north or south you are on the earth. Uses degrees, with the equator at 0 degrees and the poles at 90 degrees (north or south).

Continued on next page

Terms and Definitions, Continued

**GradeMetrix
terms &
definitions,
continued**

Term	Definition
Longitude	A measure of how far east or west you are on the earth. Uses degrees with the prime meridian at 0. Positive degrees are east of prime meridian and negative degrees west.
NEZ	Refers to Northing, Easting, and Elevation.
Point of Interest (POI)	The point from which the cut/fill and NEZ information is derived.
Subscription	A subscription is a feature that is enabled for a limited time. Once the end-date of the subscription has been reached, the feature will turn off until the subscription is renewed.

Chapter 1: Introduction

Overview

Introduction This Operator Guide provides information to help you quickly set up your GradeMetrix application software for excavator operations.

Contents

	Topic	See Page
	Product Overview	9
	Key Features	10

Product Overview

**Product
overview**

GradeMetrix™ Excavator is a machine guidance solution for excavators of all sizes ranging from compact to large, with support for multiple bucket types, including tilt buckets.

Key Features

GradeMetrix Excavator key features

GradeMetrix Excavator software features:

- Rugged Hardware
 - Easy to Install
 - Optional laser receiver kit
 - Optional tilt bucket accessory kit
 - Simplified User Interface
 - Dynamic Cut/Fill
 - Supports industry standard files
 - Build flat pads
 - Build single, dual, or multiple slopes
 - Stake points
-

Chapter 2: Getting Started with GradeMetrix

Overview

Introduction The information in this chapter shows you how to install the GradeMetrix software for excavator and provides an overview of GradeMetrix functions.

Contents


	Topic	See Page
	Software Installation	12
	Operator Interface	15
	GradeMetrix Main Menu	45

Software Installation

Install GradeMetrix software

To install your GradeMetrix software, complete the following steps:

Table 1-1: Software Installation


Step	Action
1	<p>Click the Install file. The Select Destination Location screen displays. Verify the location is correct or click Browse to select another file location.</p> <p>Click to select “I accept the agreement” and then “Next” to accept End User License Agreement.</p> 
2	Click Next .

Continued on next page

Software Installation, Continued

Install
GradeMetrix
software,
continued

Table 1-1: Software Installation (continued)


Step	Action
3	<p>The Select Additional Tasks screen displays. Notice the option to Create a desktop shortcut is selected and click Next.</p> 

Continued on next page

Software Installation, Continued

Install
GradeMetrix
software,
continued

Table 1-1: Software Installation (continued)


Step	Action
4	<p>Click Install.</p>  <p>The GradeMetrix software installation begins on your computer.</p>

Operator Interface

Plan View

GradeMetrix is designed to open automatically when the IronOne starts up. When the software opens, you are brought directly to the **Plan View**. The **Plan View** has a variety of customizable views shown in the next section.

The **Plan View** has a variety of features.



Vertical Offset


Use the arrows on the bottom-left to add or subtract a vertical offset. For instance, in the example above, a 0.94 ft cut with a 0.00 vertical offset is shown. Clicking on the up arrow once adds a vertical offset of a tenth, decreasing the cut to 0.84 ft as seen in the example below.




Continued on next page

Operator Interface, Continued

Vertical Offset, continued



To add a specific vertical offset, or adjust the step size, click and hold the Cut/Fill arrow. The following dialogue window appears:



Continued on next page


Operator Interface, Continued

Vertical Offset, continued

You can enter a specific **Offset** in the **Offset** field. The **Step** field configures how much the vertical offset changes each time you click the arrow that is below the Cut/Fill bar.

To add **Preset** values, type a value in the **Offset** field. Next, click and hold one of the three values shown at the bottom. In the example below, **Preset 1** has values of 0.10 ft, 0.20 ft, and 0.30 ft.

To toggle between three independent sets of values, click **Preset 1**.



The image shows a 'Grading Setup' dialog box. At the top, there are four radio buttons: 'Grading' (selected), 'Steering', 'Limits', and 'Bucket'. Below these are two input fields: 'Offset: 0.30ft' and 'Step: 0.10ft', each with a keyboard icon to its right. At the bottom, there are four buttons: '0.10ft', '0.20ft', '0.30ft' (highlighted in blue), and 'Preset 1' (with a green and black striped icon). At the very bottom right are 'OK' and 'Cancel' buttons.

Continued on next page

Operator Interface, Continued

Vertical Offset,
continued

Grading Setup

Grading Steering Limits Bucket

Offset: 

Step: 

  Preset 2


Continued on next page

Operator Interface, Continued

Cut/Fill Bar

The Cut/Fill bar shown on the left side of the screen displays a red arrow when in a cut, a blue arrow when in a fill, and a green band when on grade, this is referred to as the Cut/Fill bar.

The absolute value of the Cut/Fill value determines the length of the arrow.




Continued on next page

Operator Interface, Continued

Cut/Fill Bar,
continued

The deadband is configurable. Click and hold the arrow. Click **Limits**. The following dialogue displays:



The image shows a 'Grading Setup' dialog box with four tabs: 'Grading', 'Steering', 'Limits', and 'Bucket'. The 'Limits' tab is selected and highlighted in green. Below the tabs are four rows of input fields, each with a keyboard icon to its right. The first row is 'Upper Limit: 1.50ft', the second is 'Upper Band: 0.10ft', the third is 'Lower Band: -0.10ft', and the fourth is 'Lower Limit: -1.50ft'. At the bottom right of the dialog are 'OK' and 'Cancel' buttons.

Field	Value
Upper Limit:	1.50ft
Upper Band:	0.10ft
Lower Band:	-0.10ft
Lower Limit:	-1.50ft

The **Upper Band** and **Lower Band** are “On Grade” tolerances. Any value between these two values (in the above example, -0.10 ft. and 0.10 ft.) is considered on grade.

Continued on next page


Operator Interface, Continued

Cut/Fill Bar, continued

The **Upper Limit** and **Lower Limit** affect the graphical scaling of the “Cut/Fill” arrow.

If you set the **Upper Limit** to 5.0 ft, when you have a 5 ft. cut, the cut/fill arrow displays at the top of the dialogue window.

In the following example, the **Upper Band** is set to 5 ft. Therefore, a cut of 2.58 ft. scales the arrow to about half the size of the dialogue window.




Continued on next page

Operator Interface, Continued

Guidelines

To select a guideline, click on a polyline. The following dialogue displays:



To select the station and change the direction, click **Flip the guideline**. You can create and save a filename or use the default filename. Click to select **Use this guideline** and click **OK**.


You can grade to the elevation associated with the line by selecting **Use for design elevation**. You must type in **Limit width**. Entering 10', for example, will create a surface 5' on both sides of the polyline.

Continued on next page

Operator Interface, Continued

Guidelines, continued

The surface is shown in purple. Choosing to grade to the elevation associated with a polyline will supersede any design surface that you have loaded. You will instead grade to the elevation associated with the line. The top-left of the screen will show “(3D Guideline)” next to the project name indicating you are grading to the elevation of the line and not a DTM.




Continued on next page

Operator Interface, Continued

Guidelines,
continued

To configure the **Guideline**, click and hold the Cut/Fill arrow.

Click the **Steering** tab. You can use this dialogue to create an offset, adjust the step, and change the **Guide Location** (change the query point from the left/center/right of bucket).



The **Grading Setup** dialog box features four tabs: **Grading**, **Steering** (selected), **Limits**, and **Bucket**. The **Steering** tab contains the following controls:

- Offset:** A text input field with the value `0.00ft` and a keyboard icon to its right.
- Step:** A text input field with the value `0.10ft` and a keyboard icon to its right.
- Use Guideline:** A text input field containing `GL_5.guide` and a dropdown arrow to its right.
- Guide Location:** A text input field containing `Left` and a dropdown arrow to its right.

At the bottom of the dialog are two buttons: **OK** (with a blue checkmark icon) and **Cancel** (with a red X icon).

Continued on next page

Operator Interface, Continued

Top panel icons The top panel icons contain a variety of options. The icons are shown below, and each option is described.




Figure 2-1: Top Panel Icons

Continued on next page


Operator Interface, Continued

Select View



To select a different view, click the  icon (upper right corner of the screen). Several examples are shown below.

The pop-up window displays a list of options:





Continued on next page

Operator Interface, Continued

Plan, Section, Cut/Fill view


The **Plan, Section, & Cut/Fill** view shows the **Plan** view on the left half of the screen. The right half of the screen is split showing both a **Section** view of the excavator tool (along with the surface) and a **Cut/Fill** value (0.26 ft. in the example below).



Continued on next page

Operator Interface, Continued

Big Cut/Fill view The **Big Cut/Fill** view displays the cut/fill value only.





Continued on next page

Operator Interface, Continued

Plan, Section, & Profile view

The **Plan, Section, & Profile** view shows the **Plan** view on the left side of the screen. The right side of the screen is split between a **Section** view of the bucket (and design surface) and a **Profile** view of the machine (and design surface).



Continued on next page

Operator Interface, Continued


Plan & Section view

The **Plan & Section** view shows the **Plan** view on the top of the screen, and the **Section** view of the tool on the bottom half of the screen (with the design surface).

The bottom of the screen is divided into two sections. The left section shows the cut (or fill) with an arrow pointing down (cut) or up (fill). Additionally, the vertical offset (0.00 in this example) is shown. The right section shows the cross slope of the cutting edge (in this example, 0.0%).

If using a standard bucket, this value is the same as the cross slope of the machine chassis. If using a tilting bucket, this value is independent of the chassis roll.


The cross slope of the design is also shown (-18.6% in this example).



Continued on next page

Operator Interface, Continued


Plan & Section view, continued



Continued on next page

Operator Interface, Continued


Plan only view The **Plan Only** view shows the machine on the linework with the Cut/Fill arrow on the left. The design surface is not shown in this view.



Continued on next page


Operator Interface, Continued

Dual Cut/Fill



The **Dual Cut/Fill** screen displays a cut/fill value on both sides of the bucket.

The Cut/Fill bar on the left shows the Cut/Fill value for the left side of your bucket, and the Cut/Fill bar on the right shows the Cut/Fill value for the right side of the bucket.



Continued on next page

Operator Interface, Continued

Quick Info

In the top panel icons, click the blue **information (“i”)** icon to view configurable text options, such as position, and number of satellites in use, etc.



(Press anywhere in the pop-down screen to hide the menu.)

The following table lists the terms and definitions found in the **information (“i”)** menu.

Table 2-1: Information menu

Term	Definition
Northing	The Northward-measured distance from the origin, or the “Y”-axis.
Easting	The Eastward-measured distance from the origin, or the “X”-axis.
Actual Z	The local height above the origin of the local coordinate system. Actual Z is the elevation, or the “Z” axis.
Design Z	The design elevation (Actual Elevation – Design Elevation = Cut Value (if negative-Fill Value).
Station	If using a guideline, indicates the current station on the guideline.
Cut/Fill	The difference between design and actual elevation.
Grading Offset	A small offset (positive or negative) to the Cut/Fill value.
Cross slope	The angle made between the left and right side of the tracks and a horizontal plane (also known as roll).

Continued on next page

Operator Interface, Continued

Quick Info,
continued

Table 2-1: Information menu (continued)


Term	Definition
Long slope	An angle made between the front and back of the machine and a horizontal plane (also known as pitch).
UTC Date	The date based on UTC (Coordinated Universal Time) time zone.
UTC Time	Coordinated Universal Time zone.
Solution	The solution should read "RTK Fixed".
SATs Used	The quantity of satellites the GNSS receiver is using in the position algorithm.
Visible SATs	The quantity of satellites tracked by the GNSS receiver.
Ground Speed	The speed of the machine travel based on position data.
Azimuth	The angular measurement between the vector created from the back of the machine to the front of the machine and north.
MBIAS	An offset in heading resulting in GNSS antenna placement. For instance, if the machine is facing north (azimuth = 0 degrees) and the receiver reports 358 degrees, there is an MBIAS of -2 degrees (assuming LBIAS is 0. See LBIAS).
LBIAS	The angle between Site North and WGS84 North. For instance, the point located at Northing = 1000, Easting = 500, Elevation = 200 is directly north of a point located at Northing = 500, Easting = 500, Elevation = 200. However, if there is a rotation in the localization, this may not equal true north. Azimuth (of machine) = Heading (from GNSS receiver) – MBIAS – LBIAS.

Continued on next page

Operator Interface, Continued


Quick Info,
continued

Note: Select/de-select which information fields you want to display by clicking the **Settings** icon, and **Info Summary**.



Click the  icon in the upper-right corner to view the **Information** screen.

Note: The **Information** screen icon is disabled when the **Quick Info** menu is displayed. Turn off the **Quick Info** menu to enable the icon.



Continued on next page

Operator Interface, Continued

Antenna Info

The **VR1000 Info (or VR500 Info, depending on the system in use)** tab provides the following information:

- **Raw Position Information** –raw position and GNSS quality information from the GNSS receiver.
- **Raw Status Information** –additional GNSS status information (i.e., dilution of precision, RMS values, RTK latency, and UTC time) from receiver.
- **Local Antenna Position** –the NEZ in local project coordinates.
- **Directional Information** – the GNSS heading as well as an indicator (if GNSS), or course over ground heading. It also gives the declination and speed. *Troubleshooting Tip: Heading should always read “GNSS.” If you do not have a Cut/Fill value, check to see if this value reads “Course over Ground.” See more information in the [Troubleshooting](#) section of this manual.*

The **Raw Position Information** displays the current plan values for:

- Latitude
- Longitude
- Height (orthometric height)
- Separation (geoid separation)
- Ellipsoid (ellipsoid elevation)
- Speed
- Solution
- SATS Used
- Visible SATS


Note: The **Local Antenna Position** displays the projected coordinates at the GNSS antenna.

Continued on next page

Operator Interface, Continued

Antenna Info,
continued

Note: To change latitude/longitude to a military grid or UTM (Universal Transverse Mercator) Go to **Settings -> Format**.



Continued on next page

Operator Interface, Continued


SAT View

The **SAT View** tab displays the available satellites. The strength of each satellite signal is color-coded.

Table 2-2: Satellite Signal Strength Indicators

Color	Description
Green	Strong signal. SNR > 32 dB
Yellow	SNR is greater than or equal to 27 dB, but less than 32 dB
Red	SNR is greater than or equal to 25 dB, but less than 27 dB
White	SNR is less than 25 dB

Satellites that are blinking have an elevation of 3 degrees or less.




Continued on next page

Operator Interface, Continued

SAT Info

The **SAT Info** tab displays data-driven detail about each satellite used in the solution.



PRN	ELEV	AZI	L1:Trk	L2:Trk	L5:Trk
G002	46°	264°	46	44	
G005	33°	306°	38	36	
G006	39°	205°	39	36	41
G007	68°	97°	51	48	
G009	48°	59°	44	41	43
G013	8°	254°	28	25	
G016	6°	33°	30	28	
G023	11°	71°	28	27	
G029	2°	323°	27	26	
G030	53°	178°	49	47	48
R005	37°	170°	39	37	
R006	71°	278°	51	50	
R007	25°	327°	33	31	
R009	33°	248°	34	33	
R015	29°	41°	34	32	
R016	71°	313°	56	54	
R017	9°	74°	25	24	
R024	8°	25°	25	24	

Continued on next page


Operator Interface, Continued

Sensor Info

The **Sensor Info** tab displays all the configured sensors. You can check the sensor operation and the pitch and roll.

Click **Show Calibrated Values** to view the calibrated (rather than raw) tilt sensor value.

The green check mark indicates a sensor is connected. If you do not have a cut/fill value and you see a sensor that is not connected, there may be a failed sensor or cable. See the [Appendix A, Troubleshooting](#) section for more information.



Continued on next page


Operator Interface, Continued

VEH Info

The **VEH Info** tab displays the following information:

- **Vehicle**-Northing, Easting, Elevation, and Station
- **Status**-Azimuth, MBias, LBias, Speed, Direction, Status
- **Design**-Elevation, Cut/Fill, Grading Offset, Cross-Slope, Long-Slope

The **2D Point Check** and **3D Point Check** are critical features to diagnose errors and check the quality of a calibration. For more information regarding those features, please consult the HGNSG GradeMetrix Excavator Installation Guide.




Continued on next page

Operator Interface, Continued

Modules

The **Modules** tab displays a listing of modules used and the status of each module.



Module	Status	Software Version
GradeMetrix Interface	Operational	1.0.28
Alert Manager	Asleep	1.0.28
Log Manager	Asleep	1.0.28
GNSS Position (JoystickSim)	Operational	1.0.8
Model Manager	Operational	1.0.28
Position Model	Operational	1.0.28
Design Model	Operational	1.0.28
Grading Model	Operational	1.0.28

Return to main screen



Click the  icon to de-select and return to the GradeMetrix Main screen.

Continued on next page

Operator Interface, Continued

GradeMetrix file requirements



Click the three bars () on the top-left to enter the **Main Menu**.

The following screen displays. Use the arrows on the left and right to toggle between pages.



GradeMetrix Main Menu

Main Menu

The GradeMetrix **Main Menu** displays the following icons. You can use the arrows on the left and the right of the screen to scroll between screen 1 and screen 2.

For a breakdown and listing of **Main Menu** icons related to specific functions (i.e., create a job), refer to the beginning of Chapters 3 through 5 in this manual.

Administrator settings

To enable **Administrator** permissions, click the figure icon on the bottom left side of the GradeMetrix **Main Menu**.




Continued on next page

GradeMetrix Main Menu, Continued

Administrator settings,
continued

A pop-up window displays. Click to select the **Administrator** checkbox.

To set the **Administrator** password, click the **Settings** icon and select the **General** tab. Click the keyboard icon and type your desired password.



Continued on next page

GradeMetrix Main Menu, Continued


Settings

On the lower-left portion of the GradeMetrix **Main Menu**, click the gear icon to access **Settings**.



Note: You must be logged on as an **Administrator** to make changes to some GradeMetrix **Settings**.

The **Settings** window displays. The left navigation menu lists the GradeMetrix **Settings** options:




Continued on next page

GradeMetrix Main Menu, Continued

General settings The **Application Theme** can be changed. Click the drop-down arrow to select from default or pre-set custom views.

Click in the **Collect Samples For:** keyboard icon and type in the desired value in seconds.

To save your settings, click **Ok**. To cancel your changes, click **Cancel**.




Continued on next page

GradeMetrix Main Menu, Continued

Languages

GradeMetrix supports English (American), English (British), Spanish, and Japanese languages.

Click to highlight your desired language. If you wish to change the language, you must reboot the software after making any changes.



Continued on next page

GradeMetrix Main Menu, Continued


System logs

In the **System Logs** screen, click in the field to set the system logging options.

Table 2-3: System Logs

Option	Function
User Log Cache Size	Determines number of logs held in memory before flushing them to a disk.
Save User Log Every	Performs an autosave to disk.
Enable logging user interaction	Logs all user interactions.
Alert Cache Size	Determines number of logs held in memory before flushing them to a disk.
Save Alerts Every	Performs an autosave to disk.
Enable logging system alerts	Saves error message (GPS errors, sensor errors, etc.).

When you are finished setting the system logging options, click **Ok**. To cancel your changes, click **Cancel**.



Continued on next page

GradeMetrix Main Menu, Continued

Model

On the **Model Options** screen you can check and edit the location settings for your GradeMetrix job in the **Model** screen. Click to select/edit the following fields:


Table 2-4: Model Options

Option	Description
Steering Query Location:	Selects machine POI for steering reference.
Speed and Heading Rate:	The rate at which reverse state is determined.
Motion Detection Tolerance:	GradeMetrix uses your GNSS position to determine motion. Note: A change in position is required for GradeMetrix to set the machine from moving to stopped position.
History Distance Tolerance:	Records the cumulative history movement and sets a history marker.
Maximum History Size:	The amount of history markers stored for your previous points.
Enabling Cut/Fill:	The default (and suggested) setting is When RTK Fixed . If the GNSS receiver loses an RTK Fix, Cut/Fill will no longer display. If set to Allow aRTK Fixed , Cut/Fill will display if the receiver drops into an aRTK™ Fix. If Allow Atlas is selected, the receiver will show Cut/Fill when Atlas® is converged, the receiver is aRTK Fixed, and the receiver is RTK Fixed. If set to Always Show, Cut/Fill will always display (even when RTK isn't available).
HRMS Tolerance:	Sets the Horizontal RMS thresholds for when an alert will occur.
VRMS Tolerance:	Sets the Vertical RMS thresholds for when an alert will occur.

Continued on next page

GradeMetrix Main Menu, Continued

Model,
continued



Click to select the checkbox to select **Enable avoidance zones and surfaces**. If the module is built with avoidance zones, an alarm will sound when entering those zones.


To save your settings, click **Ok**. To cancel your changes, click **Cancel**.

Continued on next page

GradeMetrix Main Menu, Continued

As-Built

The **As-Built** option tracks job progress, and can be configured for pass counts, or Cut/Fill.



Continued on next page

GradeMetrix Main Menu, Continued

Site map

Use the **Site Map** screen to set display and zooming views for your GradeMetrix job.

Click the down-arrow to select any of the following options from the pop-up window.

Show Display As: There are three display options to view your machine as the map rotates:

1. **Moving Map**-machine always faces the top of the screen as the map rotates.
2. **Fixed Rotation**-machine stays in a static position and the map will point toward the specified direction (i.e., north, south, east, west).
3. **North Up**-the top of the map is always north.

Click the keyboard icon to the right of the following fields to separate auto center and manage zooming:


- **Rotation Angle:** if using fixed rotation, enter the degrees to rotate the map clockwise.
- **Zooming Factor:** set the numeric value to zoom on the right side of the plan view (The greater the value set (50 or above), increases the zoom out.)
- **Auto center the machine when the moving map is not selected:** the view adjusts as your machine moves to prevent your machine from driving off screen.

Continued on next page

GradeMetrix Main Menu, Continued

Site map,
continued

Manage zooming while navigation and surveying: when staking out a point, the view will zoom in closer to the point.



To save your settings, click **Ok**. To cancel your changes, click **Cancel**.

Surfaces

The **Surfaces** option enable/disable on the background surfaces shown on the plan view.

Select from these options:

- Show Using:
- On-Count Color:
- Passes Color:

Show Cut/Fill-select the box to display Cut/Fill surfaces on the **Plan View** and color the grid based upon the Cut/Fill value.

Note: This option is only available if an existing surface file is loaded.

Continued on next page

GradeMetrix Main Menu, Continued

Surfaces,
continued

The **Site Plan Options** can be enabled/disabled to show on the **Plan View**.

Refer to Table 2-5 for a description of each option according to the view you select.

Table 2-5: Site Plan Options and Views

Site Plan Option	Selected	Not Selected	View
Show Opaque Vehicle	X		The chassis of the excavator will be filled in.
		X	The excavator chassis will be transparent, allowing for better viewing of the linework.
Show Compass	X		A compass is shown on the Plan View .
Show Guideline	X		This option must be checked for the guideline to display.
Show Stake Points	X		Each topo point in the topo file you have loaded will be shown with a marker on the Plan View .
Show Stake Text	X		The topo points shown on the screen will have the point number displayed on the screen next to the point marker.

Continued on next page

GradeMetrix Main Menu, Continued

Surfaces,
continued


Table 2-5: Site Plan Options and Views (continued)

Site Plan Option	Selected	Not Selected	View
Show Machine History	X		Breadcrumbs display on the screen indicating the machine path. Go to the Model tab to configure how many markers are stored and at what distance interval they are to be stored.
Show Linework		X	The linework from your Plan View file will not display on the screen.
Show Plan Text	X		Text on the Plan View will display.
Show Scale Ruler	X		A distance scale will display in the Plan View .
Show Heading Bias Line	X		Two lines will be drawn on the excavator. The angle between those two lines is equal to the MBIAS of your machine.
Show Machine Markers	X		Circles will be drawn on both sides of the bucket, the boom pin, and primary antenna. This only affects the overhead view.
Show Query Markers	X		The guideline location query location is shown on the excavator as a red circle and the cut/fill location is shown as a green triangle.

Continued on next page

GradeMetrix Main Menu, Continued

Surfaces, continued




Continued on next page

GradeMetrix Main Menu, Continued

Info Summary tab

The **Info Summary** screen displays the list of text options to display on the **Quick Info** screen. Click to select the options you wish to display.

To de-select an option, click the box a second time. After making your selections, click **Ok**.



Continued on next page

GradeMetrix Main Menu, Continued

Formats


The **Display Format Options** screen lists the format options that can be displayed for a job. Click the down-arrow to the right of each field to change a selection.

- **Geodetic Format**-Displays latitude/longitude, UTM, or military grid.
- **Station Format**-Selects format to show stationing and offset.
- **Length Format**-Selects the unit of measure for northing, easting, and elevation.
- **Angular Format**-Selects between Degrees and Gradians,
- **Slope Format**-Selects between percent and degrees.

Note: If “Use the units specified in the current job” is selected, you will not be able to select **Length Format** and **Angular Format** since job units will be used.

Show Current Time As-Click the down-arrow to select **Local**, **UTC**, or **Do Not Show**.

Click **Ok** to return to the GradeMetrix **Home** screen.




Continued on next page


GradeMetrix Main Menu, Continued

Exit GradeMetrix

To exit GradeMetrix, click the red power icon in the lower left side of the GradeMetrix **Main Menu**.



Highlight and click the **Shutdown** option. The confirmation message displays:



Click **Yes**. The GradeMetrix application closes.

Chapter 3: Working with GradeMetrix Jobs

Overview

Introduction This chapter covers the information you need to create, modify, delete and design jobs in GradeMetrix.

Contents

	Topic	See Page
	Menu Icons	63
	Create a Job	64
	Open a Job	77
	Modify a Job	78
	Delete a Job	80
	Job Tools	81
	File Tools	83

Menu Icons

Menu icons

The following icons are used to perform job functions in GradeMetrix.

Table 3-1: Main Menu Icons-Job Functions

Icon Name	Icon	Description
New Job <i>(must be accessed by authorized Admin user)</i>		Create a new job.
Open Job		Open an existing or saved job.
Modify Job		Edit an existing or saved job.
Delete Job		Delete a created job.
Job Tools		Export a job file to external storage or rename a job.

Create a Job

Overview

Before creating a job in GradeMetrix, review the files and file formats supported by GradeMetrix.

Files and formats used in GradeMetrix

Various files are loaded into GradeMetrix on specific, recommended directories on the Control Panel using two different methods:

1. Manually selecting files in GradeMetrix from memory sticks (USB drives, thumb drives, etc.) or
2. Using Windows Explorer to copy files.

GradeMetrix can support the following files and file formats:

- Site Plan File: DWG, DXF, LandXML
 - Surface Model File: DWG, DXF 3D face triangles or polylines, TIN, FLT, GRD, LandXML, and LandXML Grid
 - Survey Topo File: TOPO
 - Tin File: MESH, TIN, NTR, DXF, DWG, FLT
 - Geoid File: BIN
 - Localization File: LOCAL (SiteMetrix™ Grade), LOC (SiteMetrix), .COT (SiteMetrix Survey)
-


Continued on next page

Create a Job, Continued

Create a job

To create a job, on the GradeMetrix **Main Menu** (screen 1), click **New Job**. The **Job Basics** screen displays.

Note: You must be logged in as an **Administrator** to create a new job in GradeMetrix. The **New Job** icon is disabled for all other users.




Continued on next page

Create a Job, Continued

Job basics screen

Click the keyboard icon and type the job name, description and job notes.

Click **Next**.




The screenshot shows a software window titled "Job Basics". It contains three text input fields: "Name" with the value "New Job Example", "Description" with the value "This is my new job.", and "Notes" with the value "These are my notes.". Each field has a small keyboard icon on its right side. At the bottom right of the window, there are three buttons: "Back", "Next", and "Cancel". The "Next" button is highlighted with a red rectangular box.

Continued on next page

Create a Job, Continued

Job files screen Click the document icon to the right of each field to add files to your GradeMetrix job:

- Localization
- Geoid Separation
- Horizontal Shift
- Linework
- Guideline
- Survey Topo



Job Files

Localization: 

Geoid Separation: 

Horizontal Shift: 

Linework: 

Guideline: 


Survey Topo: 

Continued on next page

Create a Job, Continued

Job files screen,
continued

To add Job Localization, click the document icon to the right of the **Localization** field.



To add **Geoid Separation**, **Horizontal Shift**, **Linework**, **Guideline**, and **Survey Topo**, click the document icon to the right of that field.

After adding all the associated **Job Files**, click **Next**.


Continued on next page

Create a Job, Continued

Surface options window

The **Surface Options** window displays. Click **Add** and select the file.

Note: You can add multiple types of surfaces.



Continued on next page

Create a Job, Continued

Surface options window, continued

Click the down-arrow to select a **Work Type** option.


- **Design**- This is the most commonly selected option. The Design surface is the surface you are grading to.
- **Actual** –Select **Actual** if you have a jobsite topo to upload to the current actual surface.
- **Warning** – Select to trigger a warning in the software if your elevation is either above or below the uploaded surface (see **Alert Method**).
- **Watch** – This is similar to Warning. This allows for two levels of alert (i.e., you can choose to upload a ‘Watch’ surface to set low priority alerts to an operator and set another ‘Warning’ surface for higher priority alerts to an operator.
- **Pass Count** –Select to color the screen based on how many times a machine has passed over a grid cell.

Continued on next page

Create a Job, Continued

Surface options window, continued

The option you selected displays in the **Work Type:** list.



In addition to **Work Type**, the following options are available:

- Fill Style
- Fill Color
- Line Style
- Line Color
- Alert Method: This option is available when **Work Type** is set to **Warning** or **Watch**. This can be set to **Alert When Below**, **Alert When Above**, or **When Crossing**.
 - **Alert When Below** issues an alert when the cutting edge of the machine is below the warning or watch surface and can be used to prevent over cutting. If set to **Alert When Above**, an alert is issued when the cutting edge is above the surface. This alert could be used for safety purposes. If set to **When Crossing** an alert is set if you are on a dangerous surface, such as a gas well.

Continued on next page

Create a Job, Continued

Surface options window, continued

There are two checkboxes: **Show in Views** and **Always on Top**. Selecting **Show in Views** will allow the surface to show up in the Plan View section and profile views.

Always on Top will show the surface (if a secondary surface) above the primary surface. For instance, you can load multiple design surfaces. The surface at the top of the list drives the Cut/Fill. The other surfaces can be used visually. For instance, if you are cutting to ore and want to see ore deposits, you can upload a surface, click **Always on Top**, and see the surface.

Continued on next page

Create a Job, Continued


Job Mapping window

The **Job Mapping** window displays.

Click the down-arrow to select units for the following fields:

- Units of Measure
- Transform Method
- Alignment Method

Click to use the keyboard icon and type the **Job Scale**.



The screenshot shows the 'Job Mapping' window with the following fields and controls:

- Units of Record:** US-Survey Feet (dropdown menu)
- Transform Method:** Similarity (dropdown menu)
- Alignment Method:** Align to Grid (dropdown menu)
- Job Scale:** 1.0000000000000000 (text input field with a keyboard icon)
- Geo-reference/State Grid:** UTM/UPS Standard (text input field)
- Navigation:** Back, Next, and Cancel buttons at the bottom right.

A red box highlights the dropdown arrows and the keyboard icon in the right-hand column of the form.

Continued on next page

Create a Job, Continued

Job Mapping window,
continued

To set a geographical reference grid, click **Geo-reference/State Grid**. Click to select from the displayed list.

Click **Next**.



Continued on next page

Create a Job, Continued

Job Localization screen

The **Job Localization** screen displays. Click **Add**.



The screenshot shows a software window titled "Job Localization". Inside the window, there is a table with the following column headers: Latitude, Longitude, Height, Northing, Easting, and Elevation. The table body is currently empty. At the bottom right of the window, there is a control bar with several buttons: "Remove" (with a minus sign), "Add" (with a plus sign and highlighted by a red box), "Edit" (with a plus sign), "Back" (with a left arrow), "Finish" (with a checkmark), and "Cancel" (with an X).

Click the keyboard icon to the right of each field to set the localization settings:

- Latitude
- Longitude
- Height
- Type (drop-down arrow to select **Ellipsoid** or **Geoid**)
- Northing
- Easting
- Elevation

Continued on next page


Create a Job, Continued

Job Localization screen, continued



The **From Stake List** button-allows the user to select a control point from the stake list.

Use the drop-down arrow next to **Use In Solution:** to select from the following localization display options:



If residuals are high for the point, you may opt to not use the point. Or, if residuals are high for one component (horizontal or vertical), you may opt to turn off that one component. Click **Ok**. Click **Finish**.


Open a Job

Open a job

To open an existing Job in GradeMetrix, on the **Home** screen, click the **Open Job** on the GradeMetrix home screen.



The file explorer displays. Navigate to the desired job and click to highlight the job you want to open. Click **Open**.




Modify a Job

Modify a job

To modify an existing job in GradeMetrix, click the **Modify Job** icon on the GradeMetrix **Main Menu**.

Note: To modify some **Job** files, you must be logged in as an **Administrator**.




Continued on next page

Modify a Job, Continued

Modify Job,
continued

In the **Modify Job** screen you can change your **Mapping** settings, Job **Files**, and **Localization**. See **Create a Job** for a description of each feature.



The screenshot shows a software window titled "Job Basics". On the left is a navigation pane with icons and labels for "Basics", "Files", "Surfaces", "Mapping", and "Localization". The "Basics" tab is selected. The main area contains the following fields:

- Name:** Maricopa
- Description:** Hemisphere Test Site
- Notes:** (An empty text area)

At the bottom right of the window are "OK" and "Cancel" buttons. A lock icon is visible in the bottom left corner of the window frame.


Delete a Job

Delete a job

To delete a job created in GradeMetrix, on the **Main Menu**, click the **Delete Job** icon.



Click to highlight the name of the job you wish to delete and click **Delete**.



Job Tools


Job Tools

On the GradeMetrix **Main Menu**, click the **Job Tools** icon.



You can select from two options:

1. **Export Job** – Save your job to a thumb drive.
2. **Import LandXML** – This routine allows you to import a LandXML file and convert it to a surface.




Continued on next page

Job Tools, Continued

Job Tools,
continued

3. **Copy Job** – Create a clone of your job.
4. **Rename Job** – Change the name under which the job is saved.




File Tools

File tools

File Tools has several functionalities:

1. Backup job settings
2. Restore job settings (from a backup file)
3. Export Grid
4. Export Tin
5. Export Topo



To export files, click **Export File**. Click to select your job in **Export from:**. Click on the folder next to **Export to** to select a location to save from.

To Export grid, click to check **Export grid as**. Select on the dropdown box to the right to select from **LandXML**, **DXF**, or **CSV**.

To Export tin, click to check **Export tin as**. Click on the dropdown box to the right. Select from **LandXML** or **DXF**.

To Export topo, click to check **Export topo as**. Click on the dropdown box to the right. Select from **LandXML** or **CSV**.

Chapter 4: Machine Configuration

Overview

Introduction This chapter contains all the information you need to configure your excavator to use GradeMetrix software.

Contents


	Topic	See Page
	Menu Icons	85
	Equipment Setup	87
	Calibrate Sensors	93
	Quick Calibrate	94
	3D Calibration	95
	Radio Settings	96
	NTRIP Configuration	101

Menu Icons

Menu icons

The following icons are used to perform machine configuration functions in GradeMetrix.

Table 4-1: Main Menu Icons-Machine Configuration

Icon Name	Icon	Description
Equipment Setup		Use in administrator mode. Configure the dimensions of your machine, the GNSS hardware you're using, and save/load these settings.
Calibrate Sensors		Wizard to run you through the process of calibrating the chassis, boom, stick, dogbone, and (possibly) tilt bucket sensors.
Quick Calibrate		Use Quick Calibrate to manually calibrate a single sensor.
3D Calibration		This icon is used to calibrate the primary GNSS antenna offsets as well as the heading offset of the receiver. For complete instructions, please refer to the Hemisphere GNSS GradeMetrix Excavator Installation Guide.
Radio Settings		Configure the internal UHF radio. Authorized personnel can upload channel tables (frequencies and channel spacing) or configure the channel table from within the software. Any user (such as an operator), can select from pre-defined channels and set the protocol/modulation/FEC (for protocols that allow setting FEC).

Continued on next page

Menu Icons, Continued

Menu icons,
continued

Table 4-1: Main Menu Icons-Machine Configuration (continued)


Icon Name	Icon	Description
NTRIP Configuration		This dialogue is an NTRIP client for configuring RTK over network.

Equipment Setup


Equipment Setup

On the GradeMetrix **Main Menu** (screen 2), Use **Equipment Setup** to configure and dimensions and sensors for your machine.

This manual contains limited information on how to upload a machine configuration and hang buckets. For full details on Equipment Setup, please see the HGNSS GradeMetrix Excavator Installation Guide.



When you open Equipment Setup, the following screen displays:




Continued on next page


Equipment Setup, Continued

Equipment Setup, continued

Click **Import From...** to upload an existing machine file.



Navigate to the location of the machine file, select the machine file, and click **Open**.



Continued on next page

Equipment Setup, Continued

Equipment Setup, continued

The display updates to show the current dimensions and sensors for the machine you are uploading:

Identity				Antenna	
Name: Excavator				Type:	VR1000
Ident: CAT349				Right:	-3.281ft
				Behind:	4.921ft
				Height:	1.640ft
Geometry				Sensor Mapping	
Link Name	Length	Width	Height	CANid	Placement
artic	0.000ft			1000	Chassis
boom	19.685ft			4010	Boom
bucket	4.921ft	6.562ft		4020	Stick
chassis	13.123ft	9.842ft	6.562ft	4000	Dog-Bone
I1	1.312ft			2000	Bucket
I2	1.312ft				
I3	1.312ft				
I4	1.312ft				
I5	0.000ft				
pivot			4.101ft		
stick	9.842ft				

Click **Finish**.

GradeMetrix allows you to move the IronOne hardware between various machines. For example, if you have two excavators, you can purchase one complete GradeMetrix Excavator system and an additional wiring kit. You can then move the VR1000/500 and the IronOne hardware from one machine to another and then load the proper machine dimensions using the **Import from** routine.

Continued on next page

Equipment Setup, Continued

Equipment Setup,
continued

After your machine is installed, you can add multiple buckets. To change buckets, go to **Equipment Setup**. Click **Next**.

General Settings

Excavator

Machine Type: Excavator

Machine Id: Demo Joystick

Measurement Unit: Feet

Recent Machines:

Import From...

Back Next Cancel

Click **Bucket**.

Machine Geometry

Antenna Chassis Slew Offset Lengths Laser Dog-Bone **Bucket**

Standard Bucket

3 Foot Bucket

1. Length: 3.000ft

2. Width: 6.562ft

3. L3: 1.312ft

Quick disconnect installed


Back Next Cancel

Continued on next page

Equipment Setup, Continued


Equipment Setup, continued

The installer may have calibrated several buckets. Click on the down arrow next to the bucket type.



A screenshot of a software interface showing a list of bucket types. The first item is "Standard Bucket" with a blue downward arrow icon to its right, which is highlighted with a red square. Below it is "3 Foot Bucket" with a blue downward arrow icon, a keyboard icon, a floppy disk icon, and a red "X" icon.

A list of supported bucket types displays:




A screenshot of a dialog box showing a list of supported bucket types. The list includes "Standard Bucket", "Tilting Bucket", "Shovel Bucket", and "Leveling Bucket". Each item has a radio button to its left. The "Standard Bucket" radio button is selected. At the bottom right of the dialog is a "Cancel" button with a red "X" icon.

Continued on next page

Equipment Setup, Continued

Equipment Setup,
continued

Click to select the correct bucket type. Then click on the down arrow next to the bucket name.



After selecting the correct bucket, click **Next**. You will be navigated to the sensor page. Click **Next** again. You will then be navigated to the summary page. Click **Finish**.

Calibrate Sensors

Calibrate sensors

For full details on calibrating sensors, please see the HGNSS GradeMetrix Excavator Installation Guide.

Quick Calibrate

Quick calibrate For full details to quick calibrate sensors, please see the HGNS
GradeMetrix Excavator Installation Guide.

3D Calibration

3D Calibrate


For full details on 3D calibration, please see the HGNSG GradeMetrix Excavator Installation Guide.

Radio Settings

Overview

If receiving RTK corrections via the internal UHF radio, you can configure the radio through GradeMetrix.

On the GradeMetrix **Main Menu**, click the **Radio Settings** icon.



Continued on next page


Radio Settings, Continued

Satellite configuration

The **Satellite Configuration** screen displays three tabs:

- Basic Configuration
- Channel Configuration
- Call Sign Configuration

Click the **Import Radio Configuration** button to load a channel file. The explorer window displays. Click to locate and select the configuration file you wish to use.



The screenshot shows the "Satellite Configuration" window with three tabs: "Basic Configuration" (selected), "Channel Configuration", and "Call Sign Configuration". The "Basic Configuration" tab displays the following information:

- SN: 1709000SIM
- Version: V07.27.2.S.I.M
- Channel: CH 01 (dropdown menu)
- CH 1, RX 451.800000 MHz, BW 12.5 kHz
- Protocol: SATELLINE-3AS (dropdown menu)
- FEC: Off (dropdown menu)

At the bottom of the window, there is an "Import Radio Configuration..." button with a folder icon. The bottom right corner of the window contains "OK" and "Cancel" buttons.

Continued on next page

Radio Settings, Continued


Satellite configuration, continued

On the **Basic Configuration** tab, click the down-arrow to select values for the following fields:

- Channel
- Protocol
- FEC

On the **Channel Configuration** tab, click the down arrows to select values for **Frequency** and **Channel Width**.

Note: You must be logged in as an **Administrator** to set the **Channel Configuration**.



The screenshot shows the 'Satellite Configuration' dialog box with the 'Channel Configuration' tab selected. The dialog has three tabs: 'Basic Configuration', 'Channel Configuration', and 'Call Sign Configuration'. The 'Channel Configuration' tab is active, showing a table with 10 channels. Each channel has a 'Channel' label, a 'Frequency' input field with a dropdown arrow, and a 'Channel Width' input field with a dropdown arrow. The first five channels are pre-filled with values: Channel 1 (451.800000MHz, 12.5KHz), Channel 2 (469.550000MHz, 25.0KHz), Channel 3 (464.500000MHz, 25.0KHz), Channel 4 (462.125000MHz, 25.0KHz), and Channel 5 (464.550000MHz, 25.0KHz). Channels 6 through 10 are empty. At the bottom right, there are 'OK' and 'Cancel' buttons.


Channel	Frequency	Channel Width
Channel 1	451.800000MHz	12.5KHz
Channel 2	469.550000MHz	25.0KHz
Channel 3	464.500000MHz	25.0KHz
Channel 4	462.125000MHz	25.0KHz
Channel 5	464.550000MHz	25.0KHz
Channel 6		
Channel 7		
Channel 8		
Channel 9		
Channel 10		

Continued on next page

Radio Settings, Continued

Satellite configuration, continued

Channel Width selections




A dialog box for selecting channel width. It contains two radio button options: '12.5KHz' (selected) and '25.0KHz'. Below these options is a 'Cancel' button with a red 'X' icon.

Continued on next page

Radio Settings, Continued

Satellite configuration, continued




The image shows the 'Satellite Configuration' dialog box with the 'Channel Configuration' tab selected. It features a table with 10 channels. The first five channels are pre-filled with frequencies and channel widths. Channels 6 through 10 are empty. At the bottom right, there are 'OK' and 'Cancel' buttons.

Channel	Frequency	Channel Width
Channel 1	451.800000MHz	12.5KHz
Channel 2	469.550000MHz	12.5KHz
Channel 3	464.500000MHz	25.0KHz
Channel 4	462.125000MHz	25.0KHz
Channel 5	464.550000MHz	25.0KHz
Channel 6		
Channel 7		
Channel 8		
Channel 9		
Channel 10		

When finished making your selections, click **Ok**.

On the **Call Sign Configuration** tab, type a call sign message and select the message rate frequency. Click **Ok**.




The image shows the 'Satellite Configuration' dialog box with the 'Call Sign Configuration' tab selected. It features a 'Message:' text field, a 'Send call sign every' checkbox, and a frequency input field. At the bottom right, there are 'Ok' and 'Cancel' buttons.

NTRIP Configuration

NTRIP configuration

If receiving RTK over a network, use the embedded NTRIP client to receive RTK corrections from an NTRIP caster. On the GradeMetrix **Home** screen, click the **NTRIP Configuration** icon.



The **NTRIP Configuration** screen displays.

The screenshot shows the NTRIP Configuration screen with the following fields and controls:

- Casters:** A dropdown menu with a list icon.
- Host Address:** A text input field with a list icon.
- Port:** A text input field with the value '0' and a list icon.
- UserName:** A text input field with a list icon.
- Password:** A text input field with a list icon.
- Mount Point:** A dropdown menu with a list icon and a 'Download Source Table' button.
- Send Position to Caster Every:** A checkbox and a dropdown menu with the value '10 Seconds'.
- Buttons:** '+ Add', 'X Remove', 'Settings', and 'Connect To Caster'.
- Transfer Rate:** A label next to the 'Settings' button.
- Close:** A 'Close' button in the bottom right corner.


Continued on next page

NTRIP Configuration, Continued

NTRIP configuration, continued

Follow these steps to populate the **NTRIP Configuration** information.

Step	Action
1	Type in a name for the Caster . Type the IP (or DNS), port, Username , and Password .
2	Some NTRIP casters will require you send a position to the caster on a set interval (VRS networks and networks with a “nearest” option require this). If your caster requires this, click the checkbox next to Send Position to Caster Every and select the interval.
3	Click Download Source Table . The source table will download and the list of available mountpoints display. Select the appropriate mountpoint.
4	If you click Add , this caster will be saved as a list of available casters to select from (see Casters at the top of the screen). If you do not click Add , you can still use the NTRIP caster, but the default caster will be used, and you cannot save a list.
5	Click Setting . Select the option to auto-connect when the software opens and auto-reconnect to restore a temporarily lost internet connection.
6	Click Connect To Caster .



Chapter 5: Navigation and Field Design

Overview

Introduction Chapter 5 contains all the information you need to set up navigation and field design using GradeMetrix software.

Contents



	Topic	See Page
	Menu Icons	104
	Control	105
	Navigation	108
	Field Design	112
	Grade 2D	121
	Topo	138

Menu Icons

Menu icons

The following icons are used to perform navigation and field design functions in GradeMetrix.


Table 5-1: Main Menu Icons-Navigation and Field Design

Control		Check position and measurements. To check the accuracy of your results, compare the NEZ of the cut/fill location to a known NEZ. If the error displayed is not within specification, refer to Appendix A, Troubleshooting .
Navigation		Enter an NEZ or select from a list of control points. Grade Metrix provides distances/directions to that point.
Field Design		Use Field Design to create a surface when a model is not available.
Grade2D		This is for 2D operation. You can bench and dig and use an optional laser for elevation.
Topo		Use for conducting a topo. Software can be configured to automatically or manually store points in interval (distance or time).

Control

Control

On the GradeMetrix **Main Menu**, click the **Control** icon.



The **Check Position** screen displays. Click **Select ...** to set the **Control Point**.

Check Position		Measurement Information
Control Point:	<input type="text" value="Select..."/>	Northing:
Record At:	<input type="text" value="Center"/>	Easting:
<input type="checkbox"/> Check Using GNSS	<input type="text" value="0%"/>	Elevation:
		SATS Used:
		H Precision:
		V Precision:
		Elapsed:
		Samples:
Current Position Northing: 50,540.21ft Easting: 60,843.92ft Elevation: 509.94ft		
		<input type="button" value="Close"/>

Continued on next page

Control, Continued

Control,
continued

Click to highlight the point name and click **Ok**.

Enter/Select Position

Northing:

Easting:

Elevation:

Name	HDist	Northing	Easting	Elevation	Code	Information
4 (SimBasePos)	3.66ft	50,549.42ft	60,797.90ft	502.35ft		
5	366.77ft	50,272.17ft	60,552.23ft	502.16ft		
2	449.97ft	50,947.08ft	61,000.83ft	503.51ft		
1	567.10ft	50,000.00ft	60,945.98ft	504.27ft		
BASE	596.19ft	50,002.40ft	61,038.58ft	511.51ft		
3	965.19ft	50,000.00ft	60,000.00ft	500.00ft		

Click the down arrow to select the **Record At:** reference point, and select from the following options:

Check Position

Control Point:

Record At:

Check Using GNSS

Slew-Center

Left

Center

Right

Current Position

Northing: 50,546.80ft
Easting: 60,795.24ft
Elevation: 503.73ft

Measurement Information

Northing:
Easting:
Elevation:
SATS Used:
H Precision:
V Precision:
Elapsed:
Samples:

Selected Point


Name: 4 (SimBasePos)
Northing: 50,549.42ft
Easting: 60,797.90ft
Elevation: 502.35ft

Continued on next page

Control, Continued

Control,
continued

Press **Check Using GNSS**.



The screenshot displays the Hemisphere software interface with the following sections:

- Check Position:**
 - Control Point: [Select...]
 - Record At: Center
 - Check Using GNSS: 100%
- Measurement Information:**
 - Northing: 50,546.77ft
 - Easting: 60,795.32ft
 - Elevation: 503.75ft
 - SATS Used: 19
 - H Precision: 7mm
 - V Precision: 10mm
 - Elapsed: 3.0sec
 - Samples: 62
- Measured Offset (Pop-up window):**
 - Northing: -2.65ft
 - Easting: -2.58ft
 - Elevation: 1.40ft
 - Close
- Current Position:**
 - Northing: 50,546.71ft
 - Easting: 60,795.29ft
 - Elevation: 503.72ft
- Selected Point:**
 - Name: 4 (SimBasePos)
 - Northing: 50,549.42ft
 - Easting: 60,797.90ft
 - Elevation: 502.35ft

A pop-up window displays the **Measured Offset** of your reference point.

For **Current Position**, refer to the bottom left of the screen. Note the current position values continuously update due to standard GNSS error (machine vibration, etc.)

Refer to the **Measurement Information** column on the right side for the number of satellites used, the horizontal and vertical position, how many seconds averaged, and how many samples were collected.


- **Measurement Information**-the position of the point just measured.
- **Selected Point**- the points you selected to check.

Navigation

Navigation

The **Navigation** option provides real-time guidance (distance and direction).

On the GradeMetrix **Main Menu**, click the **Navigation** icon.



First, choose a point. Press **OK**.

Enter/Select Position						
Northing:	50,549.42ft					
Easting:	60,797.90ft					
Elevation:	502.35ft					
Name	HDist	Northing	Easting	Elevation	Code	Information
4 (SimBasePos)	51.44ft	50,549.42ft	60,797.90ft	502.35ft		
5	366.15ft	50,272.17ft	60,552.23ft	502.16ft		
2	469.15ft	50,947.08ft	61,000.83ft	503.51ft		
1	522.70ft	50,000.00ft	60,945.98ft	504.27ft		
BASE	548.35ft	50,002.40ft	61,038.58ft	511.51ft		
3	974.73ft	50,000.00ft	60,000.00ft	500.00ft		

Continued on next page

Navigation, Continued

Navigation, continued

A navigation screen displays showing the red line indicating direction the machine should travel.

The dotted line shows the direction of the machine. The heading is shown in degrees. The arrows illuminate on the right or on the left side, depending upon which direction the machine needs to move.


Distance shows how far the machine is from the point.

Continued on next page


Navigation, Continued

Navigation,
continued

Two illuminated arrows indicate how far the machine is off the line. As the position is corrected, the arrows indicate you are getting closer to the red line (correct position).



As the machine is driven closer, the screen begins to zoom in automatically.




Continued on next page

Navigation, Continued

Navigation,
continued

Note: To disable auto-zoom, go to **Settings -> Site Map -> Manage zooming while navigating and surveying**.




To exit **Navigation**, click the **Exit** button.

Field Design

Field design

To set job design settings. Click the **Field Design** icon in the GradeMetrix **Main Menu**.



Flat pad

Use **Flat Pad** to enter a set elevation to grade to (regardless of design file).

To set your flat pad elevation:

1. Type a name for the 'pad.'
2. Type "Measure From GNSS"
3. Edit the elevation if desired.


Note: Naming the pad allows you to the ability to save and edit the elevation at any time.

Continued on next page


Field Design, Continued

Flat pad,
continued

Click **Finish**. Design elevation is set to 509.928' in the following example.



Notice the surface is now green (indicating field design is used instead of DTM) and the **Job Name** at the top-left of the screen is now **Field Design**.




Continued on next page

Field Design, Continued

Hold slope

Select **Hold Slope** to extend the surface at the current slope angle.



Continued on next page

Field Design, Continued


Ramp

Choose **Ramp** to build the ramp by using coordinates or following a set guideline.

Note: If you do not have a guideline selected, you must create this ramp based on coordinates.

To set your ramp type a **Ramp Name** using the keyboard icon.

Press **Next**.




Continued on next page

Field Design, Continued


Ramp,
continued

Drive to the starting point and click **Record**.



Drive to the second point (calculates heading). Click **Record**.

Note: If you wish this ramp to exceed the length the vehicle has driven, edit the distance. You can also edit the calculated heading (bearing) and slope.





Continued on next page

Field Design, Continued

Ramp,
continued

To remove cross slope fields, click **Clear values on Add**. This will clear the field a new value can be added each time the **Add** button is pressed. Click on a lane and press **Remove**.




Continued on next page

Field Design, Continued

Ramp,
continued

Review the ramp and press **Finish**.



The screenshot shows the 'Ramp Summary' dialog box. On the left is a toolbar with icons for 'Flat Pad', 'Hold Slope', 'Sloped Pad', 'Ramp', and 'Clear Design'. The 'Ramp' icon is highlighted. The main area contains a top-left view of a ramp design on a black background with a yellow dashed centerline and a blue arrow pointing right. A scale bar at the bottom left of this view shows '7.83ft'. To the right is a 3D perspective view of the ramp. Below these views is a table with the following data:

Side of Center	Width	Slope
Left	10.00ft	2.00%
Right	10.00ft	2.00%

At the bottom right of the dialog are three buttons: 'Back', 'Finish', and 'Cancel'.

Continued on next page


Field Design, Continued

Ramp,
continued

The example below shows the newly created ramp (in blue). To make the ramp longer, edit the distance towards the beginning.

Important: This ramp becomes the job design. If the machine is not on the ramp, the machine is off the job design.

The job on the top-left is shown as **Field Design** – indicating that you are not grading to your DTM but instead grading to the **Field Design**.




Continued on next page

Field Design, Continued

Clear design

If you wish to remove a field design element, click to select one of the options in the **Clear Design** list.

For example, to remove the flat pad option, click to select **Remove Flat Pad**, and click **Finish**.



Your design elevation returns to the previously loaded Digital Terrain Model (DTM) file.

Grade 2D

Grade2D

GradeMetrix Excavator has a **2D** option. You can use an optional laser receiver on the excavator or bench each time you move the machine.




Once you are in **Grade2D**, your DTM/linework will disappear.

Continued on next page

Grade 2D, Continued

Grade2D,
continued




Continued on next page

Grade 2D, Continued

Grade2D,
continued

There are several icons on the left of the screen. The following table lists the icons and definitions used in **Grade2D**.

Table 5-2: Grade2D Icons and Definitions

Icon	Definition
	Create the main design work (flat pad, trench, profile, single slope pad, dual slope pad)
	Set reference elevation
	Set reference elevation with last bench elevation
	Reference to laser level
	Cache current elevation for when traversing
	Reference next node. When digging to a Profile or Trench, the field design will be built with nodes. Click this button to bench to the next node.
	Memorize node

Continued on next page

Grade 2D, Continued

Grade2D,
continued

Table 5-2: Grade2D Icons and Definitions (continued)


Icon	Definition
	Measure a slope with the bucket
	Exit Grade2D

When you enter **Grade2D**, the first step is to create a surface ().

Continued on next page

Grade 2D, Continued

Grade2D, continued



Use **Flat Pad** to create a surface at a set elevation:


1. Type a **Pad Name** (or select a **Recent Pad**).
2. Set the **cutting edge** on a benchmark.
3. Type in the **elevation** of that benchmark (in the example below, the **benchmark elevation** is 5.00 ft.).
4. Type **either** a **Target** or a **Depth**. The **Target** is the target elevation that you want to reach.

Example: If you benchmark is 5.00ft and set Target of 12.00ft, you would have a fill of 7.00 ft. (or a Depth of 7.00 ft.). If you set a Target of -5.00 ft., you would have a cut of 10.00 f.t (or a Depth of -10.00 ft.).

Continued on next page

Grade 2D, Continued

Grade2D, continued



The screenshot shows the 'Build Flat Pad' dialog box. On the left is a sidebar with icons for 'Flat Pad', 'Single Slope Pad', 'Dual Slope Pad', 'Trench', and 'Profile'. The main area contains the following fields and controls:


- Pad Name:** A text input field containing 'Example' and a 'Reset Pad' button with a red 'X' icon.
- Recent Pads:** A dropdown menu.
- Elevations:**
 - Bench:** A text input field containing '5.00ft'.
 - Target:** A text input field containing '-5.00ft'.
 - or Depth:** A text input field containing '-10.00ft'.
- Create Design:** A button with a small icon and a progress bar showing '0%'.
- Bottom Right:** 'Back', 'Finish' (with a blue checkmark), and 'Cancel' (with a red 'X') buttons.

Click **Create Design** and click **Finish**.

Continued on next page

Grade 2D, Continued

Grade2D,
continued



You can create a **Single Slope Pad**.

Continued on next page


Grade 2D, Continued

Grade2D,
continued

To set a **Single Slope Pad**:

5. Choose a **Pad Name** (or select from a **Recent Pad**).
6. Set the **cutting edge** on a benchmark and type a **bench elevation**.
7. Set **either a Target or a Depth**. The **Target** is the target elevation that you want to reach.

Example: If you benchmark is 5.00 ft. and set a Target of 12.00 ft., you would have a fill of 7.00 ft. (or a Depth of 7.00 ft.). If you put a Target of -5.00 ft., you would have a cut of 10.00 ft. (or a Depth of -10.00 ft.).



Build Sloped Pad

To create a sloped pad, press *Record* to measure the current position, then manually enter the elevation of the current position, main slope, and cross slope (for dual slope). When the desired elevation is established press *Finish* to accept the surface.

Pad Name:

Recent Pads:

Elevations

Bench:


Target: or Depth:

Continued on next page

Grade 2D, Continued

Grade2D,
continued

Click **Next**. Enter the long slope of the pad and the azimuth for this slope.




Click **Record**. The **Offset** is the difference between the current machine azimuth (coming from the GNSS receiver) and the azimuth you type in. If you do not have a dual antenna GNSS receiver connected, azimuth will be 0.

Click **Finish**.

Continued on next page

Grade 2D, Continued

Grade2D, continued



You can create a **Dual Slope Pad**.

To set a **Dual Slope Pad**:


- 1) Choose a **Pad Name** (or select from a **Recent Pad**).
- 2) Set the **cutting edge** on a benchmark and enter a **bench elevation**.
- 3) Set **either** a **Target** or a **Depth**. The **Target** is the desired target elevation.

Example: If you benchmark is 5.00 ft. and put a Target of 12.00 ft., you would have a fill of 7.00 ft. (or a Depth of 7.00 ft.). If you put a Target of -5.00 ft., you would have a cut of 10.00 ft. (or a Depth of -10.00 ft.).

Continued on next page

Grade 2D, Continued


Grade2D, continued



Click **Next**.

Type in a **Main Slope**, **Cross Slope**, and **Azimuth**. Click **Record**. The **Offset** is the difference between the current machine azimuth (coming from the GNSS receiver) and the azimuth you type in. If you do not have a dual antenna GNSS receiver connected azimuth will be 0.


Click **Finish**.



Continued on next page

Grade 2D, Continued

Grade2D, continued



To create a **Trench**:

- Type a **Trench** name (or select a **Recent Trench**).
 - Type a **Bench, Azimuth, and Main Slope**.
 - Click **Record**. The Offset is the difference between the current machine azimuth (coming from the GNSS receiver) and the azimuth you type in. If you do not have a dual antenna GNSS receiver connected azimuth will be 0.
 - After clicking **Next**, you will be prompted to enter a **Reference Node**. The Reference Node is a node that is drawn on the screen for display/reference purposes only and is not involved in the design of the trench. Design the trench by adding **X** and **Y** values under **Nodes** and click **Add**. You can start with an arbitrary **X, Z** for the first node.
- 4) When you are finished designing the trench, click **Finish**.

Continued on next page

Grade 2D, Continued

Grade2D, continued

- Flat Pad
- Single Slope Pad
- Dual Slope Pad
- Trench
- Profile

Trench Design

Design the trench by add, edit, or remove the nodes. Enter x and z for each of the node to determine its position. Selected node will be highlighted. At least 3 nodes and at most 15 nodes can be added to the trench. When the design is finished, press *Finish* to save and apply the trench.

Nodes:

X:

Z:

Reference Node:

X:

Z:

Remove Add Edit

Index	X	Z
1	0.00ft	0.00ft
2	2.00ft	0.00ft
3	2.00ft	-5.00ft
4	7.00ft	-5.00ft
5	7.00ft	0.00ft

Back Finish Cancel

Click **Next**.

If you traverse the machine, you will need to re-bench. Set the bucket (point of interest) a benchmark and click the **Set Reference Elevation** icon



().

Continued on next page

Grade 2D, Continued

Grade2D,
continued



The final design is **Profile**.

- Flat Pad
- Single Slope Pad
- Dual Slope Pad
- Trench
- Profile

Build Profile
Create or select a profile to design, then press *Record* to measure the current position if "Use relative heights" is checked. When the desired profile is selected and the current position is measured (if necessary), press *Next* to continue to the design page.

Profile Name:

Recent Profile:

Elevation and Azimuth

Bench

Azimuth

0%

Type a **Profile Name**. Type a **Bench** height and azimuth (if you do not have GNSS, azimuth will be 0).


Click **Record**. Enter a Cross Slope if necessary.

Click **Next**.

Continued on next page


Grade 2D, Continued

Grade2D, continued



Enter a **Reference Node**. The **Reference Node** is only for reference on the screen and is not part of the profile. Build the **Profile** by entering the nodes and click **Add**.


Click **Finish** when complete.




Continued on next page

Grade 2D, Continued

Grade2D, continued



You can set the cutting edge on a benchmark, **Machine Bench – to GPS Bench**. Type the **Bench Height** and click **Record**.



Continued on next page


Grade 2D, Continued

Grade2D,
continued

Use the **Laser Bench** if you have an optional laser receiver installed on your stick.




Set the **GPS Bench** and click **Finish**. In the example below, we benched the bucket at 5.00 ft.



Topo

Topo

Use **Topo** to create a topo point file by either manually storing points, or auto-storing points by time or distance intervals.



Continued on next page

Topo, Continued

General Settings The **General Settings** window displays the selections shown in the following table.


Table 5-3: General Topo Settings

Setting	Description
Survey Topo	Create a Survey Topo to store points. Click the icon to the right of the dialogue box and name the file.
Point of Interest	Select the point of the machine that the NEZ will be taken from when storing points.
Starting Point Id	Each time a point is stored, a corresponding point ID is created. Starting Point ID increments by 1 each time you shoot a point. The value entered indicates the ID of the first stored point.
Collect Samples For	When storing a manual point (not when auto-saving), the point will be averaged for this many seconds prior to saving.
Save Method	Click the down-arrow to select from the following options: <ul style="list-style-type: none"> – Time-the number input into ‘Save Every’ must be in seconds. – Distance-store the point by distance interval. Type a distance value in the Save Every field. – Manual-store points only when Single Shot is pressed.
Elevation Change	If doing an auto-topo, a point will be stored if elevation changes by this value – even if the saving interval has not been met.
Save first point on start when auto-saving	Click the checkbox to select. This option may only be selected if the Save Method is not manual.
Prompt for feature code	The software prompts to select from one of the available feature codes.

Continued on next page


Topo, Continued

General Settings, continued



Storing points

On the **General** tab, click the document icon to the right of the **Survey Topo** field to select or create a new file.




Continued on next page

Topo, Continued

Storing points,
continued

Click **Data Points**. The **Data Point Information** screen displays.

Click the box to select the options you wish to save to the topo file. When you are finished making your selections, click **Ok**.



Codes

You can select to prompt for **Feature Code**. When a point is stored you will receive a prompt for a code.


The **Manage Feature Codes** screen displays the listing of feature codes. Click to highlight the **Feature Code** you wish to add and click **Add**. Press **OK**.

Note: Do not select this feature if auto storing points.

Continued on next page

Topo, Continued

Codes, continued




Continued on next page

Topo, Continued

Codes,
continued

Note: If storing points manually, **Start Auto** is disabled.

To store a point, click **Single Shot**.



In the example above, locate the orange square on right side of cutting edge. This is the point just stored. Note it is on the right, as you set up in settings (**Point of Interest**), and the message reads “**Point 3 Saved**”, because you started with 3 (see following screenshot). If for example, you start with 50, the message would read “**Point 50 Saved**”.

Continued on next page


Topo, Continued

Codes,
continued

To exit, press the button on top right corner of the screen.

Note: When you return to the **Plan View** you will not see the saved points.

To view stored points, go to **Settings -> Site Plan Options -> Show Stake Points**.



Appendix A: Troubleshooting

Overview

Introduction Appendix A provides troubleshooting for common problems.

Contents

	Topic	See Page
	GradeMetrix Troubleshooting	146

GradeMetrix Troubleshooting

Troubleshooting **Table A-1: Troubleshooting**

Symptom	Possible Solution
Incorrect position	<p>First, check a control point with the machine and the survey rover.</p> <p>If the horizontal or vertical position is off, the first thing you should consider is if it is off by a consistent amount throughout the jobsite, or if the position bust varies throughout the job.</p> <p>If it is consistent, consider the following:</p> <ul style="list-style-type: none"> • Check your machine measurements/offsets. If any of these are incorrect, your projected position will be off. • Bad localization. Make sure that all of the points in your localization file have low residuals and/or that the correct coordinate system has been chosen. <p>If there is an inconsistent position bust, check:</p> <ul style="list-style-type: none"> • Sensor mounting was incorrectly chosen and/or sensor was not calibrated. <ul style="list-style-type: none"> – The above is evident if your position is correct when flat, but not if you are on a slope • If the position at the GPS antenna is correct, but the position bust worsens as you approach the cutting edge, it may be a heading offset error.

Continued on next page

GradeMetrix Troubleshooting, Continued

Troubleshooting **Table A-1: Troubleshooting (continued)**
, continued

Symptom	Possible Solution
No GNSS position	<ul style="list-style-type: none">• First, check to see if the VR500 or VR1000 is powered on.• If the receiver isn't powered, disconnect the cable and use a multimeter to verify it is receiving power and ground.• Check the Monitor screen and Sky Plots to see if there is any data from the receiver. If there is no data, but the receiver is powered, there could be a bad serial connection/mismatched baud rate.• If using a VR1000, use a multi-meter to measure the voltage from the primary antenna port. The voltage should be 5V. If it is reading 5V from the receiver, check the other end of the cable (that would plug into the antenna). If there isn't any voltage, it may be a damaged cable or bulkhead connector.

Continued on next page

GradeMetrix Troubleshooting, Continued

Troubleshooting **Table A-1: Troubleshooting (continued)**
, continued

Symptom	Possible Solution
No RTK	<ul style="list-style-type: none"> • If using a base station onsite (versus an NTRIP service), first check to verify the base station is turned on. • If the base station is turned on and sending RTK out over UHF, check to see if the Tx (or TD on some radios) light is flashing once per second. • Verify that the other rovers on the job site are receiving RTK corrections, if available. • If it is flashing once per second, check to verify the settings (frequency, bandwidth, forward error corrections, modulation, and protocol) at the base match that of the rover. • Check to see if the UHF light at the rover is blinking once per second. • The receiver may be out of UHF range. Consider installing the external UHF antenna (if using a VR500). You may need to install repeaters. See if the RTK corrections work when the machine is closer to the base station. • If using NTRIP, check cellular connectivity. One option is to exit GradeMetrix and verify you can go to a website via the browser.

Continued on next page

GradeMetrix Troubleshooting, Continued

Troubleshooting Table A-1: Troubleshooting (continued)
, continued

Symptom	Possible Solution
IronOne will not power on	<ul style="list-style-type: none"> • Check to verify the power cable is connected to machine power. The positive should go to a reliable, clean power source and ground to the chassis of the machine. • Disconnect the cable and refer to the pinout to see if 12V or 24V (depending on machine) is going into the IronOne by using a multi-meter. If the multimeter reads 12V or 24V, then power is confirmed, and the IronOne may need to be serviced. If you don't have any power, then check your power source, ground, and all fuses.
No heading	<ul style="list-style-type: none"> • If using a VR1000, you need two external antennas. Use a multi-meter to check the voltage coming out of the N-type connectors is 5V. If 5V is coming from the receiver, check the other end of the cable (that would plug into the antenna). If there is no voltage, then it is a damaged cable or bulkhead connector. • If using a VR1000, check your MSEP antenna separation measurement. It is the distance, in meters, between the two antennas, and must be accurate to within 2 cm.
No cut/fill	<ul style="list-style-type: none"> • Check to see if your GNSS receiver is RTK Fixed. If Settings -> Model -> Enabling Cut/Fill is set to "When RTK Fixed" (the default, and suggested, setting), cut/fill will be disabled if the GNSS receiver is not RTK Fixed • Check your RMS tolerances. If HRMS or VRMS is higher than configurable values in Settings -> Model, cut/fill will be disabled. • Check to make sure the receiver has valid GNSS heading.

Appendix B: Supported Hardware

Overview

Introduction Appendix B contains the pin-out and data specifications of GradeMetrix supported hardware.

Contents

	Topic	See Page
	VR500 Vector™ Smart Antenna	151
	VR1000 GNSS Receiver	157
	IronOne Hardware	164

VR500 Vector™ Smart Antenna

VR500 pin-out Figure B-1 shows the power/data cable pin-out assignments for the VR500 Smart Antenna.




Figure B-1: VR500 pin-out assignments

Continued on next page

VR500 Vector™ Smart Antenna, Continued

VR500 pin-out,
continued

Table B-1 shows the cable pin-out specifications.

Table B-1: VR500 pin-out specifications

Pin	Function	Color
1	Power +	Red
2	CAN1 High	Orange-Black stripe
3	CAN1 Low	Yellow Black stripe
4	Port B RS-232 RX/RS-422 A	Orange
5	Port B RS-232 TX/RS-422 Z	Yellow
6	CAN2 High	Green
7	CAN2 Low	Blue
8	Port B RS-422 B	Purple
9	Port B RS-422 Y	Grey
10	PPS Output	White
11	Port A RS-232 RX	Pink
12	Port A RS-232 TX	Turquoise
13	Signal Ground	Black-White stripe
14	Ethernet TD+	Brown-White stripe
15	Ethernet TD-	Red-White stripe
16	Heading Warning	Orange-White stripe
17	Speed Output	Green-White stripe
18	Ethernet RD+	Blue-White stripe
19	Ethernet RD-	Purple-White stripe
20	Manual Mark Input	Red-Black stripe
21	Power +	Brown
22	Power -	Black

Continued on next page

VR500 Vector™ Smart Antenna, Continued

VR500 data specifications

The following lists the data specifications for the VR500 Smart Antenna.

Table B-2: VR500 Sensor

Item	Specification		
Receiver type	GNSS Position & Heading RTK Receiver		
Channels	1059		
Sensitivity	-130 dBm		
SBAS tracking	3-channel, parallel tracking		
Update rate	10 Hz standard, and 20 Hz optional		
Horizontal accuracy		RMS (67%)	2DRMS (95%)
	RTK ^{1,2}	8 mm + 1 ppm	15 mm +2 ppm
	Atlas	0.04 m	0.08 m
	SBAS ¹	0.3 m	0.6 m
	Autonomous, no SA ¹	1.2 m	2.4 m
Heading accuracy	0.27° RMS		
Pitch/roll accuracy	1° RMS		
ROT	100°/s maximum		
Timing (PPS) accuracy	20 ns		
Cold start time	< 40 s typical (no almanac or RTC)		
Warm start time	< 20 s typical (almanac and RTC)		
Hot start time	< 5 s (almanac, RTC, and position)		
Maximum speed	1,850 km/h (999 kts)		
Maximum altitude	18,000 (59.055 ft)		
Differential options	SBAS, Autonomous, External RTCM v2.3, RTK v3, L-band (Atlas)		
Antenna LNA gain input	10 to 40 dB		

Continued on next page

VR500 Vector™ Smart Antenna, Continued

VR500 communication specifications

Table B-3: VR500 Communication

Item	Specification
Ports	2 full-duplex: 1x RS-232, 1x RS-232/RS-422, CAN
Baud rates	4800 - 230400
Data I/O protocol	Output: NMEA 0183, NMEA 2000, Hemisphere GNSS Proprietary ASCII and Binary Messages Input: Hemisphere GNSS Proprietary ASCII and CAN commands (for configuration)
Correction I/O protocol	Hemisphere GNSS ROX, CMR, CMR+, RTCM v2.3 (DGPS), RTCM v3x incl MSM
Timing output	PPS, CMOS, active low, programmable falling or rising edge sync, 10kΩ, 10 pF load
Ethernet	1x

VR500 power specifications

Table B-4: VR500 Power

Item	Specification
Input voltage	9-32 VDC
Power consumption	10.8W Maximum (All signals and L-band)
Current consumption	1.2A Maximum

Continued on next page

VR500 Vector™ Smart Antenna, Continued

VR500 environmental specifications

Table B-5: VR500 Environmental

Item	Specification
Operating temperature	-40°C to +70°C (-40°F to +158°F)
Storage temperature	-40°C to +85°C (-40°F to +185°F)
Humidity	95% non-condensing (when installed in an enclosure)
Shock and vibration	Shock: 50Gs, 11ms half sine pulse (MIL-STD-810G w/Change 1 Method 516.7 Procedure 1) Vibration: 7.7Grms (MIL-STD-810G w/Change 1 Method 514.7 Category 24)
EMC ⁴	CE (ISO 14982/EN 13309/ISO 13766/IEC 60945) Radio Equipment Directive 2014/53/EU, E-Mark, RCM
Enclosure	IP69

VR500 mechanical specifications

Table B-6: VR500 Mechanical

Item	Specification
Dimensions	68.6 L x 22 W x 12.3 H cm
Weight	3.9 kg
Status indication	Power, GNSS, Heading, Radio
Power/Data connector	22-Pin environmentally sealed

Continued on next page

VR500 Vector™ Smart Antenna, Continued

VR500 L-band sensor specifications

Table B-7: VR500 L-band sensor

Item	Specification
Receiver type	Single Channel
Channels	1530 to 1560 MHz
Sensitivity	-130 dBm
Channel spacing	5.0 kHz
Satellite selection	Manual and Automatic
Reacquisition time	15 seconds (typical)

VR500 aiding device specifications

Table B-8: VR aiding device

Device	Description
Gyro	Provides smooth heading, fast heading reacquisition, and reliable < 0.5° per minute heading for periods up to 3 minutes when loss of GNSS has occurred. ⁴
Tilt sensor	Provide pitch and roll data and assist in fast startup and reacquisition of heading solution.

¹ Depends on multipath environment, number of satellites in view, satellite geometry, no SA, and ionospheric activity

² Depends on multipath environment, number of satellites in view, WAAS coverage and satellite geometry

³ Depends on multipath environment, number of satellites in view, satellite geometry, baseline length (for differential services), and ionospheric activity

⁴ Based on a 40 second time constant

⁵ Hemisphere GNSS proprietary

VR1000 GNSS Receiver

VR1000 pin-out



Figure B-2: VR1000 pin-out assignments

1. Primary antenna
GNSS_RF1+5V
2. Secondary antenna
GNSS_RF2+5V
3. Radio antenna
Radio RF
4. BT/Wi-Fi antenna
BT/Wi-Fi RF

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000 pin-out, Table B-7 lists the VR1000 connector pin-out.
continued

Table B-7: VR1000 Connector Pin-out

Pin	Description	Note
1	CAN2_L	CAN2 Low
2	CAN1_H	CAN1 High
3	RD-	Ethernet RX-
4	TD-	Ethernet TX-
5	PA_RX	RS232 Port A Rx
6	PPS	1PPS OUT
7	RS422 TX+/SPEED OUT	Port B RS422 TX+/SPEED OUT
8/15	POW-	Power Ground
9	CAN2_H	CAN2 High
10	CAN1_L	CAN1 Low
11	RD+	Ethernet RX+
12	TD+	Ethernet TX+
13	PA_TX	RS232 Port A Tx
14	RS422 RX-/EVENT MARK	Port B RS422 RX-/EVENT MARK
16	CAN2_Shield	CAN2 Shield
17	CAN1_Shield	CAN1 Shield
18/19	GND	Signal Ground
20	RS232_TX PB RS422_TX-	Port B RS232 TX/RS422 TX-
21	RS232_RX PB RS422_RX+	Port B RS232 RX/RS422 RX+
22/23	POW+	Power Positive

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000 data specifications

Table B-8: VR1000 receiver

Item	Specification
Receiver Type	GNSS Position & Heading RTK Receiver
Signals Received	GPS, GLONASS, BeiDou, Galileo, QZSS, NavIC (IRNSS) and Atlas
Channels	1059
GPS Sensitivity	-142 dBm
SBAS Tracking	3-channel, parallel tracking
Update Rate	10 Hz standard, 20 Hz optional
Timing (PPS)	20 ns
Accuracy	
Rate of Turn	100°/s maximum
Cold Start	40 s (no almanac or RTC)
Warm Start	20 s typical (almanac and RTC)
Hot Start	5 s typical (almanac, RTC and position)
Heading Fix	10 s typical (Hot Start)
Antenna Input Impedance	50 Ω
Maximum Speed	1,850 mph (999 kts)
Maximum Altitude	18,288 m (60,000 ft)
Differential Options	SBAS, Atlas (L-band), RTK

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000
accuracy
specifications

Table B-9: VR1000 Accuracy

Item	Specifications		
Positioning		Horizontal (95%)	Vertical (95%)
	Autonomous, no SA ²	1.2 m	2.5 m
	SBAS (WAAS) ²	0.25 m	0.5 m
	Atlas (L- band) ^{2,3}	0.04 m	0.08 m
	RTK ¹	10 mm + 1 ppm	20 mm + 2 ppm
Heading (RMS)	< 0.2° @ 0.5 m antenna separation < 0.1° @ 1.0 m antenna separation < 0.05° @ 2.0 m antenna separation < 0.02° @ 5.0 m antenna separation < 0.01° @ 10.0 m antenna separation		
Pitch/Roll (RMS)	1°		
Heave (RMS)	30 cm (DGPS) ³ , 10 cm (RTK) ³		

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000 communication specifications

Table B-10: VR1000 Communication

Item	Specification
Ports	2 full-duplex, RS-232, CAN
Baud Rates	4800 - 230400
Correction I/O Protocol	Hemisphere GNSS ROX, CMR, CMR+, RTCM v2.3 (DGPS), RTCM v3x incl MSM
Data I/O Protocol	Output: NMEA 0183, NMEA 2000, Hemisphere GNSS Proprietary ASCII and Binary Messages Input: Hemisphere GNSS Proprietary ASCII and CAN commands (for configuration)
Timing Output	PPS, CMOS, active low, programmable falling or rising edge sync, 10k Ω , 10 pF load

VR1000 power specifications

Table B-11: VR1000 Power

Item	Specification
Input Voltage	9-36 VDC
Power Consumption	10.8W Maximum (All signals and L-band)
Current Consumption	1.2A Maximum
Maximum Power Isolation	No
Reverse Polarity Protection	Yes

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000 environmental specifications

Table B-12: VR1000 Environmental

Item	Specification
Operating Temperature	-40°C to +70°C (-40°F to +158°F)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Humidity	95% non-condensing
Mechanical Shock	50G, 11ms half sine pulse (MIL-STD-810G w/ Change 1 Method 516.7 Procedure 1)
Vibration	7.7 Grms (MIL-STD-810G w/Change 1 Method 514.7 Category 24)
EMC	CE ISO14982/EN13309/ISO13766/IEC60945), Radio Equipment Directive 2014/53/EU, E-Mark, RCM
Enclosure	IP69K

VR1000 mechanical specifications

Table B-13: VR1000 Mechanical

Item	Specification
Dimensions	No mounting Plate 23.2 L x 16.5 W x 7.9 H (cm) 9.1 L x 6.5 W x 3.1 H (in) With Mounting Plate 23.2 L x 21.4 W x 8.3 H (cm)
Status Indications (LED)	Power, Primary Antenna, Secondary Antenna, Heading, Quality, Atlas, Bluetooth, Wi-Fi, CAN1, CAN2, Ethernet, Radio
Power/Data Connector	23-pin multi-purpose

Continued on next page

VR1000 GNSS Receiver, Continued

VR1000 L-band sensor specifications

Table B-14: VR1000 L-band sensor

Item	Specification
Receiver Type	Single Channel
Channels	1530 to 1560 MHz
Sensitivity	-140 dBm
Channel Spacing	5 kHz
Satellite Selection	Manual or Automatic
Reacquisition Time	15 sec (typical)

VR1000 aiding device specifications

Table B-15: VR1000 Aiding devices

Item	Specification
Gyro	Provides smooth heading, fast heading reacquisition and reliable < 0.5° per min heading for periods up to 3 min. when loss of GNSS has occurred ⁴
Tilt Sensors	Provide pitch/roll data and assist in fast start-up and reacquisition of heading solution

¹Depends on multipath environment, number of satellites in view, satellite geometry, no SA, and ionospheric activity

² Depends on multipath environment, number of satellites in view, WAAS coverage and satellite geometry

³ Requires a subscription

⁴ Depends on multipath environment, number of satellites in view, satellite geometry, baseline length (for differential services), and ionospheric activity

IronOne Hardware

IronOne pin-outs

Figure B-3 shows the display pin-outs for the IronOne OEM Hardware.



Figure B-3: IronOne pin-out assignments

Table B-16: IronOne display pin-outs

Comm 12 pin	Description	
1	CAN H	COM1 in Win10 device manager
2	RS232 TX 1	COM2 in Win10 device manager
3	RS232 RX 1	
4	GPIO	
5	GND	Signal ground
6	RS422 TX 1	COM4 in Win10 device manager RS232/RS422/RS485 can Switch on BIOS setup: BIOS setup->Advanced->F81216SEC Super Io Configuration->Serial Port 4 Configuration
7	RS422 TX 2	
8	RS422 RX 1	
9	RS422 RX 2	
10	GND	Power ground
11	V12+ OUT	Power out for serial device
12	CAN L	COM1 in Win10 device manager

Continued on next page

IronOne Hardware, Continued

IronOne pin-outs, continued

Table B-17: IronOne video pin-outs

Video 12 pin	Description
1	V12+ OUT1
2	GND
3	CAN2 L_IN
4	CAN2 H_IN
5	NET 1TX+_IN
6	NET1 TX-_IN
7	NET 1RX-I_N
8	NET1 RX+_IN
9	GPIO2_IN
10	GND
11	VIDEO2_IN
12	VIDEO1_IN

Table B-18: IronOne communications

Comm DT15-12PA
CAN x 1
UART (RS-232 x 1)
RS-422/RS-485/RS-232 x 1 (Software switch)
GPIO x 1 (Default input pullup 5V)
12V/0.75A Power output

Table B-19: IronOne power connector

Power	Description
1	PWR+
2	PWR-
3	ACC
4	NC
5	PWR-
6	PWR+

Continued on next page

IronOne Hardware, Continued

IronOne pin-outs, continued

Table B-20: IronOne video communication

Video DT15-12PB
CAN x 1
CVBS video input x 2
10M/100M LAN x 1
GPIO x 1 (Default input pullup 5V)
12V/0.75A Power output

The following lists the data specifications for the IronOne OEM Hardware.

Table B-21: IronOne Mechanical

Specification	Description
Dimensions	22.9 L x 16.9 W x 5.2 H (cm) 9.0 L x 6.6 W x 2.0 H (in)
Weight	1.38 kg (3.04 lbs.)
Mount	Adjustable 1.5" RAM ball mount

Table B-22: Environmental

Specification	Description
Operating Temperature	-20°C to +70°C (-4°F to 158°F)
Storage Temperature	-40°C to +85°C (-40°F to 185°F)
Operating Humidity	30% ~ 95% (Relative Humidity)
Storage Humidity	45% ~ 80% (Relative Humidity)
Enclosure	IP67
Vibration	EP455 5.15

Continued on next page

IronOne Hardware, Continued

IronOne pin-
outs, continued

Table B-23: Power

Specification	Description
Input Voltage	7 - 36 VDC
Power Consumption	36 W
Current Consumption	3.0 A @ 12 VDC

Table B-24: Sensor and Multimedia

Specification
1x 2W Buzzer
1x Headphone Jack

Index

Administrator Settings	40	Navigation	117
Alert Method.....	73	NMEA	147
Atlas	147	Open Job	78
BeiDou.....	145, 146	Pitch	146
Control	11	Plan, Section, & Cut/Fill	18
Description	61, 80	Plan, Section, & Profile	20
Equipment Setup steps	88	ROX.....	147
Ethernet	147	RTCM.....	147
Files	11, 80	RTK	145, 147
Fill Color	73	SBAS	145, 146, 147
Fill Style	73	Serial ports	147
Formats	41	Settings.....	41
GLONASS	145, 146	Show in Views	73
GPS	145, 146, 147, 149	Shut down	57
Guideline	62	Site Calibration.....	80
Heading	146	Status	148
Home screen	40, 41, 56, 57, 60, 78, 79	Surface Options	82
Job Basics	60, 80	Surface options window	71
Line Color	73	Surfaces	73
Line Style	73	Survey Top.....	62
Linework.....	62, 65	Survey Topo	67, 68, 70
Name.....	80	WAAS	146

End User License Agreement

End User license agreement

IMPORTANT - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
 - a. install or use more copies of the Software than the number of copies that have been licensed;
 - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
 - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
 - d. modify or create derivative works based on the Software;
 - e. sub-license, rent, lease, loan or distribute the Software;
 - f. permit any third party to use the Software;
 - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
 - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
 - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at any time.

Continued on next page

End User License Agreement, Continued

End User license agreement, continued

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** Hemisphere GNSS[®], the Hemisphere GNSS logo, TRACER[™], Crescent[®], Eclipse[™], e-Dif[®], L-Dif[™], PocketMax[™], S320[™], SBX-4[™], Vector[™], Vega[™], Phantom[™] XF1[™], XF2[™], Cygnus[™], Atlas[™] aRTK, SureFix[™], Athena[™], Aquila[™], Lyra[™], Outback Guidance[™], and EDRIVE[™] are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners. and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential positioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.

Continued on next page

End User License Agreement, Continued

End User license agreement, continued

12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.
13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere. 19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a)

Continued on next page

End User License Agreement, Continued

End User license agreement, continued

19. negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product, (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
20. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
21. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
22. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
23. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
24. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
25. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
26. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
27. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

GENERAL. This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.

Warranty Notice

Warranty notice

COVERED PRODUCTS: This warranty covers all products manufactured by Hemisphere GNSS and purchased by the end purchaser (the "Products"), unless otherwise specifically and expressly agreed in writing by Hemisphere GNSS.

LIMITED WARRANTY: Hemisphere GNSS warrants solely to the end purchaser of the Products, subject to the exclusions and procedures set forth below, that the Products sold to such end purchaser and its internal components shall be free, under normal use and maintenance, from defects in materials, and workmanship and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for a period of 12 months from delivery of such Product to such end purchaser (the "Warranty Period"). Repairs and replacement components for the Products are warranted, subject to the exclusions and procedures set forth below, to be free, under normal use and maintenance, from defects in material and workmanship, and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater.

EXCLUSION OF ALL OTHER WARRANTIES. The LIMITED WARRANTY shall apply only if the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS relevant User's Manual and Specifications, AND the Product is not modified or misused. The Product is provided "AS IS" and the implied warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE and ALL OTHER WARRANTIES,

express, implied or arising by statute, by course of dealing or by trade usage, in connection with the design, sale, installation, service or use of any products or any component thereof, are EXCLUDED from this transaction and shall not apply to the Product. The LIMITED WARRANTY is IN LIEU OF any other warranty, express or implied, including but not limited to, any warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE, title, and non-infringement.

LIMITATION OF REMEDIES. The purchaser's EXCLUSIVE REMEDY against Hemisphere GNSS shall be, at Hemisphere GNSS's option, the repair or replacement of any defective Product or components thereof. The purchaser shall notify Hemisphere GNSS or a Hemisphere GNSS's approved service center immediately of any defect. Repairs shall be made through a Hemisphere GNSS approved service center only. Repair, modification or service of Hemisphere GNSS products by any party other than a Hemisphere GNSS approved service center shall render this warranty null and void. The remedy in this paragraph shall only be applied in the event that the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS's relevant User's Manual and Specifications, AND the Product is not modified or misused. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR CONTINGENT DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE

TO PURCHASER, even if Hemisphere GNSS has been advised of the possibility of such damages. Without limiting the foregoing, Hemisphere GNSS shall not be liable for any damages of any kind resulting from installation, use, quality, performance or accuracy of any Product.

HEMISPHERE IS NOT RESPONSIBLE FOR PURCHASER'S NEGLIGENCE OR UNAUTHORIZED USES OF THE PRODUCT. IN NO EVENT SHALL Hemisphere GNSS BE IN ANY WAY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM PURCHASER'S OWN NEGLIGENCE, OR FROM OPERATION OF THE PRODUCT IN ANY WAY OTHER THAN AS SPECIFIED IN Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS is NOT RESPONSIBLE for defects or performance problems resulting from (1) misuse, abuse, improper installation, neglect of Product; (2) the utilization of the Product with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Hemisphere GNSS; (3) the operation of the Product under any specification other than, or in addition to, the specifications set forth in Hemisphere GNSS's relevant User's Manual and Specifications; (4) damage caused by accident or natural events, such as lightning (or other electrical discharge) or fresh/ salt water immersion of Product; (5) damage occurring in transit; (6) normal wear and tear; or (7) the operation or failure of operation of any satellite-based positioning system or differential correction service; or the availability or performance of any satellite-based positioning signal or differential correction signal.

THE PURCHASER IS RESPONSIBLE FOR OPERATING THE VEHICLE SAFELY. The purchaser is solely responsible for the safe operation of the vehicle used in connection with the Product, and for maintaining proper system control settings. UNSAFE DRIVING OR SYSTEM CONTROL SETTINGS CAN RESULT IN PROPERTY DAMAGE, INJURY, OR DEATH.

Continued on next page

Warranty Notice, Continued

Warranty notice, continued

The purchaser is solely responsible for his/her safety and for the safety of others. The purchaser is solely responsible for maintaining control of the automated steering system at all times. THE PURCHASER IS SOLELY RESPONSIBLE FOR ENSURING THE PRODUCT IS PROPERLY AND CORRECTLY INSTALLED, CONFIGURED, INTERFACED, MAINTAINED, STORED, AND OPERATED IN ACCORDANCE WITH Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS does not warrant or guarantee the positioning and navigation precision or accuracy obtained when using Products. Products are not intended for primary navigation or for use in safety of life applications. The potential accuracy of Products as stated in Hemisphere GNSS literature and/or Product specifications serves to provide only an estimate of achievable accuracy based on performance specifications provided by the satellite service operator (i.e. US Department of Defense in the case of GPS and differential correction service provider. Hemisphere GNSS reserves the right to modify Products without any obligation to notify, supply or install any improvements or alterations to existing Products.

GOVERNING LAW. This agreement and any disputes relating to, concerning or based upon the Product shall be governed by and interpreted in accordance with the laws of the State of Arizona.

OBTAINING WARRANTY SERVICE. In order to obtain warranty service, the end purchaser must bring the Product to a Hemisphere GNSS approved service center along with the end purchaser's proof of purchase. Hemisphere GNSS does not warrant claims asserted after the end of the warranty period. For any questions regarding warranty service or to obtain information regarding the location of any of Hemisphere GNSS approved service center, contact Hemisphere GNSS at the following address:

Hemisphere GNSS

8515 E. Anderson Drive Scottsdale, AZ 85255, USA

Phone: +1-480-348-6380

Fax: +1-480-270-5070

TECHSUPPORT@HGNSS.COM

WWW.HGNSS.COM



Hemisphere GNSS Inc.
8515 East Anderson Drive
Scottsdale, Arizona, US 85255
Phone: 480-348-6380
Fax: 480-270-5070
PRECISION@HGNSS.COM
WWW.HGNSS.COM