



---

**875-0469-10**

User Guide

Revision: **A1**

November 22, 2021

**SiteMetrix Grade™**

**Machine Control &  
Guidance Management  
Software**

---

## Table of Contents

---

<b>Device Compliance, License and Patents .....</b>	<b>4</b>
Terms and Definitions.....	6
Chapter 1: Introduction .....	8
Overview .....	8
Product Overview .....	9
Key Features.....	10
Chapter 2: Getting Started with SiteMetrix Grade .....	11
Overview .....	11
Software Installation.....	12
User Interface .....	16
Operator Interface .....	19
SiteMetrix Grade Main Menu .....	45
Chapter 3: Working with SiteMetrix Grade Jobs .....	59
Overview .....	59
Create a Job.....	60
Open a Job .....	70
Modify a Job.....	71
Delete a Job.....	76
Job Tools .....	77
Field Design.....	79
Design a Job .....	84
Topo .....	91
Calculations.....	98
Manage Points .....	107
Check Position.....	109
Stake Out.....	112
File Tools .....	114
Appendix A: Troubleshooting .....	115
Overview .....	115
Troubleshooting.....	116

Appendix B: Technical Specifications.....	117
Overview .....	117
C631 Smart Antenna .....	118
HT20 Data Collector .....	123
Index.....	126
End User License Agreement .....	127
<b>Warranty Notice</b> .....	131

---

## Device Compliance, License and Patents

### Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and  
this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

E-Mark Statement: This product is not to be used for driverless/autonomous driving.

### Copyright Notice

Copyright Hemisphere GNSS, Inc. (2021). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

### Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™, Cygnus™, Atlas™, aRTK, SureFix™, and Athena™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

### Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

*Continued on next page*

## Device Compliance, License and Patents, Continued

---

**Notice to Customers**      Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[PRECISION@HGNS.COM](mailto:PRECISION@HGNS.COM)  
[HTTPS://WWW.HEMISPHEREGNSS.COM/](https://www.hemispheregnss.com/)

---

**Technical Support**      If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.  
8515 East Anderson Drive  
Scottsdale, AZ 85255 USA  
Phone: (480) 348-6380  
Fax: (480) 270-5070  
[SUPPORT@HGNS.COM](mailto:SUPPORT@HGNS.COM)  
[HTTPS://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2](https://hemisphere.atlassian.net/servicedesk/customer/portal/2/user/login?destination=portal%2F2)

---

**Documentation  
Feedback**

Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website:  
[HTTPS://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2](https://hemisphere.atlassian.net/servicedesk/customer/portal/2/user/login?destination=portal%2F2)

---

## Terms and Definitions

### Introduction

The following table lists the terms and definitions used in this document.

### SiteMetrix Grade terms & definitions

Term	Definition
Activation	Activation refers to a feature added through a one-time purchase. For features that require recurring fees, see Subscription.
BeiDou	BeiDou is a Chinese satellite-based navigation system.
DTM	Digital Terrain Model – the 3D grading of a job.
Ellipsoid	Ellipsoidal elevation refers to your height above the WGS84 ellipsoid.
Flat Pad	A set elevation that you grade to over the entire job site, regardless of design elevation.
Galileo	Galileo is a global navigation satellite system implemented by the European Union and European Space Agency.
Geoid	A model representing the shape of the earth, represented by mean sea level.
GLONASS	Global Orbiting Navigation Satellite System (GLONASS) is a Global Navigation Satellite System deployed and maintained by Russia.
GNSS	Global Navigation Satellite System
GPS	Global Position System
Heading	The vector created from the primary to secondary antenna. It points to the direction that the receiver is facing.
Latitude	A measure of how far north or south you are on the earth. Uses degrees, with the equator at 0 degrees and the poles at 90 degrees (north or south).

*Continued on next page*

## Terms and Definitions, Continued

---

**SiteMetrix**  
**Grade terms &**  
**definitions,**  
continued

Term	Definition
Longitude	A measure of how far east or west you are on the earth. Uses degrees, with the prime meridian at 0 (same as +180 degrees and -180 degrees). Positive degrees are east of prime meridian and negative degrees west.
NEZ	Refers to Northing, Easting, and Elevation.
Point of Interest (POI)	The point from which the cut/fill and NEZ information is derived.
Subscription	A subscription is a feature that is enabled for a limited time. Once the end-date of the subscription has been reached, the feature will turn off until the subscription is renewed.

---

# Chapter 1: Introduction

## Overview

---

**Introduction** This User Guide provides information on using SiteMetrix™ Grade.

---

## Contents

	<b>Topic</b>	<b>See Page</b>
	Product Overview	9
	Key Features	10

---

## Product Overview

---

### Product overview

SiteMetrix Grade is a grade checking software application developed by Hemisphere GNSS. SiteMetrix Grade features include:

- Grade checking with a GNSS rover
- Grade checking with a pickup truck
- Topos
- Creating surfaces
- Stakeouts
- Localization
- Machine calibration
- Calculating volumes
- Layer Management

SiteMetrix Grade is designed to run with the Hemisphere C631 Multi-GNSS Smart Antenna, which includes all constellations (GPS, GLONASS, BeiDou, Galileo, and QZSS), an internal dual band radio, Bluetooth, WiFi, tilt compensation, and hot-swappable batteries.

---

## Key Features

---

### SiteMetrix Grade key features

SiteMetrix Grade software features:

- An easy-to-use user interface
  - Stakeout design points on your site
  - Collects as-built features of your site
  - Collects topo shots to create surfaces for volume comparisons
  - Configurable to operate on a vehicle or as a manned rover
  - Configures, converts, and manages files for Hemisphere GradeMetrix™
  - Create pads, slopes, and ramps for use either stand-alone or for upload into GradeMetrix™ machine control systems
  - Network RTK compatible
  - Supports common generic file formats: DXF, DWG, and LandXML
-

## Chapter 2: Getting Started with SiteMetrix Grade

### Overview

---

**Introduction** The information in this chapter shows you how to install SiteMetrix Grade and provides an overview of SiteMetrix Grade functions.

---

### Contents

	<b>Topic</b>	<b>See Page</b>
	Software Installation	12
	User Interface	16
	Operator Interface	19
	SiteMetrix Grade Main Menu	45

---

## Software Installation

---

### **Operating system requirements**

SiteMetrix Grade can be installed to a ruggedized field computer or an office PC.

SiteMetrix Grade is designed to run on the Windows 10 Operating System.

---

### **Files and formats used in SiteMetrix Grade**

Various files are loaded into SiteMetrix Grade on the specific recommended directories on the Control Panel. Files are loaded into these directories using a couple of different methods: manually selecting files in SiteMetrix Grade from memory sticks (USB drives, thumb drives, etc.) or using Windows Explorer to copy files.

GradeMetrix can support the following files and file formats:


- Site Plan File: DWG, DXF, LandXML
  - Surface Model File: DWG, DXF 3d face triangles or polylines, TIN, FLT, GRD, LandXML, and LandXML Grid
  - Survey Topo File: TOPO
  - Tin File: MESH, TIN, NTR, DXF, DWG, FLT
  - Geoid File: BIN, GGF, GSF, GTX, TIF, ASC
  - Localization File: LOCAL (SiteMetrix Grade), LOC (SiteMetrix), COT (SiteMetrix Survey), .CAL
- 

*Continued on next page*

## Software Installation, Continued

### Install SiteMetrix Grade software


To install your SiteMetrix Grade software, complete the following steps:

Step	Action
1	<p>Click the <b>Install</b> file. Select “I accept the agreement” to accept the End User License Agreement.</p> 
2	Click <b>Next</b> .

*Continued on next page*

## Software Installation, Continued


Install  
SiteMetrix  
Grade software,  
continued

Step	Action
3	<p>Leave <b>Create a desktop shortcut</b> checked so that a desktop shortcut appears on your tablet. Click <b>Next</b>.</p>  <p>The screenshot shows a window titled "Setup - SiteMetrix version 1.1.4". Below the title bar, it says "Select Additional Tasks" and "Which additional tasks should be performed?". A sub-instruction reads: "Select the additional tasks you would like Setup to perform while installing SiteMetrix, then click Next." There are two sections: "Additional shortcuts:" with a checked checkbox for "Create a desktop shortcut"; and "Additional tasks:" with unchecked checkboxes for "Log debug messages to file" and a checked checkbox for "Install sample job". At the bottom right, there are three buttons: "Back", "Next" (highlighted in blue), and "Cancel".</p>

*Continued on next page*

## Software Installation, Continued


Install  
SiteMetrix  
Grade software,  
continued

Step	Action
4	<p>Click <b>Install</b>. The software will begin installing.</p> 

## User Interface

---

**User interface** The first time you open SiteMetrix Grade there are no jobs loaded and the receiver is not connected.



### Setting Up Administrative Modes

SiteMetrix Grade has three access levels: **User**, **Power User**, and **Administrative Mode**. Most features within the software can be configured to only allow power users or administrators. Throughout this manual, it is assumed that when a feature is discussed, it has been unlocked.

To configure access levels, click the  button on the top-left. Then

click the  icon.

Click the  icon to unlock the software. When the software is newly installed, there is not an administrative password.


---

*Continued on next page*

## User Interface, Continued

### Setting Up Administrative Modes, continued

Click the **Authorization** tab.



Feature	Authorization
Base Setup	Power User
Calculations	User
Field Design	User
New Job	Power User
Open Job	User
Modify Job	Power User
Delete Job	Power User
Job Tools	Power User
Localization	Administrator
Mapping	Administrator
Equipment Setup	Administrator
3D Calibration	Administrator
RTKSource Configuration	Power User

Each setting allows for you to choose from **User**, **Power User**, and **Administrator**.

**User:** Access without typing in any password.

**Power User:** Access by typing in the Power User Passcode.

**Administrator:** Access by typing in the **Power User** or **Administrator Passcode**.


*Continued on next page*

## User Interface, Continued


---

### Setting Up Administrative Modes, continued

Select which features should be locked down and then enter a passcode for both **Administrator** and **Power User**. Click **OK**.

After setting up the power user/administrator, click the  icon.

Click to select the **Administrator** checkbox.



You will be prompted for a passcode. If you enter the **Power User** passcode you will be able to access the power user features. If you enter the **Administrator** passcode you can access either the power user or administrator settings.

---

## Operator Interface

### Setting Up Rover

SiteMetrix Grade supports the use of a survey pole and truck. To configure

the two, click the  icon. Select the User  and select

administrator. Select the right arrow  and click the **Equipment Setup** icon.

Click the icon pictured below.



Enter a **Machine ID**. Select a **Measurement Unit**.

The screenshot shows a 'General Settings' dialog box with a sidebar on the left containing a 'Supervisor' icon and label. The main area contains the following fields:

- Machine Type: Supervisor (dropdown menu)
- Machine Id: Example (text input field)
- Measurement Unit: Feet (dropdown menu)
- Recent Machines: (empty dropdown menu)


At the bottom right of the dialog, there are three buttons: 'Import From...' (with a left-pointing arrow), 'Back' (with a left-pointing arrow), 'Next' (with a right-pointing arrow), and 'Cancel' (with a red X).

*Continued on next page*

## Operator Interface, Continued

Setting Up  
Rover,  
continued

Click **Next**.



Select the antenna type (C631). You will see several measurements:


- 1) **Right:** The receiver is on a truck. Enter the distance to the right of centerline (negative for left of centerline).
- 2) **Behind:** The receiver is on a truck. Enter the distance behind the front bumper of the truck.
- 3) **Height:** The receiver is on a truck. Enter the distance to the ground.
- 4) **Rod:** The C631 is on a survey pole (not truck). Enter the pole height.

*Continued on next page*

## Operator Interface, Continued

### Setting Up Rover, continued


Click the **Chassis** tab.



The **Machine Geometry** dialog box is shown. It has two tabs: **Antenna** (selected) and **Chassis**. The **Antenna** tab is active, showing three input fields for dimensions: 1. Length: 18.500ft, 2. Width: 6.500ft, and 3. Height: 6.300ft. To the right of these fields are three small icons. The main area contains a 3D diagram of a truck with dimension lines indicating length, width, and height. At the bottom right, there are **Back**, **Next**, and **Cancel** buttons.

Type in the chassis dimensions of the truck. This is only for graphics and does not affect the math.

Click **Next**. If you have a software activation for **Sensors**, you can set up your sensors here.



The **Sensor Placement** dialog box is shown. It has a **Network** dropdown menu set to **No Network**. Below it is a table with columns **CANid** and **DEvid**. To the right of the table are fields for **Placement:**, **Device Name:**, **Mount Position:**, and **Mount Facing:**, each with a dropdown arrow. Below these are two checkboxes: **Use internal termination** and **Use in solution**. At the bottom of the dialog are **Configure** and **Remove** buttons. At the bottom right, there are **Back**, **Next**, and **Cancel** buttons.

*Continued on next page*

## Operator Interface, Continued

### Connecting to the Receiver

Click the Bluetooth icon on the top-right.



A dialogue will appear. Click **Search** to search for Bluetooth devices.

### Receiver Connection

Name:  ▼ 

Receiver:  ▼

Mode:  ▼

Type:  ▼

Device:  ▼  Search

 Add  Remove

 Connect  Close

Click **Search**. Search for the receiver. The **Bluetooth ID** is the serial number. There is no Bluetooth pin. Set **Mode** to either Rover, **Base**, or **Static**. You can optionally enter a receiver name under **Name**.

Click **Connect**.

*Continued on next page*


## Operator Interface, Continued

### Setting up RTK Rover

After connecting to the rover, you will want to configure RTK. Go to the menu, scroll to the right, and click **RTKSource Configuration**.



SiteMetrix Grade can receive RTK over NTRIP as well as use the internal UHF radio or an external UHF radio.



**RTK Configuration**

**NTRIP** Casters: [Dropdown] [Icon]

Internal Radio Host Address: [Text] [Icon] Port: [Text] [Icon]

External Radio UserName: [Text] [Icon]

Password: [Text] [Icon]

Mount Point: [Dropdown] [Icon] Download Source Table [Icon]

Send Position to Caster Every 1 Second [Dropdown]  Auto Reconnect

Transfer Rate: 0 B/s

[Add] [Remove] [Settings] [Connect To Caster] [OK] [Cancel]

*Continued on next page*

## Operator Interface, Continued

---

**Setting up RTK Rover,**  
continued

If using NTRIP, you can use the data collector's internet (if the data collector has an internal cellular modem or WiFi) or the C631's internal GSM modem.

To setup click **Settings**.

### NTRIP Settings

NTRIP Client:	<input type="text" value="GradeMetrix"/>	
APN Name:	<input type="text"/>	
APN Username:	<input type="text"/>	
APN Password:	<input type="text"/>	

If NTRIP Client is set to **GradeMetrix**, the data collector's internet will be used to access the NTRIP caster and then the RTK messages will transfer back to the C631 via Bluetooth. If the NTRIP Client is set to **Receiver**, the C631's internal modem will be used. You can type in an **APN Name**, **Username**, and **Password**.

---

*Continued on next page*


## Operator Interface, Continued

### Setting up RTK Rover, continued

Type in a **Caster** name. You can add multiple NTRIP casters to SiteMetrix Grade (all will be saved in a database). Type in the **IP address/DNS, Port, Username, and Password**.

Click **Download Source Table**. Select the correct mount point. If using a VRS network (or a nearest base station), click **Send Position To Caster Every** and select an interval for your position to be sent to the caster. Click **Auto Reconnect** to ensure the software reconnects to the NTRIP caster every time it opens up or if you lose internet and re-gain internet. Click **OK**.

After clicking **OK**, the NTRIP client will be the only source of RTK (even if the internal UHF radio is configured). If you also configure the internal UHF radio and want to switch to it, go back into **RTKSource Configure**, and click **Internal Radio**, and click **OK**.



Alternatively, you can use the Internal Radio. Click the **Internal Radio** tab. If you have the correct administrative settings, you can enter channels with **Channel Configuration**.

**Warning: You are responsible for verifying which frequencies and bandwidths can be set up for your region.**

*Continued on next page*


## Operator Interface, Continued

---

### Setting up RTK Rover, continued

Select the channel, protocol, FEC (if applicable), and scrambling (if applicable).

Click **OK**. After clicking **OK**, the internal UHF radio will be your primary source of RTK. If you have configured the NTRIP client, the receiver will use the radio. If you configure the NTRIP client and want to switch, go into **RTKSource Configure**, click **NTRIP**, and click **OK**.



**RTK Configuration**

Basic Configuration  Channel Configuration  Call Sign Configuration

**NTRIP**

**Internal Radio**

SN: 2009000457  
Version: V07.44.2.5.1.11\_rc2

Channel: CH 01  
CH 1, TX 451.800000 MHz, RX 451.800000 MHz, BW 12.5 kHz, 1000 mW

Protocol: SATELLINE-3AS

FEC: On

Scrambler: On

*Continued on next page*


## Operator Interface, Continued

---

### Setting up RTK Rover, continued

Finally, you can select an **External Radio**. Click the **External Radio** tab. SiteMetrix Grade does not support the configuration of an external radio, but you can set the baud rate of the serial port of the C631.

On the bottom of the C631 there are two Lemo connectors. One has 5-pins and the other has 7-pins. The 5-pin connector is for an external radio.



*Continued on next page*

## Operator Interface, Continued

### Base Station Setup

SiteMetrix Grade can be used to configure your C631 as a base station. Go

into the menu (  ), scroll to the right (  ), and click **Base Setup**.



Set **Sys Mode** to **BASE**. For data type, it is suggested for most applications you use ROX or RTCM 3.2. These RTK message formats provide RTK messages for all signals/constellations. Using RTCM 3.0 limits you to GPS + GLONASS only and you will be unable to take advantage of Galileo and BeiDou.

Base Station Setup											
Coordinate:	Northing/Easting	Sys Mode:	BASE								
Northing:	50426.663ft	Data Type:	RTCM3.2								
Easting:	60940.110ft	Data Link:	UHF								
Elevation:	502.350ft	Measure Point:	Vertical height to receiver bottom								
Ground Height:	495.562ft	Antenna Height:	6.558ft								
Avg Position:	1.0sec	Unit:	Feet								
		<input type="button" value="Load Last Used Point"/> <input type="button" value="From Control Points"/> <input type="button" value="From File"/>									
<table border="1"> <thead> <tr> <th>Name</th> <th>Northing</th> <th>Easting</th> <th>Elevation</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>				Name	Northing	Easting	Elevation				
Name	Northing	Easting	Elevation								
		<input type="button" value="Save"/> <input type="button" value="Start"/> <input type="button" value="Close"/>									

If you have a localization file loaded, you have the option to enter in a **Northing, Easting, Elevation** (rather than **Latitude, Longitude, and Height**).

Click **From Control Points** to select a localization point or select **From File** to load from your topo file.

*Continued on next page*

## Operator Interface, Continued


### Using Rover

Data Link allows you to configure how the RTK messages will be transmitted.

The options are:

1. **Ext (External)** – Use to output RTK from the 5-pin Lemo connector located on the bottom of the C631. Click on the gears button next to **Data Link** to set the baud rate.
2. **UHF** – Use to output RTK from the internal UHF radio. Click on the gears button next to **Data Link** to configure the radio.
3. **Network** – Use to output RTK to a TCP/IP server or NTRIP caster. Click on the gears button next to **Data Link** to configure the network settings.

On the main screen, you can see the following:



The toolbar may show an alert symbol as shown below if there is an issue (in this case, the issue is that the GNSS receiver is RTK Float instead of RTK Fixed). Click the exclamation point to see the error.





*Continued on next page*

## Operator Interface, Continued

---

### Using Rover, continued



The  symbol shows the rover rod height (from the point on the ground to the base of the receiver). Click on this value to change it.

6.560			
1	2	3	←
4	5	6	↩
7	8	9	
±	0	.	×


*Continued on next page*

## Operator Interface, Continued

### Using Rover, continued



Clicking on the  icon changes from using a survey rover to using a truck (using the antenna height of the truck entered in Equipment Setup). In the example below, a survey rover is used:



*Continued on next page*

## Operator Interface, Continued

Using Rover,  
continued

Click the person icon once more to show the truck.


**Warning: Ensure you have the correct option shown, as the antenna height for a person and for a truck may be different.**



Click the  icon to return to the survey rover.

SiteMetrix Grade supports the use of tilted pole measurements. Click the



 symbol in the toolbar to enter **Tilt Compensation Mode** (this does not work when using a truck). The image tilts, indicating tilt compensation

mode is turned on.




*Continued on next page*


## Operator Interface, Continued

### Using Rover, continued

Tilted Pole Measurements use an internal Inertial Measurement Unit (IMU) that requires motion of an RTK Fixed receiver to initialize. The C631 must be RTK Fixed to use this feature. If the IMU needs to be initialized, a message prompts you to initialize the receiver.



To initialize the receiver, click **Initialize**.



*Continued on next page*


## Operator Interface, Continued

---

### Using Rover, continued

A prompt displays to swing the receiver back and forth. Once initialized, the status bar will go to 100%. Click **Cancel** to skip calibration, or click **Next** to calibrate your IMU.

To calibrate, firmly place the point of the receiver on a point on the ground. Do not rotate or move the receiver. Click **Calibrate**. Swing the receiver back and forth as shown in the image.



Click **Next**. A prompt displays to swing the receiver back and forth in the other axis.

---

*Continued on next page*

## Operator Interface, Continued

### Quick Info

On the top menu bar, click the **Information** icon to display the information menu.



*(Press anywhere in the pop-down screen to hide the menu.)*

Term	Definition
<b>Northing</b>	Northward-measured distance from the origin, or the "Y"-axis.
<b>Easting</b>	Eastward-measured distance from the origin, or the "X"-axis.
<b>Actual Z</b>	Local height above the origin of the local coordinate system. Actual Z is the elevation, or the "Z" axis.
<b>Design Z</b>	Design elevation (Actual Elevation – Design Elevation = Cut Value (if negative-Fill Value).
<b>Station</b>	If using a guideline, indicates the current station on the guideline.
<b>Cut/Fill</b>	The difference between design and actual elevation.
<b>Grading Offset</b>	A small offset (positive or negative) that affects cut/fill in the design elevation.
<b>Cross slope</b>	The angle made between the left and right side of the tracks and a horizontal plane (also known as roll).
<b>Long slope</b>	An angle made between the front and back of the machine and a horizontal plane (also known as pitch).
<b>UTC Date</b>	The date based on UTC (Coordinated Universal Time) time zone.
<b>UTC Time</b>	Coordinated Universal Time zone.
<b>Solution</b>	The solution should read, "Real-time Kinematic."
<b>Visible SATs</b>	The quantity of SATs visible in the sky.
<b>Ground Speed</b>	The speed of the machine travel based on position data.
<b>Azimuth</b>	The angular measurement between the vector created from the back of the machine to the front of the machine and "true north."

*Continued on next page*

## Operator Interface, Continued


Quick Info,  
continued

**Note:** Select/de-select which information fields you want to display by clicking the **Settings** icon, and **Info Summary**.



Click the  icon in the upper right corner to view the **Information** screen.

*This icon is disabled when the Quick Info menu is displayed. Turn off the Quick Info menu to enable the icon.*



*Continued on next page*

## Operator Interface, Continued

### Antenna Info

The **Antenna Info** tab provides the following information:


- **Raw Position Information** –raw position and GNSS quality information from the GNSS receiver
- **Raw Status Information** –additional GNSS status information (i.e., dilution of precision, RMS values, RTK latency, and UTC time) from receiver
- **Local Antenna Position** –the NEZ in local project coordinates
- **Directional Information** – the GNSS heading and an indicator (if GNSS), or derived heading. It also gives the declination and speed.

**Note:** The **Antenna Info** tab automatically displays the **Information** type specific to the connected antenna.

The **Raw Position Information** displays the current plan values for:

- Latitude
- Longitude
- Height (orthometric height)
- Separation (geoid separation)
- Ellipsoid (ellipsoid elevation)
- Speed
- Solution
- SATS Used
- Visible SATS

**Note:** To change latitude/longitude to a military grid or UTM (Universal Transverse Mercator) Go to **Settings -> Format**.



*Continued on next page*


## Operator Interface, Continued

### SAT View

The **SAT View** tab displays available satellites. The strength of each satellite signal is color-coded.

**Table 2-1: Satellite Signals**

Signal	Color	Description
Tracking	Green	Strong signal -used in the solution
Marginal	Yellow	Weaker signal- only a partial use in the solution
Low Signal	Red	Not tracked in the solution
Out	Grey	No signal




*Continued on next page*

## Operator Interface, Continued

### SAT Info

The **SAT Info** tab displays data-driven detail about each satellite used in the solution.



PRN	ELEV	AZI	L1:Trk	L2:Trk	L5:Trk
G002	46°	264°	46	44	
G005	33°	306°	38	36	
G006	39°	205°	39	36	41
G007	68°	97°	51	48	
G009	48°	59°	44	41	43
G013	8°	254°	28	25	
G016	6°	33°	30	28	
G023	11°	71°	28	27	
G029	2°	323°	27	26	
G030	53°	178°	49	47	48
R005	37°	170°	39	37	
R006	71°	278°	51	50	
R007	25°	327°	33	31	
R009	33°	248°	34	33	
R015	29°	41°	34	32	
R016	71°	313°	56	54	
R017	9°	74°	25	24	
R024	8°	25°	25	24	


*Continued on next page*

## Operator Interface, Continued

### Sensor Info

The **Sensor Info** tab displays all the configured sensors. You can check the sensor operation and the pitch and roll.

Click **Show Calibrated Values** to view the calibrated (rather than the raw) tilt sensor value.



CANId	Sensor	State	Pitch	Roll
✓ 1000	Chassis	Operational	1.00°	0.57°

**Sensor Properties**

- Device Type: Tilt
- Axis Count: 2
- Pitch Source: Calculated
- Roll Source: Calculated

Show Calibrated Values  
 Show Tilt as Percent


*Continued on next page*

## Operator Interface, Continued

### VEH Info

The **VEH Info** tab displays the following information:

- **Vehicle**-Northing, Easting, Elevation, and Station
- **Status**-Azimuth, HBias, Speed, Direction, Status
- **Design**-Elevation, Cut/Fill, Grading Offset, Cross-Slope, Long-Slope



Vehicle Information	Status Information
Northing: 50428.99ft	Azimuth: 241.3°
Easting: 60941.82ft	LBias: 118.706°
Elevation: 507.74ft	Speed: 0.0mph
Station: Off Guide	Direction: Backing up
	Status: Stopped


Design Information
Elevation: 503.72ft
Cut/Fill: 4.02ft (cut)
Grading Offset: 0.00ft
Cross-Slope: 0.99%
Long-Slope: 1.74%

*Continued on next page*

## Operator Interface, Continued

### Modules

The **Modules** tab displays a listing of modules used and the status.



Module	Status	Software Version	Firmware Version
SiteMetrix Interface	Operational	1.1.0	
Alert Manager	Asleep	1.1.0	
Log Manager	Asleep	1.1.0	
Model Manager	Operational	1.1.0	
Grading Model	Operational	1.1.0	
Position Model	Operational	1.1.0	
Design Model	Operational	1.1.0	
As-Built Manager	Asleep	1.1.0	
Zone Manager	Operational	1.1.0	
GNSS Position ...	Operational	1.5.0	C631, S/N: 21003381, F/W: 6.0Aa02a, ,

### Return to main screen



Click the  icon to de-select and return to the GradeMetrix main screen.


*Continued on next page*

## Operator Interface, Continued

### SiteMetrix Grade file requirements

SiteMetrix Grade requires a **Plan View** file, **Design Surface**, and **Localization** file. These files are combined into a **Job File**. Other file types, such as a **Topo File** and **Guideline** file may be loaded.

To create a new job with these files, log into **Admin Mode**, and click **New Job**. Or click **Open Job** to load an existing job or **Modify Job** to modify an existing job.



*Continued on next page*

## Operator Interface, Continued

SiteMetrix  
Grade file  
requirements,  
continued

When you load an existing job, it automatically loads all files associated with the job. A description of some of these file types are below.

**Table 2-2: Job File Types**

<b>File Type</b>	<b>Description</b>
<b>Job File</b>	A collection of files (plan view, design surface, etc.) along with settings. Loading a job loads all files and settings.
<b>Plan View</b>	The map of a job site that shows distinguishable features (such as buildings, streams, etc.) as well as a general topo map of the site.
<b>Design Surface</b>	The digital terrain model that drives the cut/fill values. An elevation is associated with each northing and easting and this design elevation is compared to the actual elevation of the machine at the current northing/easting.
<b>Guideline File</b>	Provides steering offsets towards a polyline.
<b>Topo File</b>	A file that stores all of the points stored in the Topo routine.

## SiteMetrix Grade Main Menu

### Main Menu

The SiteMetrix Grade Main Menu displays the following:

**Table 2-3:- SiteMetrix Grade Main Menu Icons**



Icon Name	Icon	Description
<b>New Job</b> <i>(must be accessed by authorized Admin user)</i>		Create a new job.
<b>Open Job</b>		Open an existing or saved job.
<b>Modify Job</b>		Edit an existing or saved job.
<b>Delete Job</b>		Delete a created job.
<b>Job Tools</b>		Export a job file to external storage or rename a job.
<b>Equipment Setup</b>		Use in administrator mode. Configure the dimensions of your machine, the GNSS hardware you are using, and save/load these settings.

*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

Main Menu,  
continued

**Table 2-3: SiteMetrix Grade Main Menu Icons (continued)**

Icon Name	Icon	Description
<b>Calibrate Sensors</b>		Calibrate the sensor to determine a cross slope and long slope offset, based upon the sensor installation. Use this for body sensors.
<b>Quick Calibrate</b>		Use Quick Calibrate to check the cross slope/long slope is on a sensor.
<b>RTK Source Configuration</b>		This is where you can configure your RTK source (NTRIP, internal UHF radio, or external radio).
<b>Navigation</b>		Enter an NEZ or select from a list of control points. Grade Metrix provides distances/directions to that point.
<b>Field Design</b>		Use Field Design to create a surface when a model is not available.
<b>Manage Points</b>		Use Manage Points to add, remove, or edit Topo Points and Lines.
<b>Topo</b>		Use for conducting a topo. Software can be configured to store points automatically or manually in interval (distance or time).

*Continued on next page*

## SiteMetrix Grade Main Menu, Continued


### Settings

On the lower-left portion of the **SiteMetrix Grade Main Menu**, click the gear icon to access the program **Settings**.



**Note:** You must be logged on as **Administrator** to make changes to some SiteMetrix Grade **Settings**.

The **Settings** window displays. The left navigation menu lists the SiteMetrix Grade Settings options:



*Continued on next page*


## SiteMetrix Grade Main Menu, Continued

---

**General settings** The following General settings can be configured:

- 1) **Collect Samples For:** The amount of time (in seconds) that a GNSS position (or heading) shot is averaged for when benching (in **Field Design**) or doing a machine calibration.
- 2) **Model Loading Method:** If set to **Save Memory**, when loading a tin file duplicate vertices will be searched for, which increases loading time. **Load Faster** is the suggested default setting.
- 3) **Enable audible alarm for system alerts:** If checked, audio alerts will be used to indicate a lost GNSS position (and other various errors).
- 4) **Enable system notification sounds:** If checked, a cut/fill audio indicator will be enabled

To save your settings, click **Ok**. To cancel your changes, click **Cancel**.



*Continued on next page*

## SiteMetrix Grade Main Menu, Continued


### System logs

In the **System Logs** screen, click in the field to set the system logging options.

**Table 2-4: System Logs**

Option	Function
<b>User Log Cache Size:</b>	Determines number of logs held in memory before flushing them to a disk.
<b>Save User Log Every:</b>	Performs an autosave to disk.
<b>Enable logging user interaction</b>	Logs all user interactions.
<b>Alert Cache Size:</b>	Determines number of logs held in memory before flushing them to a disk.
<b>Save Alerts Every:</b>	Performs an autosave to disk.
<b>Enable logging system alerts</b>	Saves error message (GPS errors, sensor errors, etc.).

When you are finished setting the system logging options, click **Ok**. To cancel your changes, click **Cancel**.



*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

**Model Options** On the **Model Options** screen you can check and edit the location settings for your GradeMetrix job in the **Model** screen.

Click to select/edit the following fields:

**Table 2-5: Model Options**


Option	Description
<b>Speed and Heading Rate:</b>	The rate at which speed and heading information update.
<b>Motion Detection Tolerance:</b>	SiteMetrix Grade uses your GNSS position to determine motion.
<b>History Distance Tolerance:</b>	Records the cumulative history movement and sets a history marker.
<b>Maximum History Size:</b>	The amount of history markers stored for your previous points.
<b>Enabling Cut/Fill</b>	<p>If set to <b>When RTK Fixed</b>, Cut/Fill will only be shown when the C631 has an RTK Fix.</p> <p>If set to <b>Allow aRTK™ Fixed</b>, Cut/Fill will be shown when the C631 is RTK Fixed or aRTK Fixed.</p> <p>If set to <b>Allow Atlas®</b>, Cut/Fill will be shown when the C631 is Atlas Converged, aRTK Fixed/Converged, or RTK Fixed.</p> <p>If set to <b>Always Show</b>, Cut/Fill will be shown regardless of RTK status.</p>
<b>HRMS Tolerance:</b>	Sets the Horizontal RMS thresholds for when an alert will occur.
<b>VRMS Tolerance:</b>	Sets the Vertical RMS thresholds for when an alert will occur.

*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

---

### Model Options, continued



**Model Options**

Speed and Heading Rate: 500ms

Motion Detection Tolerance: 0.29ft

History Distance Tolerance: 20.00ft

Maximum History Size: 100

Enabling Cut/Fill: When RTK Fixed

HRMS Tolerance: 0.21ft

VRMS Tolerance: 0.21ft

Enable avoidance zones and surfaces

OK Cancel

Click the checkbox to select **Enable avoidance zones and surfaces**.  
If the module is built with avoidance zones, an alarm will sound when entering those zones.


To save your settings, click **Ok**. To cancel your changes, click **Cancel**.

*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

### As-Built

The **As-Built** option tracks job progress and can be configured for pass counts or cut/fill.



*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

---

### Site map

Use the **Site Map** screen to set display and zooming views for your SiteMetrix Grade job.

Click the down-arrow to select any of the following options from the pop-up window.

**Show Display As:** There are three display options to view your machine as the map rotates:

1. **Moving Map**-The map rotates to always head in the direction of the top of the screen.
2. **Fixed Rotation**-The top of the map is set to a fixed azimuth (if using Fixed Rotation, enter rotation angle).
3. **North Up**-The top of the map is always pointing north.

Click the keyboard icon to the right of the following fields to separate auto center and manage zooming:

- **Rotation Angle:** If using fixed rotation, enter the degrees to rotate the map clockwise.
- **Zooming Factor:** Set the numeric value to zoom on the right side of the plan view. (The greater the value set (50 or above), increases the zoom out.)
- **Auto center the machine when the moving map is not selected:** The view adjusts as your machine moves to prevent your machine from driving off the screen.


---

*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

Site map,  
continued

**Manage zooming while navigation and surveying:** When staking out a point, the view will zoom in closer to the point.



To save your settings, click **Ok**. To cancel your changes, click **Cancel**.

**Surfaces**

The **Surfaces** option enable/disable on the background surfaces shown on the plan view.

Select from these options:

- Show Using:
- On-Count Color:
- Passes Color:

**Show Cut/Fill**-Select the box to display cut/fill surfaces on the plan view and color the grid based upon the cut/fill value.

**Note:** This option is only available if an existing surface file is loaded.


*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

### Site plan Options

The **Site Plan Options** can be enabled/disabled to show on the **Plan View**.

- Show Opaque Vehicle – if deselected, the machine will be transparent, allowing you to see the linework behind the machine.
- Show Compass – if selected, an arrow pointing north is shown on the plan view.
- Show Guideline – if guidelines are enabled, this option must be selected to show the guidelines.
- Show Control Points – if selected, control points will be drawn on the **Plan View**.
- Show Control Point Text – if selected, descriptions associated with control points will be displayed on the screen next to the control points.
- Show Stake Points – if selected, points from your topo file are shown on the **Plan View**.
- Show Stake Text – if selected, associated text from the stake points is also shown. **Show Stake Points** must be checked.
- Show Linework – if selected, linework from your linework file will be shown. Deselecting turns off the linework.
- Show Plan Text – if selected, text in the linework file will be shown.
- Show Scale Ruler – if shown, a scale will be shown at the bottom of the **Plan View**.
- Show Machine History – if selected, breadcrumbs are drawn on the screen, showing recent machine history.
- Show Machine Markers – if selected, points of interest on the machine are shown.
- Show Query Markers – if selected, query markers are shown.




*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

### Info Summary tab

The **Info Summary** screen displays the list of text options to display on the **Quick Info** screen. Click to select the options you wish to display.

To de-select an option, click the box a second time. After making your selections, click **Ok**.



*Continued on next page*

## SiteMetrix Grade Main Menu, Continued

### Formats

The **Display Format Options** screen lists the format options that can be displayed for a job. Click the down-arrow to the right of each field to change a selection.


- **Geodetic Format** displays latitude/longitude, UTM, or military grid.
- **Station Format** shows stations when using a guideline.
- **Length Format** selects the unit of measure for northing and easting.
- **Angular Format** selects between Degrees and Gradians.
- **Slope Format** selects between percent and degrees.

**Note:** These fields can only be changed if the check box is unchecked. It is recommended to leave the box checked to minimize errors.

**Show Current Time As:** Click the down-arrow to select **Local**, **UTC**, or **Do Not Show**.

If desired, click to select the checkbox to select to **use the units specified in the current job**.

Click **Ok** to return to the SiteMetrix Grade Home screen.




*Continued on next page*

## SiteMetrix Grade Main Menu, Continued


---

### Exit SiteMetrix Grade

To exit SiteMetrix Grade, click the red power icon in the lower left side of the SiteMetrix Grade Main Menu.



Highlight and click the **Shutdown** option. The confirmation message displays:



Click **Yes**. The SiteMetrix Grade application closes.

---

## Chapter 3: Working with SiteMetrix Grade Jobs

### Overview

---

**Introduction** This chapter covers the information you need to create, modify, delete and design jobs in SiteMetrix Grade.

---

### Contents


	<b>Topic</b>	<b>See Page</b>
	Create a Job	60
	Open a Job	70
	Modify a Job	71
	Delete a Job	76
	Job Tools	77
	Field Design	79
	Design a Job	84
	Topo	91
	Calculations	98
	Manage Points	107
	Stake Out	112
	File Tools	114

---

## Create a Job

### Create a job

To create a job, on the SiteMetrix Grade Home screen, click **New Job**. The **Job Basics** screen displays.



*Continued on next page*


## Create a Job, Continued

---

### Job basics screen

Click the keyboard icon and type the job name, description and job notes.

Click **Next**.



The screenshot shows a 'Job Basics' form with three text input fields. The first field is labeled 'Name:' and contains the text 'New Job Example'. The second field is labeled 'Description:' and contains the text 'This is my new job.'. The third field is labeled 'Notes:' and contains the text 'These are my notes.'. At the bottom right of the form, there are three buttons: 'Back', 'Next', and 'Cancel'. The 'Next' button is highlighted with a red square.

---


*Continued on next page*

## Create a Job, Continued

---

**Job files screen** Click the document icon to the right of each field to add files to your SiteMetrix Grade job:

- Localization
- Geoid Separation
- Horizontal Shift
- Linework
- Guideline
- Survey Topo



**Job Files**

Localization:  

Geoid Separation:  

Horizontal Shift:  

Linework:  

Guideline:  

Survey Topo:  

*Continued on next page*


## Create a Job, Continued

### Surface options window

The **Surface Options** window displays. Click **Add** and type the name of the surface you would like to add.

**Note:** You can add multiple types of surfaces.

To upload a file, click the document icon to the right of the **File Path:** field and select the desired file.



*Continued on next page*

## Create a Job, Continued

---

### Surface options window, continued

Click the down-arrow to select a **Work Type** option.

- **Design**—The most commonly selected option. The **Design** surface is the surface you are grading to.
- **Actual**—Select **Actual** if you have a jobsite topo to upload to the current actual surface.
- **Warning**—Select to trigger a warning in the software if your elevation is either above or below the uploaded surface (see **Alert Method**).
- **Watch**—Similar to **Warning**. This allows for two levels of alert (i.e., You can choose to upload a **Watch** surface to set low priority alerts to an operator and set another **Warning** surface for higher priority alerts to an operator.
- **Pass Count**—color the screen based on how many times a machine has passed over a grid cell.


---

*Continued on next page*

## Create a Job, Continued

Surface options window, continued

The option you selected displays in the **Work Type:** list.



For each **Work Type** you must select (set) the following:

- Fill Style
- Fill Color
- Line Style
- Line Color
- Alert Method (**Note: Alert Method** is only applicable if **Work Type** is set to **Warning** or **Watch**. Select from **Alert When Below** or **Alert When Above**.)

Click to select the checkbox: **Show in Views**, and click **Next**.

**Note:** **Show in Views** must be selected to display your design in the design surface.

*Continued on next page*

## Create a Job, Continued


### Job Mapping window

The **Job Mapping** window displays.

Click the down-arrow to select units for the following fields:

- Units of Measure
- Transform Method
- Alignment Method

Click to use the keyboard icon and type the **Job Scale**.



*Continued on next page*


## Create a Job, Continued

---

**Job Mapping window,**  
continued

To set a geographical reference grid, click **Geo-reference/State Grid**. Click to select from the displayed list.

Click **Next**.




---

*Continued on next page*

## Create a Job, Continued

### Job Localization screen

The **Job Localization** screen displays. You can add points individually by clicking **Add** or import the points from a text file. To load points from a text file, click **Import CSV**.



Use the **Source File** field to select the file.

**Delimiter:** Fields can be separated with a space, tab, comma, or semi-colon.

**Text Qualifier:** If a field contains a delimiter, you can wrap the field around a text qualifier. The two supported text qualifiers are double quotation markers and single quotation markers.

**Skip Rows:** This allows you to skip the top row(s) of your file in the case of there being a header.

**CSV Format:** Select from one of several pre-defined formats or set this field to **Custom**. If set to **Custom**, click **Custom Format** to the right and define the field order.

**LLH Format:** Select from **Degrees, Minutes, and Seconds** or **Decimal Degrees**.

**Geodetic Height Format:** Select from **Feet** or **Meters**.

*Continued on next page*

## Create a Job, Continued

### Job Localization screen, continued

---

Source File:  

File parsing options

Delimiter:  Text Qualifier:   Skip Rows:  

CSV Format:   Custom Format

LLH Format:  Geodetic Height Format:

Preview


---

*Continued on next page*


## Open a Job

### Open a job

To open an existing Job in GradeMetrix, on the Home screen, click the **Open Job** on the GradeMetrix home screen.



The file explorer displays. Navigate to the desired job and click to highlight the job you want to open. Click **Open**.




## Modify a Job

### Modify a job

To modify an existing job in SiteMetrix Grade, click the **Modify Job** icon on the GradeMetrix Main Menu.

**Note:** To modify some **Job** files, you must be logged in as **Administrator**.




*Continued on next page*

## Modify a Job, Continued

### Modify Job basics screen

The **Job Basics** screen displays the **Name**, **Description**, and **Notes** about the job. Click in each field to add the necessary information.



The left navigation menu provides links to the following job information:

- Basics
- Files
- Surfaces
- Mapping
- Localization


*Continued on next page*

## Modify a Job, Continued

### Add job surfaces

From the left navigation menu, click the Surfaces option. The **Surface Options** window displays.

To modify a **Surface**, see **Surface Options** in the **New Job** section of this manual.




*Continued on next page*


## Modify a Job, Continued

### Remove a surface option

To remove a **Surface Option**, click to highlight the **Surface Option** name and click **Remove**.



The **Surface Option** is removed from the **Surface Options** field. When you have finished modifying all the necessary **Surface Options**, click **Ok**.




*Continued on next page*

## Modify a Job, Continued


### Remove a surface option, continued

The currently opened SiteMetrix Grade Job appears. A slight system delay will occur as SiteMetrix Grade applies the job modifications.



### Modify Job mapping screen

From the left navigation menu, click the **Mapping** icon. The **Job Mapping** screen displays. To modify the job mapping, see **Job Mapping** in the **New Job** section of this manual.




*Continued on next page*


## Delete a Job

### Delete a job

To delete a job created in SiteMetrix Grade, on the Main Menu, click the **Delete Job** icon.




Click to highlight the name of the job you wish to delete and click **Delete**.



## Job Tools


### Job Tools

On the SiteMetrix Grade Main Menu, click the **Job Tools** icon.



You can select from five options:

1. Manage Layers-manage the layers contained in the linework of your job
2. Export Job-save your job to a thumb drive
3. Rename Job-change the name under which the job is saved
4. Import LandXML-import a LandXML file
5. Copy Job-copy a job file




*Continued on next page*

## Job Tools, Continued

---

**Job Tools,**  
continued

If importing LandXML, select from a few options:




If uploading to use as a design surface, go back to **Modify Job** to set the surface type to **design**.

---

## Field Design

### Field design

To set job design settings. Click the **Field Design** icon in the SiteMetrix Grade Main Menu.



### Flat pad

Use **Flat Pad** to enter a set elevation to grade to (regardless of design file).

To set your flat pad elevation:


1. Type a name for the 'pad.'
2. Type the average elevation .

*Continued on next page*


## Field Design, Continued

Flat pad,  
continued

Click **Finish**. Design elevation is set to 502.73 ft. in the following example.



The surface shown in green is the field design; the surface shown in red is the DTM. The blue text at the top left reminds you that you are checking grade to a field design and not any surface associated with your job.



*Continued on next page*

## Field Design, Continued

### Sloped Pad

**Slope Pad** allows the user to make a dual sloped pad. Enter a **Pad** name and click **Next**.

- Flat Pad
- Sloped Pad
- Ramp
- Points Surface
- Clear Design

#### Build Sloped Pad

To create a sloped pad either manually enter the elevation or press *Record From GNSS*. When the desired elevation is established press *Finish* to accept the surface.

Name:

✖ Reset

Recent:  ▼

← Back
→ Next
✖ Cancel

Click **Record** to average your position. Click **Next**.

- Flat Pad
- Sloped Pad
- Ramp
- Points Surface
- Clear Design

#### Set Sloped Pad Base Point

Position the vehicle over the start point and use the GPS to measure its location. The start location may also be entered or edited manually. When the measured point is ready, press *Next* to measure the second point.

Northing:

Easting:

Elevation:

Record At:  ▼

Record

100%


← Back
→ Next
✖ Cancel

*Continued on next page*

## Field Design, Continued

### Sloped Pad, continued

Move to the end point of the pad and click **Record**. Edit bearing, distance, and slope (long slope) if necessary. For Slope, you can select between **Percent**, **Rise over Run**, or **Run over Rise**. Click **Next**.



You can create a pad of infinite width or configure width. If you want to configure width, deselect **Create an infinite Sloped Pad** and enter a width.

You can select if this width needs to be left of center, right of center, or centered (half the width on each side of centerline). Enter a **Cross Slope**, it can be entered as percent, rise over run, or run over rise.

*Continued on next page*

## Field Design, Continued

Sloped Pad,  
continued

Click **Finish**.

The screenshot shows the 'Configure Sloped Pad' dialog box. On the left is a vertical toolbar with icons for 'Flat Pad', 'Sloped Pad' (highlighted), 'Ramp', 'Points Surface', and 'Clear Design'. The main area contains the following text and controls:

**Configure Sloped Pad**  
Select the type of the Sloped Pad. An Infinite pad has unlimited boundary. Width and center line must be set for a finite pad. After configuration is done, press *Finish* to complete the setup of Sloped Pad.

Create an infinite Sloped Pad

Side of Center:  ▼

Width:

Cross Slope:  %

On the right is a preview window showing a 3D perspective view of a sloped pad on a dark terrain, with a white center point and a blue compass rose. At the bottom right of the dialog are three buttons: 'Back' (green), 'Finish' (blue), and 'Cancel' (red).

## Design a Job


### Ramp

Choose **Ramp** to build the ramp by using coordinates for following a set guideline.

**Note:** If you do not have a guideline selected, you must create this ramp based on coordinates.

To set your ramp type a **Ramp Name** using the keyboard icon. You can create a ramp by using two sets of coordinates (select **From Coordinates**) to create a baseline, or by following a Guideline (select **From Guideline**).

Press **Next**.



**Build Ramp**  
Select how you would like to build the ramp and the press *Next*.

Name:

Recent:

From Coordinates


Follow Guideline

*Continued on next page*


## Design a Job, Continued

Ramp,  
continued

If you selected **From Guideline**, you will be prompted to select a guideline.



Or drive to the starting point and click **Record**.



Drive to the second point (calculates heading). Click **Record**.

*Continued on next page*

## Design a Job, Continued

Ramp,  
continued

**Note:** If you wish this ramp to exceed the length the vehicle has driven, edit the distance. You can also edit the calculated heading (bearing) and slope. Slope can be entered as percent, rise over run, or run over rise.

The screenshot shows the 'Fix Ramp Direction and Forward Slope' screen in the Hemisphere software. On the left is a vertical menu with icons and labels for 'Flat Pad', 'Sloped Pad', 'Ramp' (highlighted in blue), 'Points Surface', and 'Clear Design'. The main area contains the following elements:

- Fix Ramp Direction and Forward Slope** title and a descriptive paragraph: "Position the vehicle over the second point and use the GPS to measure its location. This will fix the direction and forward slope of the ramp. The location may also be entered or edited manually. When the measured point is ready, press *Next* to build the cross slopes."
- Input fields for:
  - Bearing: 0.00°
  - Distance: 500.00ft
  - Slope: % 10.000%
- A 'Record At:' dropdown menu set to 'Right'.
- A 'Record' button with a satellite icon.
- A yellow progress bar showing 100% completion.
- Navigation buttons at the bottom: 'Back' (left arrow), 'Next' (right arrow), and 'Cancel' (red X).
- A map view on the right showing a top-down perspective of a terrain with a white circle indicating the vehicle's current position and a blue circle representing a target point.

*Continued on next page*

## Design a Job, Continued

**Ramp,**  
continued

To remove cross slope fields, click **Clear values on Add**. This will clear the field a new value can be added each time the **Add** button is pressed. Click on a lane and press **Remove**.

**Add a New Lane**

Enter the width of the lane, its slope, and which side of the center-line it will be appended then press *Add*. Continue this process until the desired number of lanes is created then press *Next*.

Side of Center:

Lane Width:

Cross Slope:

Clear values on Add

Side of Center	Width	Slope
Left	10.00ft	2.00%

Buttons:

Review ramp and press **Finish**.

**Ramp Summary**

Review the ramp design and verify it is correct. Press *Finish* to save or *Back* to make changes.

Side of Center	Width	Slope
Left	10.00ft	2.00%

Buttons:

*Continued on next page*


## Design a Job, Continued

### Ramp, continued

The example below shows the newly created ramp (in blue). To make the ramp longer, edit the distance towards the beginning.

**Important:** This ramp becomes the job design. If the machine is not on the ramp, the machine is off the job design.


The below example shows the machine blade exceeding the edge, and no longer on the job design.



*Continued on next page*


## Design a Job, Continued

**Points Surface** You can generate a surface from existing topo points.



After entering the name of the new surface, select **Next**.

Select the topo file that will be used to generate a surface. A perimeter will be drawn around the outermost points.




*Continued on next page*

## Design a Job, Continued

### Points Surface, continued


The surface will be shown prior to clicking **Finish** and saving the surface.



### Clear design

If you wish to remove a field design element, click to select one of the options in the **Clear Design** list.

For example, to remove the flat pad option, select and click **Finish**.



Your design elevation returns to the previously loaded Digital Terrain Model (DTM) file.

## Topo

### Topo

Use **Topo** to create a topo point file by either manually storing points, or auto-storing points by time or distance intervals.



*Continued on next page*

## Topo, Continued


**General Settings** The **General Settings** window displays the following selections:

Setting	Description
<b>Survey Topo:</b>	<p>Create a Survey Topo to store points.</p> <p>Click the icon to the right of the dialogue box and name the file.</p>
<b>Point of Interest:</b>	<p>Select the point of the truck that the NEZ will be taken from when storing points. If using a survey rod, this feature is not applicable.</p>
<b>Starting Point Id</b>	<p>Each time a point is stored, a corresponding point ID is created.</p> <p>Starting Point ID increments by 1 each time you shoot a point. The value entered indicates the ID of the first stored point.</p>
<b>Save Method:</b>	<p>Click the down-arrow to select from the following options:</p> <ul style="list-style-type: none"> <li>– <b>Time</b>-the number input into <b>Save Every</b> must be in seconds.</li> <li>– <b>Distance</b>-store the point by distance interval. Type a distance value in the <b>Save Every</b> field.</li> <li>– <b>Manual</b>-store points only when <b>Single Shot</b> is pressed.</li> </ul>
<b>Collect Samples For</b>	<p>The length of time that a point is averaged for when collecting points.</p>
<b>Save first point on start when auto-saving</b>	<p>Click the checkbox to select. This option may only be selected if the <b>Save Method</b> is <b>not</b> manual.</p>
<b>Prompt for feature code</b>	<p>The software prompts to select from one of the available feature codes.</p>
<b>Allow time profile while stationary</b>	<p>Allow SiteMetrix Grade to collect points on a time interval even while the receiver is stationary.</p>

*Continued on next page*

## Topo, Continued

### General Settings, continued



### Storing points

On the **General** tab, click on document icon to the right of the **Survey Topo** field to select or create a new file.



*Continued on next page*

## Topo, Continued

---


### Storing points, continued

Click or type to select the following options:

- **Point of Interest:** Choose where to store the point from.
- **Save Method:** Set to store a point manually, or autosave every several seconds or several feet driven.
- **Starting Point Id:** Each point has an ID and increments.

Click **Point Info**. The **Point Information** screen displays.

Click the box to select the options you wish to save to the topo file. When you are finished making your selections, click **Ok**.



### Codes

You can select to prompt for **Feature Code**. When a point is stored, you will receive a prompt for a code.


The **Manage Feature Codes** screen displays the listing of feature codes. Click to highlight the **Feature Code** you wish to add and click **Add**. Press **OK**.

**Note:** Do not select this feature if auto storing points.

*Continued on next page*

## Topo, Continued

### Codes, continued




*Continued on next page*

## Topo, Continued

---

### Lines

The **Lines** tab allows you to select from lines you have created as well as remove them.



*Continued on next page*

## Topo, Continued

---

### Topo


After configuring the options, click **OK**.

If you selected to store topo by the time or distance interval, you can click **Start Auto** to begin your auto topo. **Single Shot** will store a single point at your location.

**Setup** returns to the **Configuration** page.

**Exit** returns to the **Plan View** screen.


Click **Start Line** to shoot topo points and create a line. Click **End Line** to finish the line.



## Calculations

### Calculations

Use the **Calculations** tab to calculate volumes, inverse between points, or do a 3D Calibration for a GradeMetrix dozer or excavator.



After clicking on **Calculations**, options display for the **Vehicle Calibration Wizard**, **Volumes**, and **Inverse**.



*Continued on next page*

## Calculations, Continued


---

### Calculations, continued

For information on the **Vehicle Calibration Wizard**, please see the GradeMetrix Excavator Installation Guide or GradeMetrix Dozer Installation Guide.

**Volumes** compares two surfaces and calculates cut/fill between those two surfaces.

**Volumes** will prompt you to select a starting surface.




*Continued on next page*

## Calculations, Continued

---

### Calculations, continued

Select the option to create a surface in real-time by making a topo, loading a surface file (such as a DTM or in-field design surface), or comparing to a constant elevation.





The image shows a software dialog box with three radio button options: "Surface File", "Elevation", and "Create Topo". The "Surface File" option is selected, indicated by a dark purple dot in the center of its radio button. Below the options is a "Cancel" button with a red circle containing a white "X" icon.

---

*Continued on next page*

## Calculations, Continued

Calculations,  
continued



*Continued on next page*

## Calculations, Continued


Calculations,  
continued



*Continued on next page*

## Calculations, Continued


Calculations,  
continued




*Continued on next page*

## Calculations, Continued

### Calculations, continued



The **Inverse** routine allows for calculating distance, azimuth, and bearing between points.




*Continued on next page*


## Calculations, Continued

### Calculations, continued

You can select points from your topo file, your localization file, or from the screen.



Select the desired tab at the top (**From Topo** = from the topo file loaded; **From Control** = from localization file; **From Screen** = allows you to click on a point that is drawn on the screen).



*Continued on next page*

## Calculations, Continued

Calculations,  
continued

Click **Next**.

Select the second point.

**Final Point Selection**

Northing: 50369.75ft  
 Easting: 60914.51ft  
 Elevation: 507.01ft

From Topo From Control From Screen

volumeSurface\_2021-09-09\_1.topo

Name	Northing	Easting	Elevation
SP_1	50523.22ft	60886.99ft	511.64ft
SP_2	50504.82ft	60890.71ft	509.71ft
SP_3	50510.16ft	60904.84ft	509.83ft
SP_4	50502.97ft	60930.68ft	508.26ft
SP_5	50487.16ft	60937.46ft	507.00ft
SP_6	50456.82ft	60966.89ft	507.00ft
SP_7	50436.44ft	60968.64ft	506.98ft
SP_8	50408.93ft	60957.40ft	507.02ft
SP_9	50387.56ft	60939.82ft	507.04ft
SP_10	50368.85ft	60919.18ft	507.08ft
SP_11	50359.04ft	60916.76ft	507.03ft
SP_12	50363.62ft	60923.66ft	506.99ft
SP_13	50369.75ft	60914.51ft	507.01ft
SP_14	50360.37ft	60906.77ft	507.05ft
SP_15	50365.41ft	60879.69ft	507.07ft

Back Next Cancel

Click **Next**.


**Report**

Start Point		Result	
Northing:	50487.16ft	Horizontal Distance:	119.63ft
Easting:	60937.46ft	Vertical Distance:	0.01ft
Elevation:	507.00ft	Slope Distance:	119.63ft
Final Point		Slope:	0.0°
Northing:	50369.75ft	Bearing:	191.1°
Easting:	60914.51ft		
Elevation:	507.01ft		


Back Finish Cancel

## Manage Points

**Manage Points** Use **Manage Points** to add, remove, or edit Topo Points and Lines.



Select a point and you have the option to remove that point or edit that point. Additionally, you can add a point manually or **Import CSV**.



Importing from CSV allows you to select the fields of the CSV file from several predetermined formats or select a custom format.

Source File:

File parsing options

Delimiter:  Text Qualifier:  Skip Rows:

CSV Format:

Preview

The **From Line** tab allows you to see lines that were created in the Topo routine. You can add or remove lines manually as well as edit the nodes of existing lines.


**Manage Points and Lines**

Filter

Name	Code	Description
 LP_122		


## Check Position

### Check Position



**Check Position** checks the accuracy of your GNSS receiver. Place the receiver onto a control point, select the point from the loaded file, and click **Check**. Your current GNSS position is read and averaged, and the deltas to that point are checked.

You can select a file **From Topo**, **From Control**, or **From Screen**.




*Continued on next page*

## Check Position, Continued


**Check Position, continued** Click the point below your GNSS receiver and click **Check**.

**Delta Northing, Easting, and Elevations** are provided, along with **HRMS, VRMS,** and satellite count.



Name	HDist	Northing	Easting	Elevation	Code
SP_36	0.05ft	50523.07ft	60887.17ft	502.55ft	BC
SP_1					
SP_2					
SP_3					
SP_21					
SP_22					
SP_20					
SP_35					
SP_4	47.94ft	50502.97ft	60930.68ft	508.26ft	
SP_23	50.52ft	50480.35ft	60914.08ft	507.92ft	
SP_19	56.05ft	50474.87ft	60858.66ft	507.09ft	
SP_5	61.82ft	50487.16ft	60937.46ft	507.00ft	
SP_31	65.78ft	50460.01ft	60905.72ft	508.04ft	

In **Tilt Compensation Mode**, you are given the option to test the accuracy of tilted pole measurements. Plumb your pole and click **Check**. The position will be averaged for ten seconds.



**Tilted Pole Check**

Please place the pole tip on the ground, keep the pole vertical, then click **Check** to start measuring position, the measuring won't start until the pole is plumbed. Once measured, keep the pole tip at the same position on the ground and the pole can be tilted at any angle. The difference of position and tilt angle will be updated.

Northing: 0.03ft  
 Easting: 0.03ft  
 Elevation: 0.02ft  
 Pitch: -7.82°  
 Roll: -9.78°  
 Yaw: -40.45°  
 Status: Initialized

*Continued on next page*

## Check Position, Continued

### Check Position, continued

**Tilted Pole Check**  
Please place the pole tip on the ground, keep the pole vertical, then click *Check* to start measuring position, the measuring won't start until the pole is plumbed. Once measured, keep the pole tip at the same position on the ground and the pole can be tilted at any angle. The difference of position and tilt angle will be updated.

Northing:	<input type="text"/>
Easting:	<input type="text"/>
Elevation:	<input type="text"/>
Pitch:	<input type="text" value="-0.38°"/>
Roll:	<input type="text" value="-0.24°"/>
Yaw:	<input type="text" value="-36.71°"/>
Status:	Initialized




Tilt the pole in various directions and SiteMetrix Grade will calculate **Delta Northing**, **Delta Easting**, and **Delta Elevations**.


# Stake Out

## Stake Out

SiteMetrix Grade can stake a topo point, localization point, or a line.



When you enter the **Stake-Out** routine select a point from your topo file, localization file, or the screen. Select a point and click **OK**.




*Continued on next page*


## Stake Out, Continued

Stake Out,  
continued

Delta northing, easting, elevation along with total distance and azimuth displays, allowing you to stake the point.




If you select a line to stake, click **Previous** or **Next** to switch between nodes.




## File Tools

**File Tools** exports your grid, tin, or topo.



If you select to export your topo, you can export it as LandXML or CSV.



# Appendix A: Troubleshooting

## Overview

---

**Introduction** This chapter contains frequent questions that may arise while using SiteMetrix Grade and how to troubleshoot them.

---

## Contents

	<b>Topic</b>	<b>See Page</b>
	Troubleshooting	116
	Overview	117
	C631 Smart Antenna	118
	HT20 Data Collector	123
	Index	126

---

## Troubleshooting

### Troubleshooting

**Table A-1: Troubleshooting**

Symptom	Possible Resolution
Wrong Position	Check your C631 over a control point. If the Northing, Easting, and Elevation do not match, first check to make sure that your C631 is RTK Fixed. If it is RTK Fixed, ensure your base station coordinate is correct. Check to ensure you have the correct localization loaded, and the residuals are within tolerance.
No RTK	<p>If using NTRIP, check to see if network coverage is available. If using the WiFi or Cellular on the HT20, exit SiteMetrix Grade and try to access the internet with a web browser. If using a SIM card in the C631, check the Cellular Signal Quality.</p> <p>If using UHF, first ensure the base station radio is transmitting. Most radios have a TD or Tx light that will blink once per second. Next, ensure you are in range of UHF. Set the C631 next to the base station radio to see if it is functioning.</p>

## Appendix B: Technical Specifications

### Overview

---

**Introduction** Appendix B contains the technical specifications for the C631 Smart Antenna and the HT20 Data Collector.

---

### Contents

	<b>Topic</b>	<b>See Page</b>
	C631 Smart Antenna	118
	HT20 Data Collector	123
	Index	126

---

## C631 Smart Antenna

### C631 Smart Antenna specifications

The following lists the specifications for the C631 Smart Antenna.

**Table B-1: GNSS Receiver**

Item	Specification
Receiver type	Multi-Frequency GPS, GLONASS, BeiDou, Galileo, QZSS, IRNSS, and Atlas L-band
Signals Received	GPS L1CA/L1P/L1C/L2P/L2C/L5 GLONASS G1/G2/G3, P1/P2 BeiDou B1i/B2i/B3i/B1OC/B2A/B2B/ACEBOC GALILEO E1BC/E5a/E5b/E6BC/ALTBOC QZSS L1CA/L2C/L5/L1C/LEX IRNSS L5 Atlas
Channels	800+
RTK Formats	RTCM2.1, RTCM2.3, RTCM3.0, RTCM3.1, RTCM3.2 including MSM
Recording Intervals	Selectable from 1, 2, 4, 5, 10 Hz (20 Hz or 50 Hz optional)

*Continued on next page*

## C631 Smart Antenna, Continued

C631 Smart Antenna specifications, continued

**Table B-2: Accuracy**

Item	Specification		
Secondary antenna	GPS L1,L1P,L2C,L2P GLONASS G1,G2 BeiDou B1,B2 Galileo E1,E5b L-band		
GPS sensitivity	-142 dBm		
SBAS tracking	3-channel, parallel tracking		
Update rate	10 Hz standard, and 20 Hz available		
Positioning		<b>RMS (67%)</b>	<b>2DRMS (95%)</b>
	RTK <sup>1,2</sup>	8 mm + 1 ppm	15 mm + 2 ppm
	Atlas (H10) <sup>1,2</sup>	0.04 m	0.08 m
	SBAS <sup>1</sup>	0.3 m	0.6 m
	Autonomous, no SA <sup>1</sup>	1.2 m	2.4 m
	Static Performance <sup>1</sup>	2.5 mm + 1 ppm	5 mm + 1 ppm
	Tilt Compensation (within 30°)	2 cm (with 1.8 m pole)	
	Tilt Compensation (within 30°)	2 cm (with 1.8 m pole)	
	Initialization Time	< 10 s	

*Continued on next page*

## C631 Smart Antenna, Continued

C631 Smart Antenna specifications, continued

**Table B-3: L-Band Receiver Specifications**

Item	Specification
Receiver Type	Single Channel
Frequency Range	1525 to 1560 MHz
Sensitivity	-130 dBm
Channel Spacing	5.0 kHz
Satellite Selection	Manual and Automatic
Reacquisition Time	15 seconds (typical)

**Table B-4: Communications**

Item	Specification
Bluetooth	Bluetooth 2.1+EDR / 4.0 LE
Wi-Fi	802.11 b/g
Network	LTE FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/B18/B19/B20/B25/B26/B28 LTE TDD: B38/B39/B40/B41 UMTS: B1/B2/B4/B5/B6/B8/B19 GSM: B2/B3/B5/B8
Radio	Frequency range: 410MHz ~ 470MHz and 902.4MHz ~ 928MHz Channel Spacing: 12.5 KHz / 25 KHz Protocol: TrimTalk 450S, PCC EOT, TrimMark III(19200)
WebUI	To upgrade software, manage settings, data download, via smartphone, tablet or other electronic device, configure advanced radio settings

*Continued on next page*

## C631 Smart Antenna, Continued

C631 Smart Antenna specifications, continued

**Table B-5: Connector Ports**

Item	Specification
TNC	For connecting to UHF radio antenna
LEMO 5-pin	For connecting to external power supply, external radio
LEMO 7-pin	For serial port, USB
Card Slots	For Micro SIM card and Micro SD card

**Table B-6: Data and Storage**

Item	Specification
Storage Type	8 GB internal, SD card up to 32 GB

**Table B-7: Physical**

Item	Specification
Weight	1.19 kg (1 battery), 1.30 kg (2 batteries)
Dimensions	156 x 76 mm

**Table B-8: Environmental**

Item	Specification
Operating Temperature	-30°C ~ +65°C
Storage Temperature	-40°C ~ +80°C
Protection	IP67. Protected from temporary immersion to a depth of 1 m
Shock Resistance	MIL-STD-810G, method 516.6. Designed to survive a 2 m pole drop on concrete floor. Designed to survive a 1 m free drop on hardwood floor.
Humidity	Up to 100%
Vibration	MIL-STD-810G, method 514.6E-I
Inflammability	UL recognized, 94HB Flame Class Rating (3) 1.49 mm
Chemical Resistance	Cleaning agents, soapy water, industrial alcohol, water vapor, solar radiation (UV)

*Continued on next page*

## C631 Smart Antenna, Continued

C631 Smart Antenna specifications, continued

**Table B-9: Electrical**

Item	Specification
Input Voltage	9 to 28 V DC
Battery	With removable dual battery, for single battery parameter: 7.2 V, 3400 mAh, 24.48 Wh
Working Time	12 hours in Rover UHF mode (2 batteries)

**Table B-10: User Interface**

Item	Specification
Button	Switch receiver on/off, broadcast current operation mode and status
LEDs	Power, Satellite, Data Link, Bluetooth
WebUI	Supports software updates, receiver status and settings, and data downloads via smartphones, tablets, or other Wi-Fi capable devices.

<sup>1</sup>Depends on multipath environment, number of satellites in view, satellite geometry, and ionospheric activity

<sup>2</sup>Depends also on baseline length

<sup>3</sup>Requires a subscription from Hemisphere GNSS

## HT20 Data Collector

### HT20 Data Collector specifications

Tables B-11 through B-20 show the HT20 Data Collector specifications.

**Table B-11: System specifications**

System	Specification
Processor	Quad-core Intel® Pentium N4200
Operating System	Microsoft® Windows 10
Storage	128 GB Flash Storage

**Table B-12: Display specifications**

7.0"
1200x800
Sunlight-viewable
multi-touch capacitive touchscreen

**Table B-13: Camera specifications**

Rear: 13MP
Front: 5MP

**Table B-14: Connectivity**

System	Specification
Cellular	4G LTE multi-carrier capable 2x2 MIMO
Wireless LAN	Wi-Fi 802.11 a/b/g/n/ac 2.4 GHz and 5 GHz
Bluetooth	5.0
NFC	Yes

**Table B-15: Power**

System	Specification
Battery	Removable Li-Ion battery, 43.2 Whr
Technology	Operates 8–10 hours on one charge Optimized for powerful performance in cold temperatures

*Continued on next page*

## HT20 Data Collector, Continued

HT20 Data  
Collector  
specifications,  
continued

**Table B-16: Mechanical**

System	Specification
Dimensions	137 x 215 x 35 mm
Weight	680–907 g

**Table B-17: Rugged Features**

Feature	Specification
IP Rating	IP68 waterproof & dustproof
Drop Tested	multiple drops from 4' (1.2 –1.5 m) onto concrete
Water	1.4 m (4' 7") for 2 hours
MIL-STD	MIL-STD-810G MIL-STD-461F
Environmental	Operating Temp -20°C ~ 50°C Storing Temp -30°C ~ 70°C
Shock Resistance	MIL-STD-810G, Method 500.5
Low Pressure (Altitude)	Method 501.5

**Table B-18: Temperature**

	Specification
High	Method 502.5
Low	Method 503.5
Shock	Method 506.5
Rain	Method 507.5
Humidity	Method 510.5
Sand and Dust	Method 512.5
Immersion	Method 514.6
Vibration	Method 516.6 Shock

*Continued on next page*

## HT20 Data Collector, Continued

---

HT20 Data  
Collector  
specifications,  
continued

**Table B-19: Certifications**

FCC Class B, CE Marking, Industry Canada, EN62368 Safety, RoHS 2
Compliant, Optional Class

**Table B-20: Interfaces**

	<b>Specification</b>
<b>I/O Ports</b>	USB 3.0 x 1
	3.5 mm audio jack
	Optional RS-232 9-Pin

---

## Index

---

Alert Method .....	65
BeiDou.....	119
Control .....	12
Description.....	61, 72
Files .....	12, 72
Fill Color .....	65
Fill Style.....	65
Formats.....	47
GLONASS.....	119
GPS.....	119
Guideline.....	62
Home screen.....	47, 57, 58, 60, 70, 71
Job Basics .....	60, 72
Line Color .....	65
Line Style.....	65
Linework .....	62
Name.....	72
Open Job .....	70
SBAS .....	119
Settings .....	47
Show in Views.....	65
Shut down.....	58
Site Calibration.....	72
<b>Surface Options</b> .....	74
Surface options window .....	63
<b>Surfaces</b> .....	65
Survey Top .....	62

---

# End User License Agreement

---

## End User license agreement

**IMPORTANT** - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
  - a. install or use more copies of the Software than the number of copies that have been licensed;
  - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
  - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
  - d. modify or create derivative works based on the Software;
  - e. sub-license, rent, lease, loan or distribute the Software;
  - f. permit any third party to use the Software;
  - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
  - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
  - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at any time.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

1. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
2. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
3. **TRADEMARKS.** "Hemisphere GNSS", "Crescent", "Eclipse" and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
4. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
5. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential positioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
6. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
7. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.
8. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

1. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
2. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
3. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
4. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
5. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
6. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere. 19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a) negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product,

---

*Continued on next page*

## End User License Agreement, Continued

---

### End User license agreement, continued

- (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
5. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
  6. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
  7. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
  8. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
  9. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
  10. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
  11. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
  12. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

**GENERAL.** This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.

---

# Warranty Notice

---

## Warranty notice

**COVERED PRODUCTS:** This warranty covers all products manufactured by Hemisphere GNSS and purchased by the end purchaser (the "Products"), unless otherwise specifically and expressly agreed in writing by Hemisphere GNSS.

**LIMITED WARRANTY:** Hemisphere GNSS warrants solely to the end purchaser of the Products, subject to the exclusions and procedures set forth below, that the Products sold to such end purchaser and its internal components shall be free, under normal use and maintenance, from defects in materials, and workmanship and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for a period of 12 months from delivery of such Product to such end purchaser (the "Warranty Period"). Repairs and replacement components for the Products are warranted, subject to the exclusions and procedures set forth below, to be free, under normal use and maintenance, from defects in material and workmanship, and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater.

**EXCLUSION OF ALL OTHER WARRANTIES.** The LIMITED WARRANTY shall apply only if the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS relevant User's Manual and Specifications, AND the Product is not modified or misused. The Product is provided "AS IS" and the implied warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE and ALL OTHER WARRANTIES,

express, implied or arising by statute, by course of dealing or by trade usage, in connection with the design, sale, installation, service or use of any products or any component thereof, are EXCLUDED from this transaction and shall not apply to the Product. The LIMITED WARRANTY is IN LIEU OF any other warranty, express or implied, including but not limited to, any warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE, title, and non-infringement.

**LIMITATION OF REMEDIES.** The purchaser's EXCLUSIVE REMEDY against Hemisphere GNSS shall be, at Hemisphere GNSS's option, the repair or replacement of any defective Product or components thereof. The purchaser shall notify Hemisphere GNSS or a Hemisphere GNSS's approved service center immediately of any defect. Repairs shall be made through a Hemisphere GNSS approved service center only. Repair, modification or service of Hemisphere GNSS products by any party other than a Hemisphere GNSS approved service center shall render this warranty null and void. The remedy in this paragraph shall only be applied in the event that the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS's relevant User's Manual and Specifications, AND the Product is not modified or misused. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR CONTINGENT DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE

TO PURCHASER, even if Hemisphere GNSS has been advised of the possibility of such damages. Without limiting the foregoing, Hemisphere GNSS shall not be liable for any damages of any kind resulting from installation, use, quality, performance or accuracy of any Product.

**HEMISPHERE IS NOT RESPONSIBLE FOR PURCHASER'S NEGLIGENCE OR UNAUTHORIZED USES OF THE PRODUCT.** IN NO EVENT SHALL Hemisphere GNSS BE IN ANY WAY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM PURCHASER'S OWN NEGLIGENCE, OR FROM OPERATION OF THE PRODUCT IN ANY WAY OTHER THAN AS SPECIFIED IN Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS is NOT RESPONSIBLE for defects or performance problems resulting from (1) misuse, abuse, improper installation, neglect of Product; (2) the utilization of the Product with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Hemisphere GNSS; (3) the operation of the Product under any specification other than, or in addition to, the specifications set forth in Hemisphere GNSS's relevant User's Manual and Specifications; (4) damage caused by accident or natural events, such as lightning (or other electrical discharge) or fresh/ salt water immersion of Product; (5) damage occurring in transit; (6) normal wear and tear; or (7) the operation or failure of operation of any satellite-based positioning system or differential correction service; or the availability or performance of any satellite-based positioning signal or differential correction signal.

**THE PURCHASER IS RESPONSIBLE FOR OPERATING THE VEHICLE SAFELY.** The purchaser is solely responsible for the safe operation of the vehicle used in connection with the Product, and for maintaining proper system control settings. UNSAFE DRIVING OR SYSTEM CONTROL SETTINGS CAN RESULT IN PROPERTY DAMAGE, INJURY, OR DEATH.

---

*Continued on next page*

## Warranty Notice, Continued

---

### Warranty notice, continued

The purchaser is solely responsible for his/her safety and for the safety of others. The purchaser is solely responsible for maintaining control of the automated steering system at all times. THE PURCHASER IS SOLELY RESPONSIBLE FOR ENSURING THE PRODUCT IS PROPERLY AND CORRECTLY INSTALLED, CONFIGURED, INTERFACED, MAINTAINED, STORED, AND OPERATED IN ACCORDANCE WITH Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS does not warrant or guarantee the positioning and navigation precision or accuracy obtained when using Products. Products are not intended for primary navigation or for use in safety of life applications. The potential accuracy of Products as stated in Hemisphere GNSS literature and/or Product specifications serves to provide only an estimate of achievable accuracy based on performance specifications provided by the satellite service operator (i.e. US Department of Defense in the case of GPS and differential correction service provider). Hemisphere GNSS reserves the right to modify Products without any obligation to notify, supply or install any improvements or alterations to existing Products.

**GOVERNING LAW.** This agreement and any disputes relating to, concerning or based upon the Product shall be governed by and interpreted in accordance with the laws of the State of Arizona.

**OBTAINING WARRANTY SERVICE.** In order to obtain warranty service, the end purchaser must bring the Product to a Hemisphere GNSS approved service center along with the end purchaser's proof of purchase. Hemisphere GNSS does not warrant claims asserted after the end of the warranty period. For any questions regarding warranty service or to obtain information regarding the location of any of Hemisphere GNSS approved service center, contact Hemisphere GNSS at the following address:

**Hemisphere GNSS**

8515 E. Anderson Drive Scottsdale, AZ 85255, USA

Phone: +1-480-348-6380

Fax: +1-480-270-5070

[TECHSUPPORT@HGNSS.COM](mailto:TECHSUPPORT@HGNSS.COM)

[WWW.HGNSS.COM](http://WWW.HGNSS.COM)

---



Hemisphere GNSS Inc.  
8515 East Anderson Drive  
Scottsdale, Arizona, US 85255  
Phone: 480-348-6380  
Fax: 480-270-5070  
[PRECISION@HGNSS.COM](mailto:PRECISION@HGNSS.COM)  
[WWW.HGNSS.COM](http://WWW.HGNSS.COM)