



**GRADEMATRIX™ LOADER
INSTALLATION GUIDE
Revision: A1**



Additional information, documentation, and software can be found at:

WWW.HGNSS.COM

Copyright 2023

Device Compliance, License and Patents

Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 This device may not cause harmful interference, and
 this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

E-Mark Statement: This product is not to be used for driverless/autonomous driving.

Copyright Notice

Copyright Hemisphere GNSS, Inc. (2023). All rights reserved.
 No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™, Cygnus™, Atlas™, aRTK, SureFix™, and Athena™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners.

Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

Continued on next page

Overview, Continued

Notice to Customers Contact your local dealer for technical assistance. To find the authorized dealer near you:

Hemisphere GNSS, Inc
8515 East Anderson Drive
Scottsdale, AZ 85255 USA
Phone: (480) 348-6380
Fax: (480) 270-5070
PRECISION@HGNS.COM
[HTTPS://WWW.HEMISPHEREGNSS.COM/](https://www.hemispheregnss.com/)

Technical Support If you need to contact Hemisphere GNSS Technical Support:

Hemisphere GNSS, Inc.
8515 East Anderson Drive
Scottsdale, AZ 85255 USA
Phone: (480) 348-6380
Fax: (480) 270-5070
SUPPORT.HGNS.COM

**Documentation
Feedback**

Hemisphere GNSS is committed to the quality and continuous improvement of our products and services. We urge you to provide Hemisphere GNSS with any feedback regarding this guide by opening a support case at the following website:

[HTTPS://HEMISPHERE.ATLASSIAN.NET/SERVICEDESK/CUSTOMER/PORTAL/2/USER/LOGIN?DESTINATION=PORTAL%2F2](https://hemisphere.atlassian.net/servicedesk/customer/portal/2/user/login?destination=portal%2F2)

Table of Contents

Device Compliance, License and Patents	2
Chapter 1: Getting Started.....	6
Overview	6
Getting Started.....	7
Tools List	8
Preparing for Installation	9
Safety Information and Warnings.....	10
What’s Included in Your Kit.....	11
Machine Inspection Checklist	14
Chapter 2: Sensor Installation.....	15
Overview	15
GMS-1 Sensor Installation.....	16
Rotary Encoder Installation	26
Chapter 3: Installing the VR500 Antenna	32
Overview	32
Install the VR500 Antenna	33
Chapter 4: IronTwo	38
Overview	38
IronTwo Display Installation	39
Chapter 5: GradeMetrix® System	44
Overview	44
Measure and Set Up Equipment.....	45
Configure Machine Measure	47
Set Up Sensor	50
Calibrate System	54
Quick Calibrate.....	58
3D Calibration	60
Verify Machine Accuracy	74
Save Machine Settings	77
Appendix A: Troubleshooting	79

Overview	79
Troubleshooting.....	80
Appendix B: Technical Specifications.....	82
Overview	82
VR500 Receiver	83
IronTwo	88
GMS-1 Sensor.....	90
Appendix C: Cable Pin-Outs	92
Overview	92
Part Number 051-0426-10	93
Part Number 051-0406-10	95
Part Number 051-0407-10	96
VR500 Installation Schematic	97
Index.....	98
End User License Agreement	99

Chapter 1: Getting Started

Overview

Introduction

Chapter 1 provides you with the information and proper tooling needed to begin a GradeMetrix® Loader installation.

It is recommended for only an experienced service technician perform the installation and configuration of the Hemisphere GradeMetrix® system.

Contents

	Topic	See Page
	Getting Started	7
	Tools List	8
	Preparing for Installation	9
	Safety Information and Warnings	10
	What's Included in Your Kit	11
	Machine Inspection Checklist "Firmware"	14

Getting Started

Introduction

This section lists the tools required, preparation, and power setup necessary to prepare your machine for the GradeMetrix® Loader system installation.

Tools List

Tools list

A variety of tools are needed to properly set up and install your GradeMetrix® Loader system.

Review the following list and locate these required tools prior to beginning installation:

- Slotted screwdriver
 - Phillips screwdriver
 - Adjustable wrench
 - ½" & 3/8" ratchet set
 - Inch sockets
 - Metric sockets
 - Cable tie cutters
 - Allen wrench set (inch)
 - Allen wrench set (metric)
 - Torx wrench
 - Wire stripper / Crimp tool
 - GNSS base/rover
 - Open wheel measuring tape
 - Cable ties
 - Split tube or other cable protection
 - Electrical Tape
 - Heat Shrink
 - Electrical terminals i.e., spade, ring etc.
 - Thread locker i.e., Loctite or similar
 - Nickel anti-seize grease or similar
 - Cold Gal and Machine-color paint if welding
-

Preparing for Installation

Prepare for installation

To prepare for a loader installation, place the loader on a flat surface.

Locate a clean source of power and a safe mounting location for the IronTwo control box. Check to ensure the control box and the GMS-1 sensors have power.

Important: The IronTwo must receive 7 – 36 VDC of input power from the machine (most machines should provide 24 V directly from the battery).

Note: The IronTwo must be installed so the operator can see the screen. Use care not to place the IronTwo in a location that might compromise visibility or block an exit from the cab.

Safety Information and Warnings

Safety information and warnings

Refer to the safety manual of each machine for proper operation and safety precautions. Store this guide and all related safety information with related machine manuals for future reference.

Prior to installing and operating GradeMetrix®, read and follow all safety precautions as outlined in this manual.

Review and adhere to the follow safety warnings:

- Before you begin working on the machine, use the machine's master switch to disconnect power to the machine.
- A human operator is required to manually maintain a safe operating speed.
- GradeMetrix® is a grade reference tool and is not designed to replace the machine's operator. **Do NOT allow a driver to operate without safety instructions. Avoid obstacles to prevent human, machine, and property injury.**

Important: The safety warnings contained in this manual are intended as guidelines and are not meant to be a complete list of potential hazards.

What's Included in Your Kit

Kit contents

Your GradeMetrix® kit contains the parts listed in Table 1-1, Installation Kit Contents.

Table 1-1: Installation Kit Contents

Level	Part Number	Description	Qty
1	051-0406-10	CBL, IO, VR500, 22-PIN to 5-PIN, 3.5M	1
1	051-0407-10	CBL,IO,IronX Bulkhead, 4m	1
1	150-0053-10	IronX BT_Wifi Antenna	1
1	150-0054-10	IronX Cellular Antenna	1
1	676-0036-0	ADAPTER,MINI-C,N2K,BULKHEAD	1
1	710-0148-10	IronX Flush Mount Kit	1
1	710-0149-10	IronX U-Mount Kit	1
1	710-0157-10	KIT, VR500 MACH. CTROL MOUNT	1
1	710-0159-10	KIT, VR500 MACH. CTROL MAGNETS	1
1	710-0186-20	KIT,CAN SENSOR,CABLES	1
2	051-0425-20	Cable, M12 CAN M/F Sensor, 3m	2
2	051-0425-30	Cable, M12 CAN M/F Sensor, 5m	3
1	710-0223-10	KIT, BT/WIFI ANTENNA WITH ADAPTER	1
1	710-0230-10	GradeMetrix Consumables Kit, VR500	1
1	710-0260-10	KIT, SENSORS, LOADER	1
2	710-0217-10	KIT, GMS-1 SENSOR MOUNT, WITH COVER	1
2	710-0218-10	KIT, GMS-1 SENSOR MOUNT, BASIC	2
1	750-5019-10	SENSOR,GMS-1,VER,M12-5PIN,M-F	2
1	750-5020-10	SENSOR,GMS-1,HOR,M12-5PIN,M-F	1
1	750-0245-10	CAN TERMINATION RESISTOR, M12(F)	1
1	752-0028-10	VR500 RECEIVER, HGSS	1

Continued on next page

What's Included in Your Kit, Continued

Kit contents,
continued

The kit also comes with an IronTwo terminal.

Table 1-1: Installation Kit Contents (continued)

Level	Part Number	Description	Qty
1	980-7008-10	IronTwo (Americas + EMEA)	1
2	752-0040-10	HGNSS IronTwo Display	1
2	051-0426-10	HGNSS IronTwo Bulkhead Cable	1
2	050-0046-20	CBL,ADO,PWR ADAPT, GRADEMATRIX	1
2	050-0022-01	CBL,ADO,POWER	1

OR

Level	Part Number	Description	Qty
1	980-7009-10	IronTwo (Americas + EMEA)	1
2	752-0040-20	HGNSS IronTwo Display	1
2	051-0426-10	HGNSS IronTwo Bulkhead Cable	1
2	050-0046-20	CBL,ADO,PWR ADAPT, GRADEMATRIX	1
2	050-0022-01	CBL,ADO,POWER	1

NOTE: Due to manufacturing processes outside of HGNSS purview, the installer may be required to adapt the GradeMetrix® kit to your individual system.

Continued on next page

What's Included in Your Kit, Continued

Kit contents,
continued

If you have an articulating loader, an encoder must be ordered. You may order the encoder with, or without, a bracket (bracket referenced in this user manual).

Part Number	Description
980-5018-10	KIT, SENSOR, ROTARY ENCODER, HGNSS
710-0250-10	KIT, ROTARY ENCODER W/ MOUNTING BRACKETS

Machine Inspection Checklist

Machine Inspection Checklist

To ensure peak performance, GradeMetrix® should be installed only after a thorough machine inspection has been conducted.

To avoid bodily and machine injury, follow the machine inspection checklist below:

- Park the machine on a clean and level surface.
 - Turn off the machine and remove +power from the batteries.
 - Lower all implements to the ground.
 - Apply the parking brake and chock wheels if necessary.
 - Inspect any drilling and/or cutting sites to ensure no electrical wiring damage will be incurred.
 - Periodically re-measure the bucket/blade width at the tips to adjust accuracy due to blade wear.
-

Chapter 2: Sensor Installation

Overview

Introduction

The loader uses a GMS-1 sensor on the chassis for machine pitch/roll, a GMS-1 for the boom angle and a GMS-1 sensor on the bucket for bucket angle. This chapter details the steps required for installing these sensors.

Contents

	Topic	See Page
	GMS-1 Sensor Installation	16
	Rotary Encoder Installation	26

GMS-1 Sensor Installation

Sensors


There are two types of GMS-1 sensors. There is a horizontal sensor (P/N: 750-5020-10) used on the chassis and a vertical sensor (P/N: 750-5019-10) used on the blade.

It is extremely important to ensure the horizontal and vertical sensors are mounted in the correct location.

Important: Take care and ensure the horizontal and vertical sensors are mounted in the correct position.

The labels on the GMS-1 sensors clearly indicate each sensor.

Below is a horizontal sensor label.



Below is a vertical sensor label.



The mounting bracket must be welded to the appropriate locations:

- **Body sensor** – The horizontal slope sensor used to measure the pitch and roll of machine.
- **Boom sensor** – The vertical tilt sensor used to measure the boom angle.
- **Bucket sensor** - The vertical tilt sensor used to measure the bucket/blade lift.

Important: It is important to choose safe welding locations for each sensor. Before doing any welding, make sure that the IronTwo is disconnected with the machine isolated. This may mean disconnecting a battery terminal lead.

Continued on next page

GMS-1 Sensor Installation, Continued

Brackets

The GMS-1 sensors include a base bracket (P/N: 602-1194-10) that can be welded to the machine. This bracket has two welding holes, so the bracket can be welded to the machine and hide the weld. Refer to Figure 2-1 bracket dimensions.




Figure 2-1: Bracket dimensions

Strain relief wings are also included. Screw the strain relief wing onto the bracket with the provided 14mm M6x1mm screws. The CAN cable can be zip-tied to the strain relief wing.

Figure 2-2 shows the drawing of P/N: 602-1196-10 strain relief wing.




Figure 2-2: P/N 602-1196-10 strain relief wing

Continued on next page

GMS-1 Sensor Installation, Continued

Brackets, continued

After the base bracket has been welded onto the machine, the GMS-1 sensor can be bolted onto the bracket with the provided 20mm M6x1mm screws.




Figure 2-3: Base Bracket Screws




Figure: 2-4: Bracket

Continued on next page

GMS-1 Sensor Installation, Continued

Brackets, continued

One strain relief plate and one spacer (P/N: 602-1197-10) is included for the bucket. The spacer can be attached to the base bracket on the opposite side of the strain relief wing using the provided 14mm M6x1mm screws. See the following example.

A cover is added to the sensor bracket for protection.




Figure 2-5: Strain Relief Plate and Spacer

Note: The standoffs in the installation are used only because a cover is placed (not bolted) over the installation.

For the chassis, use the M6 screws instead of the standoffs, and bolt (P/N: 602-1195-10) the cover onto the installation.

Continued on next page

GMS-1 Sensor Installation, Continued

Sensor Placement

Place the horizontal sensor on the chassis and level to the loader body.
Place the label of the GMS-1 sensor either facing up or facing down.

The LED light can be placed facing left, right, forward, or backwards. Take care to square the sensor so the LED faces one of these locations.

The vertical sensor must be placed on the blade. Place the label facing forward (toward the front of the machine) or backward (toward the cab).

The LED light can be placed to face up, down, left, or right. The base bracket should be welded onto the blade and the cover placed over the sensor. The coil cable is connected to this sensor. It is best to place the LED where you can see it, since it can be used for diagnostics. The LED should remain green if everything is configured and working correctly. Red indicates an error.



Figure 2-6: Horizontal Sensor and Chassis

Continued on next page

GMS-1 Sensor Installation, Continued

Install sensors To install the sensors, start at the bucket of the loader. Start at the bucket and work back towards the chassis because surplus cable is easier to protect at the chassis.

Weld the bucket sensor on the back of the bucket in a protected place to minimize material rollover damage. The bracket has two square holes in it to allow for welding.



Figure 2-7: Bucket Sensor Mount

Mount the sensor with the LED facing forward. The kit comes with two 3-meter (10 feet) CAN cables and three 5-meter (16 feet) CAN cables. Use the shortest cable that will allow you to safely route the cable to the boom. It is best to use the shortest cable near the bucket to avoid excess cable near the bucket. Add the strain relief plate and standoffs per Figure 2-5 and bolt the cover on.

Continued on next page

GMS-1 Sensor Installation, Continued

Install sensors,
continued

The below photo shows a bucket sensor with the cover with the cable mounted with strain relief. The CAN cable is also run through hydraulic hose for additional protection.



Figure 2-8: Bucket Sensor

Continued on next page

GMS-1 Sensor Installation, Continued

Install sensors, continued

Next, mount the boom sensor. The boom sensor can be mounted on the inside of the boom to better protect it, as shown below. Cable loom can be added for better protection of the cables. The boom sensor is mounted where possible in a parallel alignment to a line between the boom and bucket pins. The LED is facing forward. The strain relief plates allow you to firmly attach the CAN cables to the brackets for protection.




Figure 2-9: Boom sensor installed on the inside of the boom

Continued on next page

GMS-1 Sensor Installation, Continued

Install sensors, continued

The chassis sensor needs to be installed horizontally on the chassis. The chassis articulates. **It is important to install the chassis sensor on the same side as the GNSS antennas.**

In the example below, the wheel loader articulates around the red line.



Continued on next page

GMS-1 Sensor Installation, Continued

Install sensors, continued

The GNSS antenna is on top of the cab, and so it's important that the chassis sensor be installed on that side of the red line (the cab side).

In the example below, the chassis sensor is shown installed on the cab side of the articulation point, on the same side as the VR500.



If you are installing this system onto an articulating loader, please see the section on installing the rotary encoder. Otherwise, the chassis sensor will connect to the IronTwo cable (see Figure 2-11).

Rotary Encoder Installation

Installing the encoder

For an articulating wheel loader, it is necessary to know the angle of the articulation point. To do this, install an encoder over the articulation point.



Figure 2-10: Articulation Point

It is important that the encoder is directly over the pivot point. If the encoder is not directly over the articulation point, there will be a horizontal shift on the encoder bracket when the machine articulates.

Continued on next page

Rotary Encoder Installation, Continued

Installing the encoder,
continued
Installing the encoder



Figure 2-11: Articulation Point

The encoder comes with a divot in the bracket to help you center it over the pivot point.

Continued on next page

Rotary Encoder Installation, Continued

Installing the
encoder,
continued



Figure 2-12: Pivot Point

Continued on next page

Rotary Encoder Installation, Continued

Installing the encoder,
continued

The guide pin can be removed after welding the base.




Figure 2-13: Guide Pin

Next, the bracket can be welded to the machine. It is possible that spacers may be needed to add depth to the base of the bracket.

Continued on next page

Rotary Encoder Installation, Continued

Installing the
encoder,
continued



Figure 2-14: Encoder with Bracket

A base is provided that can be welded to the machine. You can screw in the rod.

Continued on next page

Rotary Encoder Installation, Continued

Installing the
encoder,
continued



Figure 2-15: Encoder Shaft

Chapter 3: Installing the VR500 Antenna

Overview

Introduction Chapter 3 contains the information you need to install the VR500 antenna to your GradeMetrix loader system.

Contents

Topic	See Page
Install the VR500 Antenna	33

Install the VR500 Antenna

Install the VR500 antenna

Install the VR500 on the roof of the cab.

The VR500 antenna may be installed parallel or perpendicular to the centerline of the machine.

If installing the VR500 perpendicular to the centerline of the machine, place the primary antenna on the left-hand side of the machine and secondary on the right-hand side.

If installing the VR500 parallel to the centerline, install the primary antenna in the back and install the secondary antenna in front.



Continued on next page

Install the VR500 Antenna, Continued

Install the
VR500 antenna,
continued



Continued on next page

Install the VR500 Antenna, Continued

Steps to install the VR500 antenna

To install the VR500 antenna, follow the steps as detailed in Table 3-1.

Table 3-1: Install VR500 Antenna


Step	Action														
1	Install the VR500 antenna onto the mounting bracket.														
2	If welding to a surface plate, (Weld Plate Kit P/N: 710-0158-10), square it center and close to the centerline of cab.														
3	<p>If using magnetic mounting (Mag Mount Kit P/N: 710-0157-10), remove the bottom plate and install the magnets directly on the cross bars.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>IMPORTANT: If the antenna mount moves or the antenna location is changed, the calibration and measure-up must be repeated, or the machine accuracy will be inaccurate. We recommend permanently marking the exact location for future reference.</p> </div>														
4	<p>Figure 3-1 shows the VR500 mounting brackets. If you are using a weld-on mount, use the bottom plate.</p> <p>Do not use the bottom plate if you are using the magnetic mount.</p> <p>Table 3-1: Permanent mount (P/N: 710-0157-10)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Part Number</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>602-1186-10</td> <td>BRACKET, VR500 MC MOUNT</td> </tr> <tr> <td>602-1185-10</td> <td>PLATE, WELDED, VR500 MC MOUNT</td> </tr> <tr> <td>681-1076-10</td> <td>PLUG, LDPE, FOR 23.4mm DIA HOLE</td> </tr> <tr> <td>675-1342-10</td> <td>SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS</td> </tr> <tr> <td>678-1146-10</td> <td>WSHR, FLT, 0.344" ID, 0.75" OD, SS 18-8</td> </tr> <tr> <td>678-1145-10</td> <td>WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8</td> </tr> </tbody> </table>	Part Number	Description	602-1186-10	BRACKET, VR500 MC MOUNT	602-1185-10	PLATE, WELDED, VR500 MC MOUNT	681-1076-10	PLUG, LDPE, FOR 23.4mm DIA HOLE	675-1342-10	SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS	678-1146-10	WSHR, FLT, 0.344" ID, 0.75" OD, SS 18-8	678-1145-10	WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8
Part Number	Description														
602-1186-10	BRACKET, VR500 MC MOUNT														
602-1185-10	PLATE, WELDED, VR500 MC MOUNT														
681-1076-10	PLUG, LDPE, FOR 23.4mm DIA HOLE														
675-1342-10	SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS														
678-1146-10	WSHR, FLT, 0.344" ID, 0.75" OD, SS 18-8														
678-1145-10	WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8														

Continued on next page

Install the VR500 Antenna, Continued

Steps to install the VR500 antenna, continued

Table 3-1: Install VR500 antenna (continued)

Step	Action												
<p>4 (cont.)</p>	<div style="text-align: center;">  </div> <p>Figure 3-1: VR500 mounting brackets</p> <p>Table 3-2: Magnet Mount: (P/N: 710-0158-10)</p> <table border="1" data-bbox="570 1329 1401 1667"> <thead> <tr> <th>Part Number</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>602-1186-10</td> <td>BRACKET, VR500 MC MOUNT</td> </tr> <tr> <td>681-1076-10</td> <td>PLUG, LDPE, FOR 23.4mm DIA HOLE</td> </tr> <tr> <td>675-1342-10</td> <td>SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS</td> </tr> <tr> <td>678-1145-10</td> <td>WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8</td> </tr> <tr> <td>478-0020-10</td> <td>MAGNET, BASE, ENCASED, NEODYMIUM, 1.75"OD, .375"THK</td> </tr> </tbody> </table>	Part Number	Description	602-1186-10	BRACKET, VR500 MC MOUNT	681-1076-10	PLUG, LDPE, FOR 23.4mm DIA HOLE	675-1342-10	SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS	678-1145-10	WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8	478-0020-10	MAGNET, BASE, ENCASED, NEODYMIUM, 1.75"OD, .375"THK
Part Number	Description												
602-1186-10	BRACKET, VR500 MC MOUNT												
681-1076-10	PLUG, LDPE, FOR 23.4mm DIA HOLE												
675-1342-10	SCR, BUTTON HEAD, HEX, M8X1.25, 20MM, SS												
678-1145-10	WSHR, LCK, 8.5mm ID, 14.8mm OD, SS.18-8												
478-0020-10	MAGNET, BASE, ENCASED, NEODYMIUM, 1.75"OD, .375"THK												
<p>5</p>	<p>Apply cable wrap on the cable (cable P/N: 051-0406-10) where the cable may be exposed to chaffing, rubbing, or high heat to extend the cable life.</p>												

Continued on next page

Install the VR500 Antenna, Continued

Running Cables

The IronTwo has a bulkhead cable that runs from the IronTwo to an M12 male CAN connector and 6-pin Deutsch connector (See [Appendix D Cable Pin-Outs](#) for more information).




Figure 3-2: IronTwo J3 Connector

Continued on next page

Chapter 4: IronTwo

Overview

Introduction Chapter 4 contains installation information for the IronTwo display.

Contents

	Topic	See Page
	IronTwo Display Installation	39

IronTwo Display Installation

Install the IronTwo

The GradeMetrix® Loader Installation Kit comes with the following components:

1. IronTwo (P/N: 752-0040-10 or 752-0040-20)
2. IronTwo Power Cable (P/N:050-0022-01 + P/N: 050-0046-01)
3. IronTwo U-Mount Kit (P/N: 710-0149-10)



IronTwo Flush Mount Kit (P/N: 710-0148-10)

To install the components, you must have:

1. Philips Screwdriver
2. Nut driver



Continued on next page

IronTwo Display Installation, Continued

Install the IronTwo, continued

The IronTwo control panel console and mounting assembly (RAM mount included in the GradeMetrix® Loader Installation Kit) should be installed inside of the cab in a location that gives the operator a clear view.

There are several options for mounting the IronTwo control box. Regardless of which option is used, the first step is to screw the provided RAM ball (from either of the above kits) to the back of the IronTwo, as shown below:



Figure 4-1: IronTwo back view

Continued on next page

IronTwo Display Installation, Continued

Install the IronTwo, continued

Regardless of which mounting method is used, you can put the adjustable arm on the RAM ball.



Figure 4-2: Adjustable arm

IronTwo Display Installation, Continued

Install the IronTwo,
continued

Follow these steps to install the IronTwo control box to your machine:

Table 4-1: Install IronTwo control box

Step	Action
1	Attach the 1.5" RAM ball to the rear of the IronTwo using the included bolts.
2	Install the 1.5" RAM base mount to an unobstructed location in the cab for console mounting. Note: The RAM swivel mount can be used to adjust the location and viewing angle of the console.
3	Using the IronTwo U-Mount Kit (P/N: 710-0149-10), mount the IronTwo to the window rails at the right-side of machine cab.
4	Ensure adequate cable slack is provided, so the IronTwo can swivel on the RAM mount without putting stress on the cables.

The IronTwo power cable runs power to the console.

IMPORTANT!
The main power cable (P/N: 050-0022-01, P/N: 050-0046-01 connected) leads should be installed to system power (9-36 +VDC and chassis ground).

Do NOT ground to the negative terminal of the battery; always ground to the machine chassis.

IronTwo Display Installation, Continued

IronTwo cable schematic

The IronTwo power cable comes with an ignition wire (orange wire) that can be connected to switch power. If connected to switch power, the IronTwo will automatically be turned on after receiving power. If you do not want to use switch power, connect the ignition to constant power.

The IronTwo bulkhead adapter cable harness (P/N: 051-0426-10) must be installed and routed along the interior side of the cab. Install harness cables away from sharp edges and other areas that could damage cables. The cable provides the following connections for the installation:

- **Serial (1)** – 6-pin Deutsch Connector -Connects to the GNSS receiver.
- **CAN (1)** – M12 Connector -Connects to CAN axial sensors for monitoring boom, stick, and bucket movement.

Note: When installing cables, ensure you leave enough slack behind the IronTwo so the display screen may be moved in any direction and will not place any stress on the cabling.

The diagrams below show the cable schematics for P/N: 051-0426-10. The J1 connector plugs into the IronTwo. The J2 connector connects a CAN cable. The J3 connector connects to the VR500 cable.




Figure 4-3: Cable schematic for P/N: 051-0426-10 (IronTwo)

Chapter 5: GradeMetrix® System

Overview

Introduction This chapter provides information necessary to use the GradeMetrix® System to measure and setup your equipment.

Contents


Topic	See Page
Measure and Set Up Equipment	45
Configure Machine Measure	47
Set Up Sensor	50
Calibrate System	54
Quick Calibrate	58
3D Calibration	60
Verify Machine Accuracy	74
Save Machine Settings	77

Measure and Set Up Equipment

Steps to measure and set up equipment

To measure and setup your equipment, follow the steps as detailed in Table 5-1: Measure and Set Up Equipment. Make sure that you're logged in as an **Administrator**.

Table 5-1: Measure and Set Up Equipment



Step	Action
1	<p>Select Equipment Setup.</p> 
2	<p>Select Loader in the General Settings screen.</p> 

Continued on next page

Measure and Set Up Equipment, Continued

Steps to measure and set up equipment, continued

Table 5-1: Measure and Set Up Equipment (continued)

Step	Action
3	<p>Assign a Machine ID.</p> <p>Note: Your Machine ID should be a unique identifier that will identify this specific machine to your company.</p>
4	<p>Select the unit of measure. Click NEXT.</p> 
5	<p>Follow the screen directions for measuring the machine.</p> <p>Locate the four tabs across the top below Machine Geometry for machine measure configuration.</p> <ul style="list-style-type: none"> • Antenna - Antenna location • Chassis - Body size/graphical representation in run screen • Lengths – Boom dimensions & boom pin location • Attachment - Bucket configuration 

Configure Machine Measure

Configure Machine Measure

To configure your machine measure, follow the steps as detailed in Table 5-2.

Table 5-2: Configure machine measure


Step	Action														
1	<p data-bbox="581 558 1385 663">On the Antenna tab, select the type of antenna and receiver you are using. For loader installations, select the VR500 receiver.</p> <table border="1" data-bbox="581 705 1385 1682"> <thead> <tr> <th data-bbox="581 705 846 741">Field</th> <th data-bbox="846 705 1385 741">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="581 741 846 777">Type</td> <td data-bbox="846 741 1385 777">Select VR500.</td> </tr> <tr> <td data-bbox="581 777 846 812">Mount</td> <td data-bbox="846 777 1385 812">Select Chassis.</td> </tr> <tr> <td data-bbox="581 812 846 938">Pitch orientation</td> <td data-bbox="846 812 1385 938">The VR500 orientation is parallel with the machine's tracks and the arrow points in the direction of forward travel.</td> </tr> <tr> <td data-bbox="581 938 846 1064">Roll orientation</td> <td data-bbox="846 938 1385 1064">Roll orientation is perpendicular to the machine's tracks with the arrow pointing to the right side of machine.</td> </tr> <tr> <td data-bbox="581 1064 846 1373">MBias</td> <td data-bbox="846 1064 1385 1373">This value will automatically be calculated during the 3D calibration and does not need to be manually typed in. MBias is the angular offset between the VR500's heading and the machine's heading. If the machine is facing due north (0 degrees) and the VR500 reads 5 degrees, the MBias is 5 degrees.</td> </tr> <tr> <td data-bbox="581 1373 846 1682">Right</td> <td data-bbox="846 1373 1385 1682">This value is the distance of the primary antenna from the centerline of the machine. If the primary antenna is to the left of the centerline, this value is negative. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.</td> </tr> </tbody> </table>	Field	Description	Type	Select VR500 .	Mount	Select Chassis .	Pitch orientation	The VR500 orientation is parallel with the machine's tracks and the arrow points in the direction of forward travel.	Roll orientation	Roll orientation is perpendicular to the machine's tracks with the arrow pointing to the right side of machine.	MBias	This value will automatically be calculated during the 3D calibration and does not need to be manually typed in. MBias is the angular offset between the VR500's heading and the machine's heading. If the machine is facing due north (0 degrees) and the VR500 reads 5 degrees, the MBias is 5 degrees.	Right	This value is the distance of the primary antenna from the centerline of the machine. If the primary antenna is to the left of the centerline, this value is negative. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.
Field	Description														
Type	Select VR500 .														
Mount	Select Chassis .														
Pitch orientation	The VR500 orientation is parallel with the machine's tracks and the arrow points in the direction of forward travel.														
Roll orientation	Roll orientation is perpendicular to the machine's tracks with the arrow pointing to the right side of machine.														
MBias	This value will automatically be calculated during the 3D calibration and does not need to be manually typed in. MBias is the angular offset between the VR500's heading and the machine's heading. If the machine is facing due north (0 degrees) and the VR500 reads 5 degrees, the MBias is 5 degrees.														
Right	This value is the distance of the primary antenna from the centerline of the machine. If the primary antenna is to the left of the centerline, this value is negative. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.														

Continued on next page

Configure Machine Measure, Continued

Configure Machine Measure, continued

Table 5-2: Configure machine measure (continued)


Step	Action						
1 (cont.)	<table border="1"> <thead> <tr> <th data-bbox="574 474 846 516">Field</th> <th data-bbox="846 474 1411 516">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="574 516 846 709">Behind</td> <td data-bbox="846 516 1411 709">This value is the distance from the primary antenna to the blade. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.</td> </tr> <tr> <td data-bbox="574 709 846 905">Height</td> <td data-bbox="846 709 1411 905">This value is the height of the antenna above the tracks (measured to the lip of the VR500). Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.</td> </tr> </tbody> </table>	Field	Description	Behind	This value is the distance from the primary antenna to the blade. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.	Height	This value is the height of the antenna above the tracks (measured to the lip of the VR500). Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.
Field	Description						
Behind	This value is the distance from the primary antenna to the blade. Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.						
Height	This value is the height of the antenna above the tracks (measured to the lip of the VR500). Note: You do not need to enter this value. It will be calculated automatically during the 3D calibration.						
2	<p>Click the Chassis tab. Type the body length and width per the diagram below. These values can be approximate, as they are only used for graphics.</p> 						

Continued on next page

Configure Machine Measure, Continued

Configure Machine Measure, continued

Table 5-2: Configure machine measure (continued)


Step	Action
3	<p>Click the Attachment tab. Type buckets length and width. The base is measured from the buckets deepest point to teeth/blade edge. The BA (base angle) will populate from the calibration menu.</p> 

Configure Machine Measure

Configure Machine Measure

After clicking **Next** in the screen above, you will see the **Sensor Placement** screen.

Table 5-3: Set up sensor



Step	Action
1	<p>Click Sensor Network. Set Network to J1939.</p> 

Continued on next page

Configure Machine Measure, Continued

Configure Machine Measure, continued

Table 5-3: Set up sensor (continued)


Step	Action
2	<p>Each sensor is unconfigured.</p> <p>Click the sensor name and click Configure. A dialogue window displays. Click the dropdown box next to Placement. If the sensor is on the bucket, select Bucket. If the sensor is on the chassis, select Chassis. For the bucket sensor, check Use internal termination. Click OK.</p>  <p>You will need 4 sensors: chassis, front-steering, boom, and bucket. If a rotary encoder was installed, the rotary encoder sensor will be shown and you will need to set Direction. If you mount the encoder upside down, select Flip Direction.</p> 

Continued on next page

Configure Machine Measure, Continued

Configure Machine Measure, continued

Table 5-3: Set up sensor (continued)

Step	Action												
3	<p>Set up the orientation of the sensor. Mount Position refers to the direction of the label.</p> <p>For the chassis sensor:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">If ...</th> <th style="text-align: left;">Then ...</th> </tr> </thead> <tbody> <tr> <td>the label is facing up</td> <td>Set to Label Up</td> </tr> <tr> <td>the label is facing down</td> <td>Set to Label Down</td> </tr> </tbody> </table> <p>For the blade sensor:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">If ...</th> <th style="text-align: left;">Then ...</th> </tr> </thead> <tbody> <tr> <td>the label is facing forward</td> <td>Set to Label Forward</td> </tr> <tr> <td>The label is facing toward the cab</td> <td>Set to Label Back</td> </tr> </tbody> </table> 	If ...	Then ...	the label is facing up	Set to Label Up	the label is facing down	Set to Label Down	If ...	Then ...	the label is facing forward	Set to Label Forward	The label is facing toward the cab	Set to Label Back
If ...	Then ...												
the label is facing up	Set to Label Up												
the label is facing down	Set to Label Down												
If ...	Then ...												
the label is facing forward	Set to Label Forward												
The label is facing toward the cab	Set to Label Back												

Continued on next page

Configure Machine Measure, Continued

Configure
Machine
Measure,
continued

Table 5-3: Set up sensor (continued)


Step	Action
4	If Mount Facing is selected, a pull-down screen display. You can select from the listed options for the bucket sensor's arrow orientation.
5	Click FINISH .

Calibrate System

Calibrate system

To calibrate the system, follow the steps as detailed in Table 5-4: Calibrate System. The loader should be outside with a clear view of the sky and no obstructions. Use this method to calibrate all the sensors using GradeMetrix.

Table 5-4: Calibrate System



Step	Action
1	<p>Click Calibrate Sensors and follow instructions.</p> <p>It is recommended to use a firm, flat surface during the calibration process.</p> 

Continued on next page

Calibrate System, Continued

Calibrate system, continued

Table 5-4: Calibrate System (continued)



Step	Action
2	<p>Follow the instructions on the screen. Locate a firm, flat level surface twice the length of the machine. Place the machine so the bucket sits in the middle as shown below.</p> <p>Place the bucket flat on the ground (with no weight on it or placed in 'float'). Mark both corners of the bucket.</p> <p>Select Calibrate. Click Next.</p> 
3	<p>Follow the instructions on the screen.</p> <p>Carefully lift the bucket so as to not damage the marks and track the machine to rotate 180 degrees and carefully place the bucket to align with the mark made at the last step</p> <p>Select Calibrate. Select Finish.</p> 

Continued on next page

Calibrate System, Continued

Calibrate system, continued

Table 5-4: Calibrate System (continued)



Step	Action
4	<p>The follow the instructions on the screen. Square the articulation point. The azimuth of the bucket should be the same as the azimuth of the chassis. There should be no rotation of the boom or bucket. This determines the zero point of the rotary encoder.</p> <p>Note: if you do not have a rotary encoder installed, this step will not be shown.</p> 
5	<p>Use a string line, laser, total station, or any other available tool to level the boom. The boom pin to bucket pin must be level.</p> 

Continued on next page

Calibrate System, Continued

Calibrate system, continued

Table 5-4: Calibrate System (continued)

Step	Action
6	<p>Align the bucket pin with the bucket teeth and press Calibrate.</p> 
7	<p>Using a level, position the bottom of the bucket into a level plane and press Calibrate. Press Finish to complete.</p> 


Continued on next page

Quick Calibrate

Steps to quick calibrate

To quick calibrate the system, follow the steps as detailed in Table 5-5: Quick Calibrate.

Table 5-5: Quick Calibrate


Step	Action
1	<p>Click Quick Calibrate.</p> <p>This method is a direct setting of a single sensor and works well with a calibrated 'Smart Level' tool.</p>  <p>The screenshot shows the Maricopa software interface with a dark background. A red box highlights the 'Quick Calibrate' icon, which depicts a level tool. Other icons visible include 'Equipment Setup', 'Calibrate Sensors', '3D Calibration', 'RTKSource Configuration', 'Receiver Configuration', and 'Update Firmware'. The interface also features a top status bar with the name 'Maricopa' and various system icons, and a bottom navigation bar with directional and control buttons.</p>

Continued on next page

Quick Calibrate, Continued

Steps to quick calibrate, continued

Table 5-5: Quick Calibrate (continued)

Step	Action
2	<p>Select the sensor to be calibrated.</p> <p>Pitch/Roll Place the Smart Level on a flat part of the machine running rear of the machine to the bucket. Enter the ‘Smart Level’ readings of the pitch. Place the Smart Level on a flat surface running across the machine i.e. door to door. Enter the roll values for the sensor.</p> <p>Boom Bring the boom to level from boom pin to bucket pin. (Use string line/laser/total station). Press Calibrate.</p> <p>Bucket Bring the bucket level from the bucket pin to the tip/teeth. . (Use string line/laser/total station). Press Calibrate. It’s good idea is to complete this with the boom in its level calibrated position.</p> 
3	Click OK when you are finished calibrating all the sensors.

3D Calibration


3D Calibration

Before proceeding with the 3D calibration, ensure the chassis and bucket sensors are calibrated. Face the machine **North**.

The VR500 on the loader and the C631 rover must be RTK Fixed. Make sure the C631, connected to SiteMetrix™ Grade, is running the same projection as GradeMetrix. To check if the C631 is in the same datum, set it next to the primary antenna of the VR500. Verify the readings are close between the two. If the projection is incorrect, the northing and easting will show obvious errors.

To calibrate a GradeMetrix® Loader, use SiteMetrix Grade.

Table 5-6: SiteMetrix Grade Points

Step	Action
1	<p>Click the Bluetooth icon on the top-right of the screen.</p>  <p>A dialogue window displays. Click Search to search for Bluetooth devices.</p> 

Continued on next page

3D Calibration, Continued


3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
2	<p>Click Search to search for the receiver. The Bluetooth ID is the serial number. There is no Bluetooth pin. Set Mode to either Rover, Base, or Static.</p> <p>Under Name, use the option to name the C631 as “base” or “rover”, rather than using the serial number.</p> <p>Click Connect.</p> <p>After connecting to the rover, configure the RTK. Go to the menu, scroll to the right, and click RTKSource.</p> <p>SiteMetrix Grade can receive RTK over NTRIP and use the internal UHF radio or an external UHF radio.</p>
3	<p>If using NTRIP, you can use the data collector’s internet (if internal cellular modem or WiFi) or the C631’s internal GSM modem. To setup click Settings.</p> <div data-bbox="576 1134 1315 1564" style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p>NTRIP Settings</p> <p>NTRIP Client: <input type="text" value="GradeMetrix"/> </p> <p>APN Name: <input type="text"/> </p> <p>APN Username: <input type="text"/> </p> <p>APN Password: <input type="text"/> </p> </div>

Continued on next page

3D Calibration, Continued

3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
4	<p>If the NTRIP Client is set to GradeMetrix, the data collector's internet will be used to access the NTRIP caster and the RTK messages will transfer back to the C631 via Bluetooth.</p> <p>If the NTRIP Client is set to Receiver, the C631's internal modem will be used.</p> <p>Type the APN Name, Username, and Password.</p> <p>Type a Caster name. You can add multiple NTRIP casters to SiteMetrix Grade (all saved in a database).</p> <p>Type the IP address/DNS, Port, Username, and Password. Click Download Source Table.</p> 

Continued on next page

3D Calibration, Continued

3D Calibration,
continued

Table 5-6: SiteMetrix Grade Points (continued)


Step	Action
5	<p>Select the correct mount point. If using a VRS network (or the nearest base station), click Send Position To Caster Every and select an interval for your position to send to the caster.</p> <p>Click Auto Reconnect to ensure that the software reconnects to the NTRIP caster every time it opens or if internet is lost and re-gained. Click OK.</p> <div style="border: 1px solid black; padding: 5px;"> <p>Note: After clicking OK, the NTRIP client is the only source of RTK (even if the internal UHF radio is configured). If you wish to switch to a configured internal UHF radio, go to RTKSource Configure, click Internal Radio, and click OK.</p> </div>

Continued on next page

3D Calibration, Continued

3D Calibration,
continued

Table 5-6: SiteMetrix Grade Points (continued)


Step	Action
6	<p>Alternatively, you can use the Internal Radio.</p> <p>Click the Internal Radio tab. If you have the correct administrative settings, you can enter channels using Channel Configuration.</p> <p>Warning: You are responsible for verifying which frequencies and bandwidths can be set up for your region.</p> <p>Select the channel, protocol, FEC (if applicable), and scrambling (if applicable).</p> <p>Click OK.</p> <div data-bbox="574 978 1403 1171" style="border: 1px solid black; padding: 5px;"> <p>Note: After you click OK, the internal UHF radio is the primary source of RTK (even if the NTRIP client is configured) the receiver will use the radio. If you wish to switch to a configured the NTRIP client, go to RTKSource Configure, click NTRIP, and click OK.</p> </div> 

Continued on next page

3D Calibration, Continued

3D Calibration,
continued


Table 5-6: SiteMetrix Grade Points (continued)

Step	Action
7	<p>Finally, you can select an External Radio.</p> <p>Click External Radio. SiteMetrix Grade does not support the configuration of an external radio, but you can set the baud rate of the serial port of the C631.</p> <p>On the bottom of the C631 are two Lemo connectors. One connector has 5 pins for an external radio, and the other has 7 pins.</p> 
8	<p>Verify the antenna height is correct.</p> 

Continued on next page

3D Calibration, Continued

3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
9	<p>Go to the main menu. Click Calculations.</p> 
10	<p>Click Vehicle Calibration Wizard.</p> 

Continued on next page

3D Calibration, Continued


3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
11	<p>Select Loader.</p> <p>Start 3D Calibration Measurement Wizard</p> <p>This wizard will step you through the process of measuring the vehicle for use as input for the GradeMetrix 3D Calibration wizard. You may cancel the process at any time and can backup to re-measure any of the points.</p> <p>Continue wizard for: <input type="text" value="Loader"/></p> <ul style="list-style-type: none"> • Before measuring, please make sure the mapping, localization, the geoid shift file, and the horizontal shift file for the current job are configured and working with the base station. • All measurements are sampled and averaged to give the best result. Remember to keep your rod vertical and still during the sampling process. • Make sure you square your blade before measuring. <p style="text-align: right;"> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Cancel"/> </p>
12	<p>North Facing Primary Antenna Measurement (step 1)</p> <p>Position the loader until it is facing North. Make sure the blade is placed on the ground. Press Record to measure the position of the primary antenna.</p> <p>Primary Northing: <input type="text" value="50549.450ft"/></p> <p>Primary Easting: <input type="text" value="60797.897ft"/></p> <p>Primary Height: <input type="text" value="315.088ft"/></p> <div style="display: flex; align-items: center;"> <div style="text-align: center;"> <p>0°</p> <p>0°</p> </div> </div> <div style="text-align: center; margin-top: 10px;"> </div> <p style="text-align: center; margin-top: 10px;"> <input type="button" value="Record"/> <input type="text" value="0%"/> </p> <p style="text-align: right;"> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Cancel"/> </p>
13	<p>Enter Secondary Antenna Position (step 2)</p> <p>Leaving the loader facing North and the blade resting on the ground, measure and record the secondary antenna position. Once measured, enter the northing and easting into the fields provided.</p> <p>Secondary Northing: <input type="text" value="50549.466ft"/></p> <p>Secondary Easting: <input type="text" value="60684.000ft"/></p> <p>Secondary Height: <input type="text" value="315.085ft"/></p> <div style="text-align: center; margin-top: 10px;"> </div> <p style="text-align: right; margin-top: 10px;"> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Cancel"/> </p>

Continued on next page

3D Calibration, Continued


3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
14	<div data-bbox="581 478 1396 934"> <p>Enter Baseline Positions 1 and 2 (step 3)</p> <p>Leaving the loader facing North and the blade resting on the ground, measure and record the center of the blade and the center of the rear chassis. Once measured, enter the northings and eastings into the fields provided.</p> <p>Baseline Northing 1: <input type="text" value="50551.000ft"/></p> <p>Baseline Easting 1: <input type="text" value="60800.000ft"/></p> <p>Baseline Height 1: <input type="text" value="315.000ft"/></p> <p>Baseline Northing 2: <input type="text" value="50521.000ft"/></p> <p>Baseline Easting 2: <input type="text" value="60800.000ft"/></p> <p>Baseline Height 2: <input type="text" value="315.000ft"/></p>  <p style="text-align: right;"> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Cancel"/> </p> </div> <div data-bbox="581 982 922 1444"> </div> <div data-bbox="1026 982 1377 1444"> </div>

Continued on next page

3D Calibration, Continued

3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**


Step	Action
15	<p>Enter Blade Lateral Positions (step 4)</p> <p>Leaving the loader facing North and the blade resting on the ground, measure and record the left and right side of the blade. Once measured, enter the northings and eastings into the fields provided.</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Lateral Northing 1: <input type="text" value="50550.000ft"/></p> <p>Lateral Easting 1: <input type="text" value="60790.000ft"/></p> <p>Lateral Height 1: <input type="text" value="315.000ft"/></p> <p>Lateral Northing 2: <input type="text" value="50550.000ft"/></p> <p>Lateral Easting 2: <input type="text" value="60805.000ft"/></p> <p>Lateral Height 2: <input type="text" value="315.000ft"/></p> </div> <div style="width: 45%; text-align: center;">  </div> </div> <div style="text-align: right; margin-top: 10px;"> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Cancel"/> </div> <p>The 3D Calibration Summary displays all of your primary antenna offsets. Click Finish.</p>

Continued on next page

3D Calibration, Continued

3D Calibration,
continued

Table 5-6: SiteMetrix Grade Points (continued)

Step	Action										
16	<div style="display: flex; justify-content: space-around;">  </div> <div style="border: 1px solid gray; padding: 10px; margin-top: 10px;"> <p>3D Offset Calculation Summary</p> <p>These are the new adjustments for the antenna height, and machine azimuth bias. Press <i>Back</i> if you wish to change any values. Press <i>Finish</i> to accept the new values.</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">1. Antenna Right:</td> <td style="border: 1px solid gray; padding: 2px;">-2.078ft</td> </tr> <tr> <td>2. Antenna Behind:</td> <td style="border: 1px solid gray; padding: 2px;">0.554ft</td> </tr> <tr> <td>3. Antenna Height:</td> <td style="border: 1px solid gray; padding: 2px;">0.085ft</td> </tr> <tr> <td>4. MBIAS:</td> <td style="border: 1px solid gray; padding: 2px;">-179.990°</td> </tr> <tr> <td>5. PBIAS:</td> <td style="border: 1px solid gray; padding: 2px;">0.002°</td> </tr> </table> <div style="text-align: right; margin-top: 10px;">  </div> <div style="text-align: right; margin-top: 10px;"> <input type="button" value="Back"/> <input checked="" type="button" value="Finish"/> <input type="button" value="Cancel"/> </div> </div>	1. Antenna Right:	-2.078ft	2. Antenna Behind:	0.554ft	3. Antenna Height:	0.085ft	4. MBIAS:	-179.990°	5. PBIAS:	0.002°
1. Antenna Right:	-2.078ft										
2. Antenna Behind:	0.554ft										
3. Antenna Height:	0.085ft										
4. MBIAS:	-179.990°										
5. PBIAS:	0.002°										

Continued on next page

3D Calibration, Continued

3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**


Step	Action																														
16	<p>To save the file, insert a USB thumb drive to your HT20 tablet and save the file.</p> <div data-bbox="581 552 1396 1003" style="border: 1px solid gray; padding: 5px;"> <p>Measurement Summary</p> <p>These are the measurements to finish the 3D calibration for GradeMetrix. You can import the output of this tool directly into GradeMetrix. Press <i>Finish</i> to write the measurements to a file.</p> <table border="1" data-bbox="589 615 1388 745"> <thead> <tr> <th></th> <th>Tag</th> <th>Northing</th> <th>Easting</th> <th>Height</th> </tr> </thead> <tbody> <tr> <td>2nd Antenna</td> <td>AP</td> <td></td> <td></td> <td></td> </tr> <tr> <td>Chassis Center</td> <td>CL1</td> <td>50559.216ft</td> <td>60833.270ft</td> <td>502.545ft</td> </tr> <tr> <td>Blade Center</td> <td>CL2</td> <td>50579.268ft</td> <td>60833.571ft</td> <td>502.546ft</td> </tr> <tr> <td>Blade Left</td> <td>BL</td> <td>50579.159ft</td> <td>60829.335ft</td> <td>502.655ft</td> </tr> <tr> <td>Blade Right</td> <td>BR</td> <td>50559.204ft</td> <td>60838.319ft</td> <td>502.543ft</td> </tr> </tbody> </table> <p style="text-align: right;"> <input type="button" value="Back"/> <input checked="" type="button" value="Finish"/> <input type="button" value="Cancel"/> </p> </div>		Tag	Northing	Easting	Height	2nd Antenna	AP				Chassis Center	CL1	50559.216ft	60833.270ft	502.545ft	Blade Center	CL2	50579.268ft	60833.571ft	502.546ft	Blade Left	BL	50579.159ft	60829.335ft	502.655ft	Blade Right	BR	50559.204ft	60838.319ft	502.543ft
	Tag	Northing	Easting	Height																											
2nd Antenna	AP																														
Chassis Center	CL1	50559.216ft	60833.270ft	502.545ft																											
Blade Center	CL2	50579.268ft	60833.571ft	502.546ft																											
Blade Left	BL	50579.159ft	60829.335ft	502.655ft																											
Blade Right	BR	50559.204ft	60838.319ft	502.543ft																											

Continued on next page

3D Calibration, Continued

3D Calibration, continued



Table 5-6: SiteMetrix Grade Points (continued)

Step	Action
17	<p>Return to the GradeMetrix® loader. Click the 3D Calibration icon in GradeMetrix® Loader.</p> 
18	<p>Position the machine facing North and click Record.</p> <div data-bbox="581 997 1399 1459"> <p>North Facing Primary Antenna Measurement (step 1)</p> <p>Position the loader until it is facing North. Make sure the blade is placed on the ground. Press <i>Record</i> to measure the position of the primary antenna.</p> <p>Primary Northing: <input type="text" value="50549.450ft"/></p> <p>Primary Easting: <input type="text" value="60797.897ft"/></p> <p>Primary Height: <input type="text" value="315.088ft"/></p>  <p> 0°</p> <p> 0°</p> <p> Record <input type="text" value="0%"/></p> <p> Back  Next  Cancel</p> </div>

Continued on next page

3D Calibration, Continued


3D Calibration, continued **Table 5-6: SiteMetrix Grade Points (continued)**

Step	Action
19	<p>A prompt displays to load your file from SiteMetrix Grade. Click Yes.</p> 
20	<p>The 3D Calibration Summary displays all of your primary antenna offsets. Click Finish.</p> 

Verify Machine Accuracy

Verify machine accuracy To verify the accuracy of the machine, follow the steps as detailed in Table 5-7: Verify Machine Accuracy.

Table 5-7: Verify Machine Accuracy



Step	Action
1	<p>From the main operational screen, select the “folder” icon in the upper-right corner of the screen.</p> 

Continued on next page

Verify Machine Accuracy, Continued

Verify machine accuracy, continued

Table 5-7: Verify Machine Accuracy (continued)


Step	Action
2	<p>Verify you have an RTK Fixed solution before proceeding.</p>  <p>The screenshot shows the Maricopa software interface with the 'VEH Info' tab selected. The status bar at the top right indicates 'RTK Fixed' with a green signal strength icon and the time '3:40 PM'. The main display area is divided into four sections: 'Raw Position Information', 'Raw Status Information', 'Local Antenna Position', and 'Directional Information'. The 'Raw Position Information' section lists: Latitude: N33°04'02.9207", Longitude: W111°56'12.6082", Height: 339.528m, Separation: -30.644m, Orthometric: 370.171m, Speed: 0.000m/s, Solution: RTK Fixed, SATS Used: 22, Visible SATS: 22. The 'Raw Status Information' section lists: UTC Date: 2021-07-19, UTC Time: 22:40:16, PDOP: 0.814, HDOP: 0.500, VDOP: 0.643, HRMS: 0.02ft, VRMS: 0.03ft, RTK Status: 2s, RTCM3, BaseID: 420, Quality: 91%. The 'Local Antenna Position' section lists: Northing: 50514.93ft, Easting: 60845.39ft, Elevation: 512.04ft, Separation: 0.00ft. The 'Directional Information' section lists: Heading: 128.3° (GNSS), LBias: 1.429°, Declination: 9.96°, CSEP: 1.686ft, Speed: 0.0mph.</p>
3	<p>Select the VEH (Vehicle) tab to verify the blade accuracy.</p>  <p>The screenshot shows the Maricopa software interface with the 'VEH Info' tab selected. The status bar at the top right indicates 'RTK Fixed' with a green signal strength icon and the time '3:40 PM'. The main display area is divided into three sections: 'Vehicle Information', 'Status Information', and 'Design Information'. The 'Vehicle Information' section lists: Northing: 50510.84ft, Easting: 60849.68ft, Elevation: 502.74ft, Station: Off Guide. The 'Status Information' section lists: Azimuth: 129.1°, MBias: -2.289°, LBias: 1.429°, Speed: 0.0mph, Direction: Forward, Status: Stopped. The 'Design Information' section lists: Elevation: 502.68ft, Cut/Fill: 0.00ft (cut), Grading Offset: 0.00ft, Cross-Slope: 0.00%, Long-Slope: 0.00%. There are also two buttons: '2D Point Check' and '3D Point Check'.</p>

Continued on next page

Verify Machine Accuracy, Continued

Verify machine accuracy, continued

Table 5-7: Verify Machine Accuracy (continued)


Step	Action																																				
4	<p>Select 3D Point Check to check the accuracy at multiple locations. Use a rover to verify accuracy at left blade tip, right blade tip, and center blade.</p>  <p>The screenshot shows the Hemisphere software interface with the '3D Point Check' menu open. The menu lists several points of interest with their coordinates:</p> <table border="1" data-bbox="797 653 1182 863"> <thead> <tr> <th>Point-Of-Interest</th> <th>Northing</th> <th>Easting</th> <th>Elevation</th> </tr> </thead> <tbody> <tr> <td>Antenna</td> <td>50515.047ft</td> <td>60845.268ft</td> <td>512.034ft</td> </tr> <tr> <td>Mast</td> <td>50515.048ft</td> <td>60845.266ft</td> <td>502.595ft</td> </tr> <tr> <td>Tracks</td> <td>50517.292ft</td> <td>60841.860ft</td> <td>502.595ft</td> </tr> <tr> <td>Blade-Arm</td> <td>50517.292ft</td> <td>60841.860ft</td> <td>502.595ft</td> </tr> <tr> <td>Blade</td> <td>50510.981ft</td> <td>60849.617ft</td> <td>502.594ft</td> </tr> <tr> <td>Center</td> <td>50510.981ft</td> <td>60849.617ft</td> <td>502.594ft</td> </tr> <tr> <td>Left</td> <td>50515.363ft</td> <td>60853.183ft</td> <td>502.593ft</td> </tr> <tr> <td>Right</td> <td>50506.598ft</td> <td>60846.050ft</td> <td>502.594ft</td> </tr> </tbody> </table> <p>Other visible information in the screenshot includes:</p> <ul style="list-style-type: none"> Vehicle Information: Northing: 50510.98ft, Easting: 60849.62ft, Elevation: 502.59ft, Station: Off Guide. Design Information: Elevation: 502.68ft, Cut/Fill: 0.00ft (cut), Grading Offset: 0.00ft, Cross-Slope: 0.00%, Long-Slope: 0.00%. Status Information: RTK Fixed, 3:40 PM. 	Point-Of-Interest	Northing	Easting	Elevation	Antenna	50515.047ft	60845.268ft	512.034ft	Mast	50515.048ft	60845.266ft	502.595ft	Tracks	50517.292ft	60841.860ft	502.595ft	Blade-Arm	50517.292ft	60841.860ft	502.595ft	Blade	50510.981ft	60849.617ft	502.594ft	Center	50510.981ft	60849.617ft	502.594ft	Left	50515.363ft	60853.183ft	502.593ft	Right	50506.598ft	60846.050ft	502.594ft
Point-Of-Interest	Northing	Easting	Elevation																																		
Antenna	50515.047ft	60845.268ft	512.034ft																																		
Mast	50515.048ft	60845.266ft	502.595ft																																		
Tracks	50517.292ft	60841.860ft	502.595ft																																		
Blade-Arm	50517.292ft	60841.860ft	502.595ft																																		
Blade	50510.981ft	60849.617ft	502.594ft																																		
Center	50510.981ft	60849.617ft	502.594ft																																		
Left	50515.363ft	60853.183ft	502.593ft																																		
Right	50506.598ft	60846.050ft	502.594ft																																		

Save Machine Settings

Save Machine Settings

To save the settings for your machine, use the following steps.

Table 5-8: Save Machine Settings


Step	Action
1	<p>To save your machine settings, go to Equipment Setup:</p> 
2	<p>Click Next.</p> 

Continued on next page

Save Machine Settings, Continued

Save Machine Settings, continued

Table 5-8: Save Machine Settings (continued)

Step	Action
3	<p>Click Next until the final screen displays. Click Export to... and save the machine settings to a USB thumb drive.</p> 

Appendix A: Troubleshooting

Overview

Introduction Appendix A provides troubleshooting for the dozer installation.

Note: It is important to review each category in detail to eliminate it as a problem.

Contents

	Topic	See Page
	Troubleshooting	80

Troubleshooting

Troubleshooting **Table A-1: Troubleshooting**

Issue	Possible Solution
Incorrect Position	<p>First, check a control point with the machine and the survey rover. If the horizontal or vertical position is off, first consider if it is off by a consistent amount throughout the jobsite, or if the position bust varies throughout the job. If it is consistent, consider the following:</p> <ul style="list-style-type: none"> • Check your machine measurements/offsets. If any of these are incorrect, your projected position will be off. • Bad localization. Make sure that all points in your localization file have low residuals and/or that the correct coordinate system is selected (this can make a significant difference). <p>If there is an inconsistent position bust, check:</p> <ul style="list-style-type: none"> • Sensor mounting was incorrectly selected and/or the sensor was not calibrated. This is evident if your position is correct when flat, but not if you are on a slope. • If the position at the GPS antenna is correct, but the position bust worsens as you approach the cutting edge, it may be a heading offset error.
No GPS Position	<p>First, check to see if the VR500 is powered on. There are LED lights underneath the receiver. If the receiver is not powered, disconnect the cable and use a multimeter to verify it is receiving power and ground. Check the monitor screen and sky plots to see if there is any data from the receiver. If there is no data, but the receiver is powered, there could be a bad serial connection / mismatched baud rate.</p>

Continued on next page

Troubleshooting, Continued

Troubleshooting, continued

Table A-1: Troubleshooting (continued)

Issue	Possible Solution
No RTK	<ol style="list-style-type: none"> 1. If using a base station onsite (versus an NTRIP service), first check to verify the base station is turned on. 2. If the base station is turned on and sending RTK out over UHF, check to see if the Tx (or TD on some radios) light is flashing once per second. 3. Verify that the other rovers on the job site are receiving RTK corrections, if available. 4. If it is flashing once per second, check to verify the settings (frequency, bandwidth, forward error corrections, modulation, and protocol) at the base match that of the rover. 5. Check to see if the UHF light at the rover is blinking once per second. If it is, refer to #3. 6. The receiver may be out of UHF range. Consider installing the external UHF antenna (if using a VR500). You may need to install repeaters. See if the RTK corrections work when the machine is closer to the base station. 7. If using NTRIP, check cellular connectivity. One option is to exit GradeMetrix® and verify you can go to a website via the browser.
IronTwo Will Not Power On	<ol style="list-style-type: none"> 1. Check to verify the power cable is connected to machine power. The positive should go to a reliable, clean power source and ground to the chassis of the machine. 2. Disconnect the cable and refer to the pinout to see if 12V or 24V (depending on machine) is going into the IronTwo by using a multi-meter. If the multimeter reads 12V or 24V, then power is confirmed, and the IronTwo may need to be serviced. If you do not have any power, then check your power source, ground, and all fuses.

Appendix B: Technical Specifications

Overview

Introduction Appendix B contains the technical specifications for the VR500 GNSS receiver, the IronTwo control box, and the GMS-1 sensor.

Contents

	Topic	See Page
	VR500 Receiver	83
	IronTwo	88
	GMS-1 Sensor	90

VR500 Receiver

VR500 Receiver **Table B-1: VR500 Receiver**

Item	Specification
Receiver type	GPS, GLONASS, BeiDou, Galileo and RTK with carrier phase and L-band dual antenna
Channels	744
Satellites	12 L1CA GPS 12 L1P GPS 12 L2P GPS 12 L2C GPS 15 L5 GPS 12 G1 GLONASS 12 G2 GLONASS 12 G3 GLONASS 22 B1 BeiDou 22 B2 BeiDou 14 B3 BeiDou 12 Galileo E1 12 Galileo E5a 12 Galileo E5b 3 SBAS or 3 additional L1CA GPS 2 L-band
Primary antenna	GPS L1,L1P,L2C,L2P,L5 GLONASS G1,G2,Pcode BeiDou B1,B2,B3 Galileo E1,E5a,E5b L-band
Secondary antenna	GPS L1,L1P,L2C,L2P GLONASS G1,G2 BeiDou B1,B2 Galileo E1,E5b L-band
GPS sensitivity	-142 dBm

Continued on next page

VR500 Receiver, Continued

VR500 Receiver, continued **Table B-1: VR500 Receiver (continued)**

Item	Specification		
SBAS tracking	3-channel, parallel tracking		
Update rate	10 Hz standard, and 20 Hz available		
Horizontal accuracy		RMS (67%)	2DMRS (95%)
	RTK ^{1,2}	8 mm + 1 ppm	15 mm + 2 ppm
	Atlas	0.04 m	0.08 m
	SBAS (WAAS) ¹	0.3 m	0.6 m
	Autonomous, no SA ¹	1.2 m	2.4 m
Heading accuracy	0.27° RMS		
Pitch/roll accuracy	< 1° RMS		
ROT	145°/s maximum		
Timing (1PPS) accuracy	20 ns		
Cold start time	< 60 s typical (no almanac or RTC)		
Warm start time	< 30 s typical (almanac and RTC)		
Hot start time	< 10 s (almanac, RTC, and position)		
Maximum speed	1,850 km/h (999 kts)		
Maximum altitude	18,288 m (60,000 ft)		
Differential options	SBAS, Autonomous, External RTCM v2.3, RTK v3, L-band (Atlas), and DGPS		
Antenna LNA gain input	10 to 40 dB		

Continued on next page

VR500 Receiver, Continued

VR500 Receiver, continued **Table B-2: VR500 Communication**

Item	Specification
Serial ports	3x full-duplex UART's 2x 3.3V CMOS 1x RS-232
CAN	2 CAN ports NMEA2000, ISO-11783
Baud rates	4800 - 115200
Data I/O protocol	NMEA 0183, CAN, Hemisphere GNSS binary
Correction I/O protocol	Hemisphere GNSS' ROX, RTCM v2.3 (DGPS), RTCM v3 (RTK), CMR, CMR+3, and Atlas
Timing output	1 PPS CMOS, active high, rising edge sync, 10 k Ω , 10 pF load
Event marker input	CMOS, active low, falling edge sync, 10 k Ω 10 pF load
Ethernet	1x 10/100 base-T

Table B-3: VR500 Power

Item	Specification
Input voltage	9-32 VDC
Power consumption	10.8W Maximum (All signals and L-band)
Current consumption	1.2A Maximum

Continued on next page

VR500 Receiver, Continued

VR500 Receiver, continued **Table B-5:VR500 Environment**

Item	Specification
Operating temperature	-40°C to +70°C (-40°F to +158°F)
Storage temperature	-40°C to +85°C (-40°F to +185°F)
Humidity	95% non-condensing (when installed in an enclosure)
Shock and vibration	50Gs, 11ms half sine pulse, 10 shocks in each direction and axis, total 60 shocks Operational IEC 60068-2-29 MIL-STD-810G Vibration Sine: 30.6Grms MIL-STD-810G SAE J1211 ISO 16750-3:2007 Vibration Random: 5.96Grms IEC 60068-2-64 MIL-STD-202F
EMC ⁴	CE (ISO 14982 Emissions and Immunity) FCC Part 15, Subpart B CISPR22

Continued on next page

VR500 Receiver, Continued

VR500 Receiver, continued **Table B-6: VR500 Mechanical**

Item	Specification
Dimensions	68.6 L x 22 W x 12.3 H cm
Weight	3.9 kg
Status indication	Power, GNSS, Heading, Radio
Power/Data connector	22-Pin environmentally sealed

Table B-7: VR500 L-band sensor

Item	Specification
Receiver type	Single Channel
Channels	1525 to 1560 MHz
Sensitivity	140 dBm
Channel spacing	5.0 kHz
Satellite selection	Manual and Automatic
Reacquisition time	15 seconds (typical)

Table B-8: VR500 Aiding Devices

Device	Description
Gyro	Provides smooth heading, fast heading reacquisition, and reliable < 3° heading for periods up to 3 minutes when loss of GPS has occurred. ⁴
Tilt sensor	Provide pitch and roll data and assist in fast startup and reacquisition of heading solution.

IronTwo

IronTwo system

Table B-9: System

Item	Specification
Processor	Intel® Celeron N3350
Storage	SSD 64GB, RAM 4GB
Operating System	Windows 10

IronTwo mechanical

Table B-10: Mechanical

Item	Specification
Dimensions	263.28 W x 171 H x 35.7 D (mm) 10.4 W x 6.7 H x 1.4 D (in)
Weight	1.38 kg (3.04 lbs)
Mount	Adjustable 1.5" RAM ball mount

IronTwo environmental

Table B-11: Environmental

Item	Specification
Operating Temperature	-20°C to +60°C (-4°F to 140°F)
Operating Humidity	30% ~ 90% (non-condensing)
Enclosure	IP65

Continued on next page

IronTwo, Continued

IronTwo power

Table B-12: Power

Item	Specification
Input Voltage	9 - 36 VDC

IronTwo screen

Table B-13: Screen

Item	Specification
Display Type	10.1" TFT edge-to-edge projective capacitive multi-touch screen
Size	192.8 mm × 116.9 mm (7.59" × 4.6")
Resolution	1920 × 1200, 800:1
Luminance	700 cd/m

IronTwo communication

Table B-14: Communication

Item	Specification
Serial Port	2 x RS232
CANBUS	2 × CANBUS
USB	2 × USB 2.0
Ethernet	2x 10/100 LAN
Wi-Fi	IEEE 802.11a/b/g/n/ac
Cellular	4G LTE
Bluetooth	Bluetooth 4.1

GMS-1 Sensor

GMS-1 sensor measurement range

Table B-15: Measurement range

Item	Specification
Pitch	$\pm 180^\circ$
Roll	$\pm 85^\circ$

GMS-1 sensor accuracy

Table B-16: Sensor accuracy

Item	Specification
Absolute Accuracy	$\pm 0.30^\circ$
Resolution	$\pm 0.01^\circ$
Repeatability	$\pm 0.05^\circ$
Refresh Rate	20 Hz
Base Sensor Cycle	5ms
Hysteresis	$\pm 0.05^\circ$

GMS-1 sensor electrical

Table B-17: Electrical

Item	Specification
Supply Voltage	9 – 30 VDC
Current	$\leq 65\text{mA @ } 10\text{ VDC}$
EMC Emission	DIN EN 61000-6-4
EMC Immunity	DIN EN 61000-6-2

Continued on next page

GMS-1 Sensor, Continued

GMS-1 sensor
pin-outs




Figure B-1: GMS-1 Sensor pin-out

Table B-18: GMS-1 Sensor pin-out

Signal	Connector	Pin Number
Power Supply	Connector 1	2
GND	Connector 1	3
CAN High	Connector 1	4
CAN Low	Connector 1	5
CAN GND	Connector 1	1
Power Supply	Connector 2	2
GND	Connector 2	3
CAN High	Connector 2	4
CAN Low	Connector 2	5
CAN GND	Connector 2	1

Appendix C: Cable Pin-Outs

Overview

Introduction Appendix C contains the cable pin-outs used for installation of the VR500 and IronTwo.

Contents

Topic	See Page
Part Number 051-0426-10	93
Part Number 051-0406-10	95
Part Number 051-0407-10	96
VR500 Installation Schematic	97
Index	99

Part Number 051-0426-10

P/N: 051-0426-10





Figure C-1: Part Number: 051-0426-10

Continued on next page

Part Number 051-0426-10, Continued

P/N: 051-0426-
P/N: 051-0426-
10, continued

Table C-1: Part Number 051-0426-10 Pin-Outs

J1	J2	J3	Signal
1	4		CAN High
2	5		CAN Low
3		6	IronTwo RS232 Rx
4		1	IronTwo RS232 Tx
5		2	
6			
7		2	Signal Ground
8			
9			
10	2	3	12V+ Out
11			
12	3	5	Power Ground

Part Number 051-0406-10

P/N: 051-0406-10




Figure C-2: Part Number: 051-0406-10

Table C-2: Part Number: 051-0406-10 Pin-Outs

C1	C2	Signal
1	21	Power+
2	12	VR500 Port A RS232 Tx
3	11	VR500 Port A RS232 Rx
4	22	Power-
5	13	Signal Ground

Part Number 051-0407-10

P/N: 051-0407-10




Figure C-3: Part Number: 051-0407-10

Table C-3: Part Number: 051-0407-10 Pin-Outs

J1	J2	Signal
1	3	VR500 Port A RS232 Rx
2	5	Signal Ground
3	1	Power-
4		
5	4	Power+
6	2	VR500 Port A RS232 Tx

VR500 Installation Schematic

VR500 Installation Schematic

Table C-4: Loader Schematic, IronTwo – VR500

051-0426-10 J1	051-0426-10 J3	051-0407-10 J1	051-0407-10 J2	051-0406-10 J2	Signal
1					CAN High
2					CAN Low
3	6	6	2	12	IronTwo RS232 Rx/VR500 Tx
4	1	1	3	11	IronTwo RS232 Tx/VR500 Rx
5					
6					
7	2	2	5	13	Signal Ground
8					
9					
10	3	3	1	21	12V+ Out
11					
12	3	5	4	22	Power Ground

Index

Atlas	84	IronTwo	9
BeiDou.....	83	Message interface.....	16
Body sensor.....	16	NMEA	85
Boom sensor	16	Pitch	84
Ethernet	85	RAM.....	40, 42, 88
Firmware	14	ROX.....	85
GLONASS	83	RTCM.....	84, 85
GPS	83, 85, 87	RTK	83, 84, 85
GradeMetrix.....	6, 8	SBAS	83, 84
Heading	84	Serial ports	85
installation	6, 8, 9, 43	Status	87
Installation Kit.....	40	WAAS	84

End User License Agreement

End User license agreement

IMPORTANT - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
 - a. install or use more copies of the Software than the number of copies that have been licensed;
 - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
 - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
 - d. modify or create derivative works based on the Software;
 - e. sub-license, rent, lease, loan or distribute the Software;
 - f. permit any third party to use the Software;
 - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
 - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
 - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at any time.

Continued on next page

End User License Agreement, Continued

VR500 Installation Schematic, continued

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, Vega™, Phantom™ XF1™, XF2™, Cygnus™, Atlas™ aRTK, SureFix™, Athena™, Aquila™, Lyra™, Outback Guidance™, and EDRIVE™ are proprietary trademarks of Hemisphere GNSS, Inc. Other trademarks are the properties of their respective owners. and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential lpositioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.
11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.

Continued on next page

End User License Agreement, Continued

VR500 Installation Schematic, continued

12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.
13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.
18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere. 19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following: (a)

Continued on next page

End User License Agreement, Continued

VR500 Installation Schematic, continued

negotiate a license or other agreement so that the Product is no longer subject to such a potential claim, (b) modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product, (c) replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality, or (d) if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.

19. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
20. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.
21. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
22. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
23. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
24. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
25. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
26. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

GENERAL. This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.



Hemisphere GNSS Inc.
8515 East Anderson Drive
Scottsdale, Arizona, US 85255
Phone: 480-348-6380
Fax: 480-270-5070
PRECISION@HGNSS.COM
WWW.HGNSS.COM