



Use the built in GPS for location.

Connect to the engine via CAN or MODBUS for remote diagnostics and control.

Use a thermocouple and oil quality sensor to monitor engine oil.

Interface to the engine controller or use a fuel sender to determine fuel level.



# Generator Control and Monitoring

Know where your generator is, and how it is being utilised.

Monitor the engine for fault codes and observe oil temperature and quality to diagnose problems before they become expensive.

Ensure your asset has fuel and that the start battery is charged.

Start and stop remotely from your dashboard.