









## Available Toolbar button options

Listed below and described are additional toolbar button options that can be configured in Tools/Options/Display Options/Advanced Display Options/Toolbar Display Options..

	Exit Program	Shutdown or Exit Carlson Grade
	Activities and Delays	Shows list of Available Activities and Delays
	Reverse Vehicle	Informs Machine that it is in Reverse (Not needed if Reverse Sensor is installed)
	Reverse Video	Changes screen display from Black to White for visibility preference
	Stakeout a Point	Opens the Stakeout routine
	Rotate Through Views	Each press cycles through available views such as cross section, plan, profile, 3D, etc.
	Show GPS Skyplot	Shows detailed information on GPS tracking and signals
	Monitor System Status	Shows detailed information on GPS position, RTK correction, Solution Status (Fixed or Float), Machine position, speed, sensor information, etc.
	Create Slope	Opens the Create Slope routine
	Create Flat Pad	Opens the Create Flat Pad routine

## SiteMetrix

---

	Automatically Store Points	Opens Store Points setup
	Bench to Known Elevation	Opens the Bench to Known Elevation routine
	Show Support Movies	Opens the In-Cab Video Support feature
	Switch to/from Rod	Switches Rover reference position to/from Truck and Rod
	Flip the Guideline	Flips the Guideline offset from one side to the other for direction control
	Increase/Decrease Vertical Offset	Increases and Decreases Vertical Offsets to and from the design surface, Flat Pad, or Slope
	Drill Setup	Opens Drill Setup options and configuration
	Drill Action	Used to initiate Drilling sequence (Carlson Drill Grade Only)